

CHECK VALVES



STOCK CODE	ITEM DESCRIPTION			CURRENT STOCK
RPV-VCK0150150RFAABBINBO	1/2"150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F6, HFS.	35
RPV-VCK0150150RFAABBINBO	1/2"150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F6, HF.	23
RPV-VCK0150150RFADDBINBO	1/2"150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF.	39
RPV-VCK0150150RFADDBKNBO	1/2"150RF SW CHECK VALVE.	BC.	A105N / F316, HF	17
RPV-VCK0150150RFCDDBLNKI	1/2"150RF SW CHECK VALVE.	BC.	A351 CF8M / F316, HF.	26
RPV-VCK0150150RFEDDBINBO	1/2"150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F5 / F316, HF.	25
RPV-VCK0150150RFEDDBINBO	1/2"150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F9 / F316, HF.	10
RPV-VCK0150150RFGDDBINBO	1/2"150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F11 / F316, HF.	8
RPV-VCK0150150RFHDDBINBO	1/2"150RF P CHECK VALVE.	BC. SPRING ASSISTED	A182 F316(L) / F316, HF	149
RPV-VCK0150150RFHDDBINBO	1/2"150RF SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	69
RPV-VCK0150150RFLCDBINBO	1/2"150RF P CHECK VALVE	BC.	A350 LF2N / F316, HFS.	9
RPV-VCK0150150RFLDDBINBO	1/2"150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A350 LF2N / F316, HF.	34
RPV-VCK0150150RFLDDBKNBO	1/2"150RF SW. CHECK VALVE.	BC.	A350 LF2N / F316, HF	17
RPV-VCK0150150RFSHHBINBO	1/2"150RF P CHECK VALVE	BC. SPRING ASSISTED.	A182 F321(H) / F321, HF	10
RPV-VCK0150300RFAABBINBO	1/2"300RF P CHECK VALVE.	BC.	A105N / F6, HFS.	5
RPV-VCK0150300RFAABBKNBO	1/2"300RF SW CHECK VALVE.	BC.	A105N / F6, HFS.	4
RPV-VCK0150300RFAABBINBO	1/2"300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F6, HF.	3
RPV-VCK0150300RFAABBKNBO	1/2"300RF SW CHECK VALVE.	BC.	A105N / F6, HF.	7
RPV-VCK0150300RFADDBINBO	1/2"300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF.	53
RPV-VCK0150300RFADDBKNBO	1/2"300RF SW CHECK VALVE.	BC.	A105N / F316, HF	20
RPV-VCK0150300RFCDDBLNKI	1/2"300RF SW CHECK VALVE.	BC. ANSI B16.34.	A351 CF8M / F316, HF.	13
RPV-VCK0150300RFEDDBINBO	1/2"300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F5 / F316, HF.	5
RPV-VCK0150300RFEDDBINBO	1/2"300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F9 / F316, HF.	5
RPV-VCK0150300RFGDDBINBO	1/2"300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F11 / F316, HF.	29
RPV-VCK0150300RFHDDBINBO	1/2"300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F316(L) / F316, HF	86
RPV-VCK0150300RFHDDBINBO	1/2"300RF SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	32
RPV-VCK0150300RFLCDBINBO	1/2"300RF P CHECK VALVE	BC	A350 LF2N / F316, HFS.	4
RPV-VCK0150300RFLDDBINBO	1/2"300RF P CHECK VALVE.	BC.	A350 LF2N / F316, HF.	40
RPV-VCK0150300RFLDDBKNBO	1/2" 300RF SW. CHECK VALVE.	BC.	A350 LF2N / F316, HF	11
RPV-VCK0150300RFSHHBINBO	1/2"300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F321(H) / F321, HF	12
RPV-VCK0150300UMCDDBLNKI	1/2"300UM SW CHECK VALVE.	BC. ANSI B16.34.	A351 CF8M / F316, HF.	5
RPV-VCK0150600RFADDBINBO	1/2"600RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF.	31
RPV-VCK0150600RFLDDBINBO	1/2"600 RF P CHECK VALVE	BC. SPRING ASSISTED	A350 LF2N / F316, HF	11
RPV-VCK0150600UMADDBINBO	1/2"600UM P CHECK VALVE.	BC. SPRING ASSISTED	A105N / F316, HF.	35
RPV-VCK0150600UMADDBKNBO	1/2"600UM SW CHECK VALVE.	BC.	A105N / F316, HF.	26
RPV-VCK0150600UMCDDBLNKI	1/2"600UM SW CHECK VALVE.	BC. ANSI B16.34.	A351 CF8M / F316, HF.	10
RPV-VCK0150600UMEDDBINBO	1/2"600UM P CHECK VALVE.	BC. SPRING ASSISTED	A182 F5 / F316, HF.	15
RPV-VCK0150600UMFDDBINBO	1/2"600UM P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F9 / F316, HF.	4
RPV-VCK0150600UMGDDBINBO	1/2"600UM P CHECK VALVE.	BC. SPRING ASSISTED	A182 F11 / F316, HF.	8
RPV-VCK0150600UMHDDBINBO	1/2"600UM SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	55
RPV-VCK0150600UMIDDBINBO	1/2"600UM P CHECK VALVE.	BC.	A182 F316(L) / F316, HF.	141
RPV-VCK0150600UMJFFBKNBO	1/2"600UM SW CHECK VALVE.	BC.	A182 F304(L) / F304, HF	15
RPV-VCK0150600UMLDDBINBO	1/2"600UM P CHECK VALVE	BC. SPRING ASSISTED	A350 LF2N / F316, HF.	31
RPV-VCK0150600UMLDDBKNBO	1/2"600UM SW CHECK VALVE	BC.	A350 LF2N / F316, HF.	27
RPV-VCK0150600UMSHHBINBO	1/2"600UM P CHECK VALVE	BC. SPRING ASSISTED	A182 F321(H) / F321, HF	8
RPV-VCK0150800BWABBBKNBO	1/2" CL 800 SW CHECK VALVE.	BC. BW80.	A105N / F6, HF.	50
RPV-VCK0150800BWADDBINBO	1/2" CL 800 P CHECK VALVE.	BC. BW80. SPRING ASSIST	A105N / F316, HF	71
RPV-VCK0150800BWADDBKNBO	1/2" CL 800 SW CHECK VALVE.	BC. BW80. SPRING ASSIST	A105N / F316, HF	50
RPV-VCK0150800BWEDDBINBO	1/2" CL 800 P CHECK VALVE.	BC. BW80. SPRING ASSIST	A182 F5 / F316, HF	20
RPV-VCK0150800BWHDDBINBO	1/2" CL 800 P CHECK VALVE.	BC. BW80. SPRING ASSIST	A182 F316(L) / F316, HF	55
RPV-VCK0150800NPAABI BO	1/2" CL 800 P CHECK VALVE.	BC. NPTF.	A105N / F6.	7
RPV-VCK0150800NPAABI CA	1/2" CL 800 P CHECK VALVE.	BC. NPTF.	A105N / F6, HFS.	4
RPV-VCK0150800NPAABBINBO	1/2" CL 800 P CHECK VALVE.	BC. NPTF.	A105N / F6, HFS.	6
RPV-VCK0150800NPABBINBO	1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F6, HF.	233
RPV-VCK0150800NPABBKNBO	1/2" CL 800 SW CHECK VALVE.	BC. NPTF.	A105N / F6, HF.	16
RPV-VCK0150800NPABBWINBO	1/2" CL 800 P CHECK VALVE.	WC. NPTF. SPRING ASSIST	A105N / F6, HF.	37
RPV-VCK0150800NPACDBMNBO	1/2" CL 800 BALL CHECK VALVE	BC. NPTF.	A105N / F316 / F316 HFS	82
RPV-VCK0150800NPADDBINBO	1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F316, HF.	69
RPV-VCK0150800NPADDBKNBO	1/2" CL 800 SW CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F316, HF.	20
RPV-VCK0150800NPEDDBINBO	1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F5 / F316, HF	26
RPV-VCK0150800NPFBBINBO	1/2" CL 800 P CHECK VALVE.	BC. NPTF.	A182 F9 / F6, HF.	4
RPV-VCK0150800NPFDDBINBO	1/2" CL 800 P CHECK VALVE.	BC. NPTF.	A182 F9 / F316, HF	19
RPV-VCK0150800NPGBBINBO	1/2" CL 800 P CHECK VALVE.	BC. NPTF.	A182 F11 / F6, HF.	9
RPV-VCK0150800NPGDDBINBO	1/2" CL 800 P CHECK VALVE.	BC. NPTF	A182 F11 / F316, HF	10
RPV-VCK0150800NPHDDBINBO	1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F316L / F316, HF.	227
RPV-VCK0150800NPHDDBKNBO	1/2" CL 800 SW CHECK VALVE.	BC. NPTF.	A182 F316L / F316, HF.	94
RPV-VCK0150800NPJFFBINBO	1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F304(L) / F304, HF	58
RPV-VCK0150800NPLDDBINBO	1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A350 LF2N / F316, HF.	117
RPV-VCK0150800NPSHHBINBO	1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F321-H / F321, HF.	32
RPV-VCK0150800PLLDDBKNBO	1/2" CL 800 SW. CHECK VALVE.	BC. PLAIN END (SCH 160 FB)	A350 LF2N / F316, HF.	20
RPV-VCK0150800SWABBBINBO	1/2" CL 800 P CHECK VALVE.	BC. S/WELD. SPRING ASS.	A105N / F6, HF.	124
RPV-VCK0151500BWADDBINBO	1/2" CL1500 P CHECK VALVE.	BC. BW160. SPRING ASSIST	A105N / F316, HF	7
RPV-VCK0151500NPADDBINBO	1/2" CL1500 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F316, HF.	111
RPV-VCK0151500NPHDDBINBO	1/2" CL1500 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F316L / F316, HF.	102
RPV-VCK0151500NPLDDBINBO	1/2" CL1500 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A350 LF2N / F316, HF.	48
RPV-VCK0151500RFAABBI HA	1/2" 1500RF P.CHECK VALVE.	BC.	A105N / F6, HFS.	5
RPV-VCK0151500RFAABBINHA	1/2" 1500RF P.CHECK VALVE.	BC.	A105N / F6, HFS.	9
RPV-VCK0151500UMADDBJNBO	1/2" 1500UM P CHECK VALVE.	BC. FB. SPRING ASSISTED	A105N / F316, HF.	49
RPV-VCK0151500UMIDDBJNBO	1/2" 1500UM P CHECK VALVE.	BC. FULL BORE. SPRING.	A182 F316L / F316, HF.	12
RPV-VCK0151500UMLDDBJNBO	1/2" 1500UM P CHECK VALVE.	BC. FULL BORE. SPRING	A350 LF2N / F316, HF.	40
RPV-VCK0152500NPIDDBINBO	1/2" CL 2500 P.CHECK VALVE	BC. NPTF. SPRING ASSIST	A182 F316(L) / F316, HF	52
RPV-VCK0152500NPLDDBINBO	1/2" CL 2500 P. CHECK VALVE,	BC. NPTF. SPRING ASSIST	A350 LF2N / F316, HF	40
RPV-VCK0152500PLHDDBJNBO	1/2" CL 2500 FB P CHECK VALVE	BC. SPRING ASSIST. PLAIN END	A182 F316-L / F316, HF	10
RPV-VCK0152500PLLDDBINBO	1/2" CL 2500 P. CHECK VALVE,	BC. PLAIN END. SPRING ASS.	A350 LF2N / F316, HF	18
RPV-VCK0152500UMIDDBJNBO	1/2" 2500UM FB P CHECK VALVE	BC. SPRING ASSISTED.	A182 F316-L / F316, HF	14
RPV-VCK0152500UMLDDBJNBO	1/2" 2500UM FB P CHECK VALVE	BC. SPRING ASSISTED.	A350 LF2N / F316(L), HF	9
RPV-VCK015PN32NPBBUI SH	1/2" PN32 P CHECK VALVE. UB.	NPTF.	ALI BRONZE B148 C95800	26
RPV-VCK0200150RFAABBKNBO	3/4"150RF SW CHECK VALVE.	BC.	A105N / F6, HF.	7

CHECK VALVES

STOCK CODE	ITEM DESCRIPTION			CURRENT STOCK
RPV-VCK0200150RFADDBINBO	3/4" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF.	92
RPV-VCK0200150RFADDBKNBO	3/4" 150RF SW CHECK VALVE.	BC.	A105N / F316, HF	9
RPV-VCK0200150RFCCBL PK	3/4" 150RF SW CHECK VALVE	BC. ANSI B16.34.	A351 CF8M / F316.	5
RPV-VCK0200150RFCDDBLNKI	3/4" 150RF SW CHECK VALVE.	BC.	A351 CF8M / F316, HF.	19
RPV-VCK0200150RFEDDBINBO	3/4" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F5 / F316, HF.	5
RPV-VCK0200150RFDDDBINBO	3/4" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F9 / F316, HF.	5
RPV-VCK0200150RFGDDBINBO	3/4" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F11 / F316, HF.	5
RPV-VCK0200150RFHDDBINBO	3/4" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F316L / F316, HF.	140
RPV-VCK0200150RFHDDBKNBO	3/4" 150RF SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	34
RPV-VCK0200150RFLCDBINBO	3/4" 150RF P CHECK VALVE.	BC.	A350 LF2N / F316, HFS.	6
RPV-VCK0200150RFLDDBINBO	3/4" 150RF P CHECK VALVE.	BC. SPRING ASSISTED	A350 LF2N / F316, HF.	89
RPV-VCK0200150RFLDDBKNBO	3/4" 150RF SW. CHECK VALVE.	BC.	A350 LF2N / F316, HF	19
RPV-VCK0200150RFSHHBINBO	3/4" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F321(H) / F321, HF	10
RPV-VCK0200300RFAABBINBO	3/4" 300RF P CHECK VALVE.	BC.	A105N / F6, HFS.	6
RPV-VCK0200300RFABBBINBO	3/4" 300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F6, HF.	9
RPV-VCK0200300RFADDBINBO	3/4" 300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF.	159
RPV-VCK0200300RFADDBKNBO	3/4" 300RF SW CHECK VALVE.	BC.	A105N / F316, HF	28
RPV-VCK0200300RFCCBL PK	3/4" 300RF SW CHECK VALVE.	BC. ANSI B16.34.	A351 CF8M / F316.	10
RPV-VCK0200300RFCDDBLNKI	3/4" 300RF SW CHECK VALVE.	BC.	A351 CF8M / F316, HF.	21
RPV-VCK0200300RFEDDBINBO	3/4" 300RF P CHECK VALVE.	BC. SPRING ASSISTED	A182 F5 / F316, HF.	8
RPV-VCK0200300RFDDDBINBO	3/4" 300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F9 / F316, HF.	10
RPV-VCK0200300RFGDDBINBO	3/4" 300RF P CHECK VALVE.	BC. SPRING ASSISTED	A182 F11 / F316, HF.	27
RPV-VCK0200300RFHDDBINBO	3/4" 300RF P CHECK VALVE.	BC.	A182 F316(L) / F316, HF	128
RPV-VCK0200300RFHDDBKNBO	3/4" 300RF SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	39
RPV-VCK0200300RFLDDBINBO	3/4" 300RF P CHECK VALVE.	BC. SPRING ASSISTED	A350 LF2N / F316, HF.	63
RPV-VCK0200300RFLDDBKNBO	3/4" 300RF SW. CHECK VALVE.	BC.	A350 LF2N / F316, HF	15
RPV-VCK0200300RFSHHBINBO	3/4" 300RF P CHECK VALVE.	BC. SPRING ASSISTED	A182 F321(H) / F321, HF	13
RPV-VCK0200300UMCDDBLNKI	3/4" 300UM SW CHECK VALVE.	BC. ANSI B16.34,	A351 CF8M / F316, HF.	8
RPV-VCK0200600RFAABBINBO	3/4" 600RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F6, HF.	39
RPV-VCK0200600RFADDBINBO	3/4" 600RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF.	28
RPV-VCK0200600UMABBBINBO	3/4" 600UM P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F6, HF.	65
RPV-VCK0200600UMABBBKNBO	3/4" 600UM SW CHECK VALVE.	BC.	A105N / F6, HF.	18
RPV-VCK0200600UMADDBINBO	3/4" 600 UM P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF.	20
RPV-VCK0200600UMADDBKNBO	3/4" 600UM SW CHECK VALVE.	BC.	A105N / F316, HF.	24
RPV-VCK0200600UMCDDBLNKI	3/4" 600UM SW CHECK VALVE.	BC. ANSI B16.34,	A351 CF8M / F316, HF.	9
RPV-VCK0200600UMEDDBINBO	3/4" 600UM P CHECK VALVE.	BC. SPRING ASSISTED	A182 F5 / F316, HF.	10
RPV-VCK0200600UMFDDBINBO	3/4" 600UM P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F9 / F316, HF.	10
RPV-VCK0200600UMGDDBINBO	3/4" 600UM P CHECK VALVE.	BC. SPRING ASSISTED	A182 F11 / F316, HF.	15
RPV-VCK0200600UMHDDBINBO	3/4" 600UM SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	28
RPV-VCK0200600UMHDDBKNBO	3/4" 600UM SW CHECK VALVE.	BC.	A182 F316(L) / F316, HF.	64
RPV-VCK0200600UMIDDBINBO	3/4" 600UM P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F316(L) / F316, HF.	7
RPV-VCK0200600UMJFFBINBO	3/4" 600UM SW CHECK VALVE.	BC.	A182 F304(L) / F304, HF	43
RPV-VCK0200600UMLDDBINBO	3/4" 600UM P CHECK VALVE	BC.	A350 LF2N / F316, HF.	21
RPV-VCK0200600UMLDDBKNBO	3/4" 600UM SW CHECK VALVE	BC.	A350 LF2N / F316, HF.	25
RPV-VCK0200600UMSHHBINBO	3/4" 600UM P CHECK VALVE	BC. SPRING ASSISTED.	A182 F321(H) / F321, HF	21
RPV-VCK0200800BWABBBKNBO	3/4" CL 800 SW CHECK VALVE.	BC. BW80.	A105N / F6, HF.	14
RPV-VCK0200800BWADDBINBO	3/4" CL 800 P. CHECK VALVE.	BC. BW80. SPRING ASSIST	A105N / F316, HF	70
RPV-VCK0200800BWADDBKNBO	3/4" CL 800 SW. CHECK VALVE.	BC. BW80. SPRING ASSIST	A105N / F316, HF	20
RPV-VCK0200800BWEDDBINBO	3/4" CL 800 P. CHECK VALVE.	BC. BW80. SPRING ASSIST	A182 F5 / F316, HF	20
RPV-VCK0200800BWHDDBINBO	3/4" CL 800 P. CHECK VALVE.	BC. BW80. SPRING ASSIST	A182 F316(L) / F316, HF	39
RPV-VCK0200800NPAABBINBO	3/4" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F6, HFS.	370
RPV-VCK0200800NPABBBINBO	3/4" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F6, HF.	282
RPV-VCK0200800NPABBBKNBO	3/4" CL 800 SW CHECK VALVE.	BC. NPTF.	A105N / F6, HF.	101
RPV-VCK0200800NPABBBWINBO	3/4" CL 800 P CHECK VALVE.	WELDED COVER. NPTF.	A105N / F6, HF.	15
RPV-VCK0200800NPACBBMNBO	3/4" CL 800 BALL CHECK VALVE	BC. NPTF. SPRING ASSIST	A105N / 316 / F6, HFS.	153
RPV-VCK0200800NPADDBINBO	3/4" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F316, HF.	190
RPV-VCK0200800NPEDDBINBO	3/4" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F5 / F316, HF.	29
RPV-VCK0200800NPFBBBINBO	3/4" CL 800 P CHECK VALVE.	BC. NPTF.	A182 F9 / F6, HF.	4
RPV-VCK0200800NPFDDBINBO	3/4" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F9 / F316(L), HF.	15
RPV-VCK0200800NPGDDBINBO	3/4" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F11 / F316, HF.	155
RPV-VCK0200800NPHDDBINBO	3/4" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F316(L) / F316, HF	200
RPV-VCK0200800NPHDDBKNBO	3/4" CL 800 SW CHECK VALVE.	BC. NPTF.	A182 F316L / F316, HF.	13
RPV-VCK0200800NPJFFBINBO	3/4" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F304L / F304, HF.	103
RPV-VCK0200800NPLDDBINBO	3/4" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A350 LF2N / F316, HF.	312
RPV-VCK0200800NPSHHBINBO	3/4" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F321-H / F321, HF.	65
RPV-VCK0200800PLLDDBINBO	3/4" CL 800 SW. CHECK VALVE.	BC. PLAIN END (SCH 160 FB)	A350 LF2N / F316, HF.	30
RPV-VCK0200800SWAABBINBO	3/4" CL 800 P CHECK VALVE.	BC. S/WELD. SPRING ASS.	A105N / F6, HFS.	403
RPV-VCK0200800SWABBBKNBO	3/4" CL 800 SW CHECK VALVE.	BC. S/WELD.	A105N / F6, HF	99
RPV-VCK0200800SWACBBMNBO	3/4" CL 800 BALL CHECK VALVE	BC. S/WELD.	A105N / 316 / F316, HFS.	200
RPV-VCK0200800SWLDDBINBO	3/4" CL 800 P CHECK VALVE.	BC. S/WELD. SPRING ASS.	A350 LF2N / F316, HF	200
RPV-VCK0201500BWADDBINBO	3/4" CL1500 P CHECK VALVE.	BC. BW160. SPRING ASSIST	A105N / F316, HF	9
RPV-VCK0201500NPADDBINBO	3/4" CL1500 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F316, HF.	46
RPV-VCK0201500NPHDDBINBO	3/4" CL1500 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F316L / F316, HF.	50
RPV-VCK0201500NPLDDBINBO	3/4" CL1500 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A350 LF2N / F316, HF.	36
RPV-VCK0201500PLHDDBINBO	3/4" CL1500 P CHECK VALVE.	BC. PLAIN END. SPRING ASSIST.	A182 F316L / F316, HF.	20
RPV-VCK0201500PLDDBINBO	3/4" CL1500 P CHECK VALVE.	BC. SPRING ASSIST. PLAIN END.	A350 LF2N / F316, HF.	10
RPV-VCK0201500RFAABBI HA	3/4" 1500RF P CHECK VALVE.	BC.	A105N / F6, HFS.	9
RPV-VCK0201500SWHCCBI BO	3/4" CL1500 P CHECK VALVE.	BC. S/WELD.	A182 F316L / F316.	1
RPV-VCK0201500SWHCDBMNBO	3/4" CL1500 BALL CHECK VALVE.	BC. S/WELD. SPRING ASSIST	A182 F316L / F316, HFS	6
RPV-VCK0201500UMADDBJNBO	3/4" 1500UM P CHECK VALVE.	BC. FB. SPRING ASSISTED	A105N / F316, HF.	42
RPV-VCK0201500UMIDDBJNBO	3/4" 1500UM FB P CHECK VALVE	BC. SPRING ASSISTED.	A182 F316(L) / F316, HF	42
RPV-VCK0201500UMLDDBJNBO	3/4" 1500UM P CHECK VALVE.	BC. FULL BORE. SPRING	A350 LF2N / F316, HF.	22
RPV-VCK0202500NPIDDBINBO	3/4" CL 2500 P. CHECK VALVE	BC. NPTF. SPRING ASSIST	A182 F316(L) / F316, HF	15
RPV-VCK0202500NPLDDBINBO	3/4" CL 2500 FB P. CHECK VALVE,	BC. NPTF. SPRING ASSIST	A350 LF2N / F316, HF.	25
RPV-VCK0202500PLHDDBINBO	3/4" CL 2500 FB P. CHECK VALVE,	BC. SPRING ASSIST. PLAIN END	A182 F316(L) / F316, HF	10
RPV-VCK0202500PLDDBJNBO	3/4" CL 2500 FB P. CHECK VALVE,	BC. SPRING ASSIST. PLAIN END	A350 LF2N / F316, HF	10
RPV-VCK0202500UMIDDBJNBO	3/4" 2500UM FB P CHECK VALVE	BC. SPRING ASSISTED.	A182 F316-L / F316, HF	10
RPV-VCK0202500UMLDDBJNBO	3/4" 2500UM FB P CHECK VALVE	BC. SPRING ASSISTED.	A350 LF2N / F316(L), HF	13
RPV-VCK020PN32NPBBUI SH	3/4" PN32 P CHECK VALVE. UB.	NPTF.	ALI BRONZE. B148 C95800	23
RPV-VCK0250150RFABBBINBO	1" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F6, HF.	293
RPV-VCK0250150RFADDBINBO	1" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF.	169
RPV-VCK0250150RFADDBKNBO	1" 150RF SW. CHECK VALVE.	BC.	A105N / F316, HF	76
RPV-VCK0250150RFCDDBLNKI	1" 150RF SW CHECK VALVE.	BC. API 600	A351 CF8M / F316, HF.	48

STOCK CODE	ITEM DESCRIPTION			CURRENT STOCK
RPV-VCK0250150RFHDDBINBO	1"150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F316(L) / F316, HF	113
RPV-VCK0250150RFHDDBNBO	1"150RF SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	100
RPV-VCK0250150RFLDDBINBO	1"150RF P CHECK VALVE.	BC. SPRING ASSISTED	A350 LF2N / F316, HF.	98
RPV-VCK0250150RFLDDBKNBO	1"150RF SW. CHECK VALVE.	BC.	A350 LF2N / F316, HF	46
RPV-VCK0250150RFSHHBINBO	1"150RF P CHECK VALVE	BC. SPRING ASSISTED.	A182 F321(H) / F321, HF	24
RPV-VCK0250300RFABBINBO	1"300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F6, HF.	56
RPV-VCK0250300RFADDBINBO	1"300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF.	58
RPV-VCK0250300RFADDBKNBO	1"300RF SW CHECK VALVE.	BC.	A105N / F316, HF.	23
RPV-VCK0250300RFCDDBLNKI	1"300RF SW CHECK VALVE.	BC. API 600	A351 CF8M / F316, HF.	15
RPV-VCK0250300RFEDDBINBO	1"300RF P CHECK VALVE.	BC. SPRING ASSISTED	A182 F5 / F316, HF.	23
RPV-VCK0250300RFFDDBINBO	1"300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F9 / F316, HF.	29
RPV-VCK0250300RFGDDBINBO	1"300RF P CHECK VALVE.	BC. SPRING ASSISTED	A182 F11 / F316, HF.	39
RPV-VCK0250300RFHDDBINBO	1"300RF P CHECK VALVE.	BC. SPRING ASSISTED	A182 F316(L) / F316, HF	112
RPV-VCK0250300RFHDDBNBO	1"300RF SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	61
RPV-VCK0250300RFLDDBINBO	1"300RF P CHECK VALVE.	BC. SPRING ASSISTED	A350 LF2N / F316, HF.	58
RPV-VCK0250300RFLDDBKNBO	1"300RF SW. CHECK VALVE.	BC.	A350 LF2N / F316, HF	32
RPV-VCK0250300RFSHHBINBO	1"300RF P CHECK VALVE	BC. SPRING ASSISTED	A182 F321 / F321, HF.	26
RPV-VCK0250300RFZEEBI BO	1"300RF P CHECK VALVE.	BC.	A350 LF3 / F304.	1
RPV-VCK0250300UMCDDBLNKI	1"300UM SW CHECK VALVE.	BC. ANSI B16.34,	A351 CF8M / F316, HF.	3
RPV-VCK0250300UMEDDBINBO	1"300 UM P CHECK VALVE.	BC. SPRING ASSISTED	A182 F5 / F316, HF	10
RPV-VCK0250600RFADDBINBO	1"600RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF.	56
RPV-VCK0250600RFLDDBINBO	1"600RF P CHECK VALVE.	BC. SPRING ASSISTED	A350 LF2N / F316, HF	44
RPV-VCK0250600UMABBINBO	1"600UM P CHECK VALVE.	BC. SPRING ASSISTED	A105N / F6, HF.	49
RPV-VCK0250600UMABBKNBO	1"600UM SW CHECK VALVE.	BC.	A105N / F6, HF.	1
RPV-VCK0250600UMADDBINBO	1"600UM P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF	74
RPV-VCK0250600UMADDBKNBO	1"600UM SW CHECK VALVE.	BC.	A105N / F316, HF	36
RPV-VCK0250600UMCDDBLNKI	1"600UM SW CHECK VALVE.	BC. ANSI B16.34,	A351 CF8M / F316, HF.	3
RPV-VCK0250600UMEDDBINBO	1"600UM P CHECK VALVE.	BC. SPRING ASSISTED	A182 F5 / F316, HF.	17
RPV-VCK0250600UMFDDBINBO	1"600UM P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F9 / F316, HF.	14
RPV-VCK0250600UMGDDBINBO	1"600UM P CHECK VALVE.	BC. SPRING ASSISTED	A182 F11 / F316, HF.	17
RPV-VCK0250600UMHDDBINBO	1"600UM SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	28
RPV-VCK0250600UMIDDBINBO	1"600UM P CHECK VALVE.	BC. SPRING ASSISTED	A182 F316(L) / F316, HF.	59
RPV-VCK0250600UMJFFBKNBO	1"600UM SW CHECK VALVE	BC.	A182 F304(L) / F304, HF	13
RPV-VCK0250600UMLDDBINBO	1"600UM P CHECK VALVE.	BC. SPRING ASSISTED	A350 LF2N / F316, HF.	54
RPV-VCK0250600UMLDDBKNBO	1"600UM SW CHECK VALVE.	BC.	A350 LF2N / F316, HF.	10
RPV-VCK0250600UMSHHBINBO	1"600UM P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F321(H) / F321, HF	15
RPV-VCK0250800BWABBKNBO	1" CL 800 SW CHECK VALVE.	BC. BW80.	A105N / F6, HF.	65
RPV-VCK0250800BWADDBINBO	1" CL 800 P.CHECK VALVE.	BC. BW80. SPRING ASSIST	A105N / F316, HF.	125
RPV-VCK0250800BWADDBKNBO	1" CL 800 SW CHECK VALVE.	BC. BW80.	A105N / F316, HF	94
RPV-VCK0250800BWEDDBINBO	1" CL 800 P. CHECK VALVE.	BC. BW80. SPRING ASSIST	A182 F5 / F316, HF	17
RPV-VCK0250800BWHDDBINBO	1" CL 800 P. CHECK VALVE.	BC. BW80. SPRING ASSIST	A182 F316(L) / F316, HF	130
RPV-VCK0250800NPAABINBO	1" CL 800 P CHECK VALVE.	BC. NPTF.	A105N / F6, HFS.	352
RPV-VCK0250800NPAABWINBO	1" CL 800 P CHECK VALVE.	WELDED COVER. NPTF.	A105N / F6, HFS.	11
RPV-VCK0250800NPABBINBO	1" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F6, HF.	399
RPV-VCK0250800NPABBKNBO	1" CL 800 SW CHECK VALVE.	BC. NPTF.	A105N / F6, HF.	229
RPV-VCK0250800NPABBWINBO	1" CL 800 P CHECK VALVE.	WC. NPTF. SPRING ASSIST	A105N / F6, HF.	29
RPV-VCK0250800NPACBBMBO	1" CL 800 BALL CHECK VALVE	BC. NPTF.	A105N / 316 / F6, HFS.	1
RPV-VCK0250800NPACDBMBO	1" CL 800 BALL CHECK VALVE	BC. NPTF. SPRING ASS.	A105N / 316 / F316, HFS	291
RPV-VCK0250800NPADDBINBO	1" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F316, HF.	307
RPV-VCK0250800NPADDBKNBO	1" CL 800 SW CHECK VALVE.	BC. NPTF.	A105N / F316, HF	148
RPV-VCK0250800NPALLBMINBO	1" CL 800 BALL CHECK VALVE	BC. NPTF.	A105N / MONEL	95
RPV-VCK0250800NPEDDBINBO	1" CL 800 P CHECK VALVE.	BC. NPTF.	A182 F5 / F316, HF	93
RPV-VCK0250800NPFDDBINBO	1" CL 800 P.CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F9 / F316, HF.	18
RPV-VCK0250800NPGDDBINBO	1" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F11 / F316, HF.	49
RPV-VCK0250800NPHDDBINBO	1" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F316(L) / F316, HF	292
RPV-VCK0250800NPHDDBKNBO	1" CL 800 SW CHECK VALVE.	BC. NPTF.	A182 F316L / F316, HF.	196
RPV-VCK0250800NPJFFBINBO	1" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F304(L) / F304, HF.	50
RPV-VCK0250800NPLDDBINBO	1" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A350 LF2N / F316, HF.	112
RPV-VCK0250800NPSHHBINBO	1" CL 800 P CHECK VALVE.	BC. NPTF.	A182 F321-H / F321, HF.	47
RPV-VCK0250800PLDDBKNBO	1" CL 800 SW. CHECK VALVE.	BC. PLAIN END (SCH 160 FB)	A350 LF2N / F316, HF.	25
RPV-VCK0250800SWAABBINBO	1" CL 800 P CHECK VALVE.	BC. S/WELD. SPRING ASS.	A105N / F6, HFS.	263
RPV-VCK0250800SWACDBMBO	1" CL 800 BALL CHECK VALVE	BC. S/WELD. SPRING ASS.	A105N / 316 / F316, HFS	150
RPV-VCK0250800SWADDBINBO	1" CL 800 P CHECK VALVE.	BC. S/WELD. SPRING ASSIST	A105N / F316, HF.	13
RPV-VCK0250800SWGDDBINBO	1" CL 800 P CHECK VALVE.	BC. S/WELD. SPRING ASS.	A182 F11 / F316, HF	1
RPV-VCK0250800SWMLLBI BO	1" CL 800 P.CHECK VALVE.	BC. S/WELD.	MONEL 400 / MONEL 400.	1
RPV-VCK0251500BWADDBINBO	1" CL1500 P CHECK VALVE.	BC. BW160. SPRING ASSIST	A105N / F316, HF	18
RPV-VCK0251500NPABBINBO	1" CL1500 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F6, HF.	100
RPV-VCK0251500NPADDBINBO	1" CL1500 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F316, HF.	148
RPV-VCK0251500NPHDDBINBO	1" CL1500 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F316L / F316, HF.	68
RPV-VCK0251500NPLDDBINBO	1" CL1500 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A350 LF2N / F316, HF.	15
RPV-VCK0251500PLHDDBINBO	1" CL1500 P CHECK VALVE.	BC. SPRING ASSIST. PLAIN END	A182 F316L / F316, HF.	10
RPV-VCK0251500PLLDDBINBO	1" CL1500 P CHECK VALVE.	BC. SPRING ASSIST. PLAIN END.	A350 LF2N / F316, HF.	10
RPV-VCK0251500RFAABBI HA	1" 1500RF P.CHECK VALVE.	BC.	A105N / F6, HFS.	2
RPV-VCK0251500SWLDDBMBO	1" CL1500 BALL CHECK VALVE.	BC. S/WELD. SPRING ASS.	A350 LF2 / F316, HFS	2
RPV-VCK0251500UMADDBJNBO	1" 1500UM P CHECK VALVE.	BC. FB. SPRING ASSISTED	A105N / F316, HF.	123
RPV-VCK0251500UMIDDBJNBO	1" 1500UM P CHECK VALVE	BC. FULL BORE, SPRING	A182 F316 / F316, HF.	52
RPV-VCK0251500UMLDDBJNBO	1" 1500UM P CHECK VALVE	BC. FULL BORE. SPRING	A350 LF2N / F316, HF.	90
RPV-VCK0252500NPIDDBINBO	1" CL 2500 P. CHECK VALVE	BC. NPTF. SPRING ASSIST	A182 F316(L) / F316, HF	85
RPV-VCK0252500NPLDDBINBO	1" CL 2500 P. CHECK VALVE,	BC. NPTF. SPRING ASSIST	A350 LF2N / F316, HF	75
RPV-VCK0252500PLIDDBINBO	1" CL 2500 P. CHECK VALVE	BC, PLAIN END. SPRING ASSIST	A182 F316(L) / F316, HF	20
RPV-VCK0252500PLLDDBINBO	1" CL 2500 P. CHECK VALVE,	BC, PLAIN END. SPRING ASSIST	A350 LF2N / F316, HF	20
RPV-VCK0252500UMIDDBJNBO	1" 2500UM FB P CHECK VALVE	BC. SPRING ASSISTED.	A182 F316-L / F316, HF	42
RPV-VCK0252500UMLDDBJNBO	1" 2500UM FB P CHECK VALVE	BC. SPRING ASSISTED.	A350 LF2N / F316(L), HF	20
RPV-VCK025PN32NPBBBK SH	1" PN32 SW. CHECK VALVE.	NPTF. UB	ASTM B148 C95800	20
RPV-VCK025PN32NPBBBUI SH	1" PN32 P CHECK VALVE, UB.	NPTF.	ASTM B148 C95800.	61
RPV-VCK0400150RFADDBINBO	1.1/2"150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF.	46
RPV-VCK0400150RFADDBKNBO	1.1/2"150RF SW CHECK VALVE.	BC.	A105N / F316, HF	64
RPV-VCK0400150RFCDDBLNKI	1.1/2"150RF SW CHECK VALVE.	BC. ANSI B16.34,	A351 CF8M / F316, HF.	9
RPV-VCK0400150RFHDDBINBO	1.1/2"150RF P CHECK VALVE.	BC. SPRING ASSISTED	A182 F316(L) / F316, HF	81
RPV-VCK0400150RFHDDBNBO	1.1/2"150RF SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	30
RPV-VCK0400150RFLDDBINBO	1.1/2"150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A350 LF2N / F316, HF.	53
RPV-VCK0400150RFLDDBKNBO	1.1/2" 150RF SW. CHECK VALVE	BC.	A350 LF2N / F316, HF	17

STOCK CODE	ITEM DESCRIPTION			CURRENT STOCK
RPV-VCK0400150RFSHHBINBO	1.1/2"150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F321(H) / F321, HF	7
RPV-VCK0400150RFVVBINBO	1.1/2"150 RF FB P. CHECK VALVE.	BC. SPRING ASSISTED.	A182 F55 / UNS S32760, HF	19
RPV-VCK0400300RFABBINBO	1.1/2"300RF P CHECK VALVE	BC. SPRING ASSISTED	A105N / F6, HF.	10
RPV-VCK0400300RFADDBINBO	1.1/2"300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF.	7
RPV-VCK0400300RFADDBKNBO	1.1/2"300RF SW CHECK VALVE.	BC.	A105N / F316, HF.	35
RPV-VCK0400300RFCDDBLNKI	1.1/2"300RF SW CHECK VALVE.	BC. ANSI B16.34,	A351 CF8M / F316, HF.	3
RPV-VCK0400300RFEDDBINBO	1.1/2"300RF P CHECK VALVE.	BC. SPRING ASSISTED	A182 F5 / F316, HF.	19
RPV-VCK0400300RFGDDBINBO	1.1/2"300RF P CHECK VALVE.	BC. SPRING ASSISTED	A182 F11 / F316, HF	12
RPV-VCK0400300RFHDDBINBO	1.1/2"300RF P CHECK VALVE.	BC. SPRING ASSISTED	A182 F316(L) / F316, HF	43
RPV-VCK0400300RFHDDBKNO	1.1/2"300RF SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	7
RPV-VCK0400300RFLDDBINBO	1.1/2"300RF P CHECK VALVE	BC.	A350 LF2N / F316, HF.	22
RPV-VCK0400300RFLDDBKNBO	1.1/2"300RF SW CHECK VALVE.	BC.	A350 LF2N / F316, HF.	29
RPV-VCK0400300RFSHHBINBO	1.1/2"300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F321(H) / F321, HF	28
RPV-VCK0400300UMCDDBLNKI	1.1/2"300UM SW CHECK VALVE.	BC. ANSI B16.34,	A351 CF8M / F316, HF.	5
RPV-VCK0400300UMFDDBINBO	1.1/2"300 UM P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F9 / F316, HF	10
RPV-VCK0400600RFADDBINBO	1.1/2"600RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF.	28
RPV-VCK0400600RFADDBKNBO	1.1/2"600RF SW CHECK VALVE	BC.	A105N / F316, HF	17
RPV-VCK0400600RFUIJBINSA	1.1/2"600RF P.CHECK VALVE.	BC.	A182 F51 / S31803, HFS.	1
RPV-VCK0400600UMABDBINBO	1.1/2"600UM P CHECK VALVE.	BC.	A105N / F6, HF.	6
RPV-VCK0400600UMADDBINBO	1.1/2"600UM P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF.	43
RPV-VCK0400600UMADDBKNBO	1.1/2" 600 UM SW. CHECK VALVE	BC	A105N / F316, HF	25
RPV-VCK0400600UMCDDBLNKI	1.1/2"600UM SW CHECK VALVE.	BC. ANSI B16.34,	A351 CF8M / F316, HF.	10
RPV-VCK0400600UMEDDBINBO	1.1/2"600UM P CHECK VALVE.	BC. SPRING ASSISTED	A182 F5 / F316, HF.	19
RPV-VCK0400600UMFDDBINBO	1.1/2"600UM P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F9 / F316, HF.	9
RPV-VCK0400600UMGDDBINBO	1.1/2"600UM P CHECK VALVE.	BC. SPRING ASSISTED	A182 F11 / F316, HF.	10
RPV-VCK0400600UMHDDBKNO	1.1/2"600UM SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	19
RPV-VCK0400600UMIDDBINBO	1.1/2"600UM SW CHECK VALVE.	BC. SPRING ASSISTED.	A182 F316(L) / F316, HF.	20
RPV-VCK0400600UMJFFBKNO	1.1/2"600UM SW CHECK VALVE	BC.	A182 F304(L) / F304, HF	4
RPV-VCK0400600UMLDDBINBO	1.1/2"600UM P CHECK VALVE.	BC. SPRING ASSISTED.	A350 LF2N / F316, HF.	22
RPV-VCK0400600UMLDDBKNBO	1.1/2"600UM SW CHECK VALVE.	BC.	A350 LF2N / F316, HF.	42
RPV-VCK0400800BWABDBKNBO	1.1/2" CL 800 SW CHECK VALVE.	BC. BW80.	A105N / F6, HF.	30
RPV-VCK0400800BWADDBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. BW80. SPRING ASSIST	A105N / F316, HF	30
RPV-VCK0400800BWADDBKNBO	1.1/2" CL 800 SW CHECK VALVE.	BC. BW80.	A105N / F316, HF	40
RPV-VCK0400800BWEDDBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. BW80. SPRING ASSIST	A182 F5 / F316, HF	26
RPV-VCK0400800BWLCDDBMNSA	1.1/2" CL800 BALL CHECK VALVE	BC. BUTT WELD SCH 160	A350 LF2N / F316, HFS	5
RPV-VCK0400800NPAABBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. NPTF.	A105N / F6, HFS.	37
RPV-VCK0400800NPABBBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F6, HF.	108
RPV-VCK0400800NPABBBINBO	1.1/2" CL 800 P CHECK VALVE.	WC. NPTF. SPRING ASSIST	A105N / F6, HF.	9
RPV-VCK0400800NPADDBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F316, HF.	143
RPV-VCK0400800NPADDBKNBO	1.1/2" CL 800 SW CHECK VALVE.	BC. NPTF.	A105N / F316, HF.	73
RPV-VCK0400800NPADDBMNSA	1.1/2" CL 800 BALL CHECK VALVE	BC. NPTF. SPRING ASSIST	A105N / 316 / 316, HFS.	29
RPV-VCK0400800NPEDDBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F5 / F316, HF.	31
RPV-VCK0400800NPFDDBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F9 / F316, HF.	29
RPV-VCK0400800NPGDDBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F11 / F316, HF.	14
RPV-VCK0400800NPHDDBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F316L / F316, HF.	46
RPV-VCK0400800NPHDDBKNBO	1.1/2" CL 800 SW CHECK VALVE.	BC. NPTF.	A182 F316L / F316, HF.	35
RPV-VCK0400800NPJFFBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F304L / F304, HF.	24
RPV-VCK0400800NPLDDBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A350 LF2N / F316, HF.	24
RPV-VCK0400800NPSHHBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. NPTF.	A182 F321-H / F321, HF.	12
RPV-VCK0400800PLFDDBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. PLAIN END	A182 F9 / F316, HF	20
RPV-VCK0400800PLGDDBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. PLAIN END**	A182 F11 / F316, HF	10
RPV-VCK0400800PLHDDBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. PLAIN. SPRING ASSIST	A182 F316L / F316, HF.	10
RPV-VCK0400800PLHDDBKNO	1.1/2" CL 800 SW CHECK VALVE.	BC. PLAIN END	A182 F316L / F316, HF.	10
RPV-VCK0400800PLLDDBKNBO	1 1/2" CL 800 SW. CHECK VALVE.	BC. PLAIN END (SCH 160 FB)	A350 LF2N / F316, HF.	9
RPV-VCK0401500BWADDBINBO	1 1/2" CL 1500 P CHECK VALVE.	BC. BW160. SPRING ASSIST	A105N / F316, HF	14
RPV-VCK0401500NPADDBINBO	1.1/2" CL 1500 P.CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F316, HF.	38
RPV-VCK0401500NPHDDBINBO	1.1/2" CL 1500 P.CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F316L / F316, HF.	45
RPV-VCK0401500NPLDDBINBO	1.1/2" CL 1500 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A350 LF2N / F316, HF.	14
RPV-VCK0401500PLHDDBINBO	1 1/2" CL 1500 P CHECK VALVE.	BC. SPRING ASSIST. PLAIN END	A182 F316L / F316, HF.	5
RPV-VCK0401500PLLDDBINBO	1.1/2" CL 1500 P CHECK VALVE.	BC. SPRING ASSIST. PLAIN END	A350 LF2N / F316, HF.	5
RPV-VCK0401500RFLDDBJNBO	1.1/2" 1500RF P CHECK VALVE.	BC. FULL BORE. SPRING	A350 LF2N / F316, HF.	1
RPV-VCK0401500UMADDBJNBO	1.1/2" 1500UM P CHECK VALVE.	BC. FB. SPRING ASSISTED	A105N / F316, HF.	26
RPV-VCK0401500UMIDDBJNBO	1.1/2" 1500UM P CHECK VALVE.	BC. FULL BORE. SPRING	A182 F316 / F316, HF.	21
RPV-VCK0401500UMLDDBJNBO	1.1/2" 1500UM P CHECK VALVE.	BC. FULL BORE. SPRING	A350 LF2N / F316, HF.	42
RPV-VCK0402500NPLDDBINBO	1 1/2" CL 2500 P. CHECK VALVE	BC, NPTF. SPRING ASSIST	A350 LF2N / F316, HF	2
RPV-VCK0402500PLIDDBINBO	1 1/2" CL 2500 P. CHECK VALVE	BC, SPRING ASSISTED	A182 F316(L) / F316, HF	20
RPV-VCK0402500PLLDDBJNBO	1.1/2" 2500 FB P CHECK VALVE	BC. PLAIN ENDED	A350 LF2N / F316, HF	5
RPV-VCK0402500UMIDDBJNBO	1 1/2" 2500UM FB P CHECK VALVE	BC. SPRING ASSISTED.	A182 F316-L / F316, HF	7
RPV-VCK0402500UMLDDBJNBO	1.1/2" 2500UM FB P CHECK VALVE	BC. SPRING ASSISTED.	A350 LF2N / F316(L), HF	13
RPV-VCK040PN32NPBBUI SH	1 1/2" PN32 P CHECK VALVE, UB	NPTF.	ASTM B148 C95800	19
RPV-VCK0500150RFBBBK SH	2" 150 FF SW. CHECK VALVE	BC,	ASTM B148 C95800.	21
RPV-VCK0500150RFADDBINBO	2"150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF	49
RPV-VCK0500150RFCDDBLNPK	2"150RF SW CHECK VALVE.	BC. ANSI B16.34.	A351 CF8M / F316, HFS.	4
RPV-VCK0500150RFCDDBLNKI	2"150RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	113
RPV-VCK0500150RFDEEBLNPK	2"150RF SW CHECK VALVE	BC. ANSI B16.34.	A351 CF8 / F304.	2
RPV-VCK0500150RFDFFB NKI	2"150RF SW CHECK VALVE.	BC. ANSI B16.34.	A351 CF8 / F304, HF	18
RPV-VCK0500150RFHDDBINBO	2"150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F316(L) / F316, HF	24
RPV-VCK0500150RFLDDBINBO	2"150RF P CHECK VALVE.	BC. SPRING ASSISTED	A350 LF2N / F316, HF	10
RPV-VCK0500150RFPDDBL KI	2"150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	108
RPV-VCK0500150RFQDDBLNKI	2"150RF SW CHECK VALVE.	BC. FULL BORE. BS1868.	A217 C5 / F316, HF.	10
RPV-VCK0500150RFQDDBLNMA	2"150RF SW CHECK VALVE.	BC. FULL BORE. BS1868.	A217 C5 / F316, HF.	3
RPV-VCK0500150RFWABBLNPK	2"150UD SW CHECK VALVE.	BC. API600.	A216 WCB / F6, HFS.	5
RPV-VCK0500150RFWBBBL KI	2"150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF	106
RPV-VCK0500150RFWDBL KI	2"150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	124
RPV-VCK0500300RFADDBINBO	2"300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF.	21
RPV-VCK0500300RFADDBKNBO	2"300RF SW. CHECK VALVE	BC, FULL BORE	A105N / F316, HF	3
RPV-VCK0500300RFCCBLNMA	2"300RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316.	30
RPV-VCK0500300RFCDDBLNKI	2"300RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	99
RPV-VCK0500300RFDFFB NKI	2"300 RF SW CHECK VALVE.	BC. ANSI B16.34	A351 CF8 / F304, HF	16
RPV-VCK0500300RFEDDBLNBO	2"300RF SW. CHECK VALVE,	BC, FULL BORE	A182 F5 / F316(L), HF	14
RPV-VCK0500300RFHDDBINBO	2" 300 RF P. CHECK VALVE	BC	A182 F316(L) / F316, HF	9
RPV-VCK0500300RFLDDBINBO	2"300RF P CHECK VALVE	BC.	A350 LF2N / F316, HF.	19

STOCK CODE	ITEM DESCRIPTION			CURRENT STOCK
RPV-VCK0500300RFPDDBL KI	2"300RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	146
RPV-VCK0500300RFPDDBLNMA	2"300RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	14
RPV-VCK0500300RFQDDBLNKI	2"300RF SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	20
RPV-VCK0500300RFQDDBLNMA	2"300RF SW CHECK VALVE.	BC. FULL BORE. BS1868.	A217 C5 / F316, HF.	1
RPV-VCK0500300RFSHHBLNBO	2"300RF SW. CHECK VALVE	BC, FULL BORE	A182 F321(H) / F321, HF	23
RPV-VCK0500300RFWABBLNPK	2"300UD SW CHECK VALVE.	BC. API600.	A216 WCB / F6, HFS.	3
RPV-VCK0500300RFWBBL KI	2"300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	103
RPV-VCK0500300RFWDBL KI	2"300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	79
RPV-VCK0500300RFWDBLNMA	2"300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	1
RPV-VCK0500300RFQDDBLNKI	2"300RF SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	20
RPV-VCK0500300RFQDDBLNMA	2"300RF SW CHECK VALVE.	BC. BS 1868. NON CE	A217 WC6 / F316, HF.	9
RPV-VCK0500300UMEDDBLNBO	2" 300 UM SW. CHECK VALVE,	BC, FULL BORE	A182 F5 / F316(L), HF	29
RPV-VCK0500300UMSHHBLNBO	2"300 UM SW. CHECK VALVE	BC, FULL BORE	A182 F321(H) / F321, HF	5
RPV-VCK0500600BWWBBLNPK	2" CL 600 SW CHECK VALVE.	BC. BW 80.	A216 WCB / F6, HF.	1
RPV-VCK0500600BWWDBLNKI	2" CL 600 SW CHECK VALVE.	BC. BW 80.	A216 WCB / F316, HF.	6
RPV-VCK0500600BWXDDBLNKI	2" CL 600 SW CHECK VALVE.	BC. BW 80.	A217 WC6 / F316, HF.	4
RPV-VCK0500600RFPDDBLNMA	2"600RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	4
RPV-VCK0500600RFWBBL KI	2"600RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF	80
RPV-VCK0500600RFWDBL KI	2"600RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	54
RPV-VCK0500600UMABBKNBO	2"600UM SW CHECK VALVE.	BC.	A105N / F6, HF.	5
RPV-VCK0500600UMADDBKNBO	2"600UM SW CHECK VALVE.	BC.	A105N / F316, HF.	29
RPV-VCK0500600UMCDDDBLNKI	2"600UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	13
RPV-VCK0500600UMCDDBLNPK	2"600UM SW CHECK VALVE.	BC. ANSI B16.34.	A351 CF8M / F316, HF.	6
RPV-VCK0500600UMEDDBLNBO	2" 600 UM SW. CHECK VALVE,	BC, FULL BORE	A182 F5 / F316, HF	9
RPV-VCK0500600UMFDDBLNBO	2" 600 UM SW. CHECK VALVE,	BC, FULL BORE	A182 F9 / F316, HF	10
RPV-VCK0500600UMGDDBLNBO	2" 600 UM SW. CHECK VALVE,	BC, FULL BORE	A182 F11 / F316, HF	4
RPV-VCK0500600UMLDDBLNBO	2"600UM P CHECK VALVE.	BC. SPRING ASSISTED.	A350 LF2N / F316, HF.	25
RPV-VCK0500600UMLDDBLNKI	2" 600 UM SW. CHECK VALVE,	BC, FULL BORE	A350 LF2N / F316, HF	25
RPV-VCK0500600UMPDDBL KI	2"600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	34
RPV-VCK0500600UMPDDBLNMA	2"600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	5
RPV-VCK0500600UMSHHBLNBO	2" 600 UM SW. CHECK VALVE,	BC, FULL BORE	A182 F321-H / F321, HF	5
RPV-VCK0500600UMTHHBLNKI	2"600UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8C / F321, HF.	8
RPV-VCK0500600UMWBBL KI	2"600UM SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	80
RPV-VCK0500600UMWDBL KI	2"600UM SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	57
RPV-VCK0500600UMXDBLNKI	2"600UM SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	10
RPV-VCK0500800BWADDBINBO	2" CL 800 P. CHECK VALVE.	BC. BW80. SPRING ASSIST	A105N / F316, HF	21
RPV-VCK0500800BWADDBLNBO	2" CL 800 SW CHECK VALVE.	BC. FULL BORE, BW 80.	A105N / F316, HF	4
RPV-VCK0500800NPABBWINBO	2" CL 800 P CHECK VALVE.	WC. NPTF. SPRING ASSIST	A105N / F6, HF.	21
RPV-VCK0500800NPADDBINBO	2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F316, HF	71
RPV-VCK0500800NPADDBKNBO	2" CL 800 SW CHECK VALVE.	BC. NPTF.	A105N / F316, HF	21
RPV-VCK0500800NPADDBLNBO	2" CL 800 SW CHECK VALVE.	BC. FULL BORE, NPTF.	A105N / F316, HF	10
RPV-VCK0500800NPHDDBINBO	2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F316L / F316, HF.	67
RPV-VCK0500800NPLDDBINBO	2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A350 LF2N / F316, HF.	39
RPV-VCK0500800NPLDDBKNBO	2" CL 800 SW. CHECK VALVE.	BC. NPTF. SPRING ASSIST	A350 LF2N / F316, HF	19
RPV-VCK0500800PLGDDBLNBO	2" CL 800 SW CHECK VALVE.	BC. FULL BORE, PLAIN	A182 F11 / F316, HF	9
RPV-VCK0500800PLHDDBLNBO	2" CL 800 SW CHECK VALVE.	BC. FULL BORE, PLAIN END	A182 F316(L) / F316, HF	9
RPV-VCK0501500BWADDBLNBO	2" CL 1500 SW CHECK VALVE.	BC. FULL BORE. BW 160	A105N / F316, HF.	7
RPV-VCK0501500BWADDBLNBO	2" CL 1500 PSB SW CHECK	VALVE, BW SCH 160	A105N / F316, HF	19
RPV-VCK0501500BWNDDPLNBO	2" CL 1500 PSB SW CHECK	VALVE, FB, BW SCH XXS	A182 F22 / F316, HF	5
RPV-VCK0501500NPADDBINBO	2" CL 1500 P. CHECK VALVE	BC. NPTF	A105N / F316, HF	14
RPV-VCK0501500NPLDDBINBO	2" CL 1500 P. CHECK VALVE	BC. NPTF	A350 LF2N / F316, HF	16
RPV-VCK0501500PLDDBINBO	2" CL 1500 P. CHECK VALVE	BC. PLAIN END	A350 LF2N / F316, HF	19
RPV-VCK0501500UMADDBJNBO	2" 1500UM P CHECK VALVE.	BC. FB. SPRING ASSISTED	A105N / F316, HF.	16
RPV-VCK0501500UMHDDBLNBO	2" 1500UM SW CHECK VALVE.	BC. FULL BORE.	A182 F316(L) / F316, HF	34
RPV-VCK0501500UMIDDBJNBO	2" 1500UM P CHECK VALVE.	BC. FB. SPRING ASSISTED	A182 F316(L) / F316, HF.	7
RPV-VCK0501500UMLDDBLNBO	2" 1500UM SW CHECK VALVE.	BC. FULL BORE.	A350 LF2N / F316, HF.	70
RPV-VCK0501500UMSHHBLNBO	2" 1500UM SW CHECK VALVE.	BC. FULL BORE.	A182 F321(H) / F321, HF	11
RPV-VCK0502500BWADDBLNBO	2" CL 2500 PSB SW CHECK	VALVE, BW SCH XXS	A105N / F316, HF	7
RPV-VCK0502500BWF91PLNBO	2" CL 2500 PSB SW CHECK	VALVE, BW SCH XXS	A182 F91 / F316, HF	5
RPV-VCK0502500BWNBBPL VE	2" CL2500 SW CHECK VALVE.	PSB. BW XXS.	A182 F22 / F6, HF.	1
RPV-VCK0502500BWNDDPLNBO	2" CL 2500 PSB SW CHECK	VALVE, BW SCH XXS	A182 F22 / F316, HF	5
RPV-VCK0502500UMLDDBLNBO	2" 2500UM SW CHECK VALVE.	BC. FULL BORE.	A350 LF2N / F316, HF.	10
RPV-VCK050PN32NPBBUI SH	2" PN50 P. CHECK VALVE,	UB, RS, NPT.	B148 C95800 ALI BRONZE	14
RPV-VCK0650150UDCDBD NKI	2.1/2"150UD SW CHECK VALVE.	BC. ANSI B16.34	A351 CF8M / F316, HF	20
RPV-VCK0800150FFBBBK SH	3" 150 FF SW. CHECK VALVE	BC,	ASTM B148 C95800.	9
RPV-VCK0800150RFCDDBLNPK	3"150RF SW CHECK VALVE.	BC. ANSI B16.34.	A351 CF8M / F316, HFS.	1
RPV-VCK0800150RFCDDBLNKI	3"150RF SW CHECK VALVE.	BC. B16.34	A351 CF8M / F316, HF	31
RPV-VCK0800150RFCDDBLNMA	3"150RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	49
RPV-VCK0800150RFPDDBLNMA	3"150RF SW CHECK VALVE.	BC. FULL BORE.	A352 LCC / F316, HFS.	2
RPV-VCK0800150RFPDDBL KI	3"150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	4
RPV-VCK0800150RFPDDBLNKI	3"150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	41
RPV-VCK0800150RFPDDBLNMA	3"150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	12
RPV-VCK0800150RFQDDBLNKI	3"150RF SW CHECK VALVE.	BC. FULL BORE. BS1868	A217 C5 / F316, HF.	8
RPV-VCK0800150RFQDDBLNMA	3"150RF SW CHECK VALVE.	BC. FULL BORE. BS1868	A217 C5 / F316, HF.	1
RPV-VCK0800150RFWBBL KI	3"150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	46
RPV-VCK0800150RFWDBL KI	3"150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	63
RPV-VCK0800150RFXDDBLNMA	3"150RF SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	2
RPV-VCK0800300BWWDBLNKI	3" CL 300 SW CHECK VALVE.	BC. BW 80.	A216 WCB / F316, HF	11
RPV-VCK0800300RFCDBLNPK	3"300RF SW CHECK VALVE	BC. ANSI B16.34.	A351 CF8M / F316.	2
RPV-VCK0800300RFCDBLNKI	3"300RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	21
RPV-VCK0800300RFDFFB NKI	3"300 RF SW CHECK VALVE.	BC. ANSI B16.34	A351 CF8 / F304, HF	4
RPV-VCK0800300RFPDDBL KI	3"300RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	43
RPV-VCK0800300RFQDDBLNKI	3"300RF SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	14
RPV-VCK0800300RFTHHBLNKI	3"300RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8C / F321, HF.	11
RPV-VCK0800300RFWABBLNPK	3"300 UD SW CHECK VALVE.	BC. API 600	A216 WCB / F6, HFS	1
RPV-VCK0800300RFWBBL KI	3"300 RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF	45
RPV-VCK0800300RFWBBLNMA	3"300RF SW CHECK VALVE.	BC. BS1868.	A216 WCB / F6, HF.	1
RPV-VCK0800300RFWDBL KI	3"300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	33
RPV-VCK0800300RFWDBLNKI	3"300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	2
RPV-VCK0800300RFXDDBLNKI	3"300RF SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	17
RPV-VCK0800300UMQDDBLNVA	3" 300 UM SW CHECK VALVE	BC, NDT	A217 C5 / F316, HF	4
RPV-VCK0800600BWWDBLNKI	3" CL 600 SW CHECK VALVE.	BC. BW 80.	A216 WCB / F316, HF	5

CHECK VALVES

STOCK CODE	ITEM DESCRIPTION			CURRENT STOCK
RPV-VCK0800600BWXDDBLNKI	3" CL 600 SW CHECK VALVE.	BC. BW 80.	A217 WC6 / F316, HF.	4
RPV-VCK0800600RFCDDBLNPK	3"600 RF SW CHECK VALVE.	BC. ANSI B16.34.	A351 CF8M / F316, HF	1
RPV-VCK0800600RFPDDBLNMA	3"600RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	3
RPV-VCK0800600RFWBBL KI	3"600 RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF	16
RPV-VCK0800600RFWDDBL KI	3"600RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	20
RPV-VCK0800600UMCDDBLNKI	3"600UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	15
RPV-VCK0800600UMDFFBLNPK	3"600UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8 / F304, HF.	4
RPV-VCK0800600UMPDDBL KI	3"600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	18
RPV-VCK0800600UMPDDBLNMA	3"600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	1
RPV-VCK0800600UMQDDBLNKI	3"600UM SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	15
RPV-VCK0800600UMQDDBLNVA	3"600UM SW CHECK VALVE.	BC. ASME B16.10	A217 C5 / F316, HF.	2
RPV-VCK0800600UMTHHBLNKI	3"600UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8C / F321, HF.	6
RPV-VCK0800600UMWBBL KI	3"600UM SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF	30
RPV-VCK0800600UMWDDBL KI	3"600UM SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	18
RPV-VCK0800600UMXDDBLNKI	3"600UM SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	12
RPV-VCK0800600UMXDDBLNMA	3"600UM SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	2
RPV-VCK0800600UMXDDBLNVA	3"600UM SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF	6
RPV-VCK0800900UMCDDBLNKI	3"900UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF	3
RPV-VCK0800900UMNDDBLNPK	3"900UM SW CHECK VALVE.	BC. NDT.	A217 WC9 / F316, HF.	3
RPV-VCK0800900UMPDDBLNKI	3"900UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	20
RPV-VCK0800900UMPDDBLNPK	3"900UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	3
RPV-VCK0800900UMRDBLNPK	3"900UM SW CHECK VALVE.	BC. NDT.	A217 C12 / F316, HF.	3
RPV-VCK0800900UMTYBLNVA	3"900UM SW CHECK VALVE.	BC. BS 1868. NDT	A351 CF8C / F347, HF	3
RPV-VCK0801500BWADPLNBO	3" 1500 SW. CHECK VALVE	PSB, BW 160.	A105N / F316, HF	15
RPV-VCK0801500BWNDDPLNBO	3" 1500 SW. CHECK VALVE	PSB, BW 160.	A182 F22 / F316, HF	2
RPV-VCK0801500UMCDDBLNKI	3"1500UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF	3
RPV-VCK0801500UMNDDBLNPK	3" 1500UM SW CHECK VALVE.	BC. NDT.	A217 WC9 / F316, HF.	3
RPV-VCK0801500UMPDDBLNKI	3" 1500UM SW CHECK VALVE.	BC.BS1868	A352 LCC / F316, HF.	16
RPV-VCK0801500UMRDBLNPK	3" 1500UM SW CHECK VALVE.	BC. NDT.	A217 C12 / F316, HF.	3
RPV-VCK0801500UMTYBLNVA	3"1500UM SW CHECK VALVE.	BC. BS 1868. NDT	A351 CF8C / F347, HF	3
RPV-VCK0802500BWNDDPLNBO	3" CL2500 SW CHECK VALVE.	PSB. BW XXS.	A182 F22 / F316, HF	3
RPV-VCK0802500UMPDDBLNVA	3" 2500 UM PSB SW CHECK VALVE	BS 1868	A352 LCC / F316, HF	4
RPV-VCK1000150FFBBL SH	4" 150 FF SW. CHECK VALVE	BC.	ASTM B148 C95800.	8
RPV-VCK1000150RFCDDBLNPK	4"150RF SW CHECK VALVE.	BC. ANSI B16.34.	A351 CF8M / F316, HFS.	4
RPV-VCK1000150RFCDDBLNKI	4"150RF SW CHECK VALVE.	BC. BS1868.	A351 CF8M / F316, HF.	36
RPV-VCK1000150RFCDDBLNMA	4"150RF SW CHECK VALVE.	BC. BS1868. NOT CE	A351 CF8M / F316, HF.	1
RPV-VCK1000150RFCDDBLNTR	4"150RF SW CHECK VALVE.	BC. BS1868.	A351 CF8M / F316, HF.	4
RPV-VCK1000150RFDFFB NKI	4"150 RF SW CHECK VALVE.	BC. ANSI B16.34	A351 CF8 / F304, HF	8
RPV-VCK1000150RFPDDBLNMA	4"150RF SW CHECK VALVE.	BC. FULL BORE.	A352 LCC / F316, HFS.	10
RPV-VCK1000150RFPDDBL KI	4"150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	37
RPV-VCK1000150RFQDDBLNKI	4"150RF SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	3
RPV-VCK1000150RFQDDBLNMA	4"150RF SW CHECK VALVE.	BC. FULL BORE. BS1868.	A217 C5 / F316, HF.	1
RPV-VCK1000150RFTHHBL*VA	4"150 RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8C / F321, HF.	2
RPV-VCK1000150RFTHHBLNKI	4"150 RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8C / F321, HF.	2
RPV-VCK1000150RFUJBLNKI	4" 150 RF SW. CHECK VALVE	BC. PTFE GASKET	ASTM A351 CD3MWCuN	1
RPV-VCK1000150RFWBBL KI	4"150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	40
RPV-VCK1000150RFWDDBL KI	4"150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	80
RPV-VCK1000300BWWBBLNPK	4" CL 300 SW CHECK VALVE.	BC. BW 80.	A216 WCB / F6, HF.	2
RPV-VCK1000300BWWDDBLNKI	4" CL 300 SW CHECK VALVE.	BC. BW 80	A216 WCB / F316, HF	3
RPV-VCK1000300BWWDDBLNVE	4" CL 300 SW CHECK VALVE.	BC. BW 80	A216 WCB / F316, HF.	3
RPV-VCK1000300HHWCBL HA	4"300 TABLE H SW.CHECK.	BC.	A216 WCB / F316.	3
RPV-VCK1000300RFCCLBLNPK	4"300RF SW CHECK VALVE	BC. ANSI B16.34.	A351 CF8M / F316.	9
RPV-VCK1000300RFCDDBLNKI	4"300RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	5
RPV-VCK1000300RFDFFBLNPK	4"300RF SW CHECK VALVE.	BC. ANSI B16.34.	A351 CF8 / F304, HFS.	2
RPV-VCK1000300RFDFFB NKI	4"300RF SW CHECK VALVE	BC. ANSI B16.34.	A351 CF8 / F304, HF	10
RPV-VCK1000300RFPDDBL KI	4"300RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	36
RPV-VCK1000300RFQDDBLNKI	4"300RF SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	10
RPV-VCK1000300RFTHHBLNKI	4"300RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8C / F321, HF.	11
RPV-VCK1000300RFWABBL HA	4"300RF SW CHECK VALVE.	BC. BS1868.	A216 WCB / F6, HFS.	1
RPV-VCK1000300RFWABBL TR	4"300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HFS.	1
RPV-VCK1000300RFWABBLNPK	4"300UD SW CHECK VALVE.	BC. API600.	A216 WCB / F6, HFS.	1
RPV-VCK1000300RFWBBL KI	4"300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF	21
RPV-VCK1000300RFWBBLNMA	4"300RF SW CHECK VALVE.	BC. BS1868.	A216 WCB / F6, HF.	5
RPV-VCK1000300RFWDDBL KI	4"300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	19
RPV-VCK1000300RFXDDBLNKI	4"300RF SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	8
RPV-VCK1000300UMQDDBLNVA	4" 300 UM SW CHECK VALVE,	BC, NDT	A217 C5 / F316, HF	4
RPV-VCK1000600BWWBBLNPK	4" CL 600 SW CHECK VALVE.	BC. BW 80.	A216 WCB / F6, HF.	2
RPV-VCK1000600BWWDDBLNKI	4" CL 600 SW CHECK VALVE.	BC. BW 80.	A216 WCB / F316, HF.	19
RPV-VCK1000600BWXDDBLNKI	4" CL 600 SW CHECK VALVE.	BC. BW 80.	A217 WC6 / F316, HF	2
RPV-VCK1000600RFWBBL KI	4"600RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	24
RPV-VCK1000600RFWBBL TR	4"600RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	1
RPV-VCK1000600RFWDDBL KI	4"600 RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	10
RPV-VCK1000600RFWDDBLNKI	4"600RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	6
RPV-VCK1000600RFXDDBLNKI	4"600 RF SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	1
RPV-VCK1000600UMCDDBLNKI	4"600UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	7
RPV-VCK1000600UMDFFB NKI	4"600UM SW CHECK VALVE.	BC. B16.34	A351 CF8 / F304, HF	2
RPV-VCK1000600UMDFFBLNPK	4"600UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8 / F304, HF.	2
RPV-VCK1000600UMPDDBL KI	4"600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	17
RPV-VCK1000600UMQDDBLNKI	4"600UM SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF	4
RPV-VCK1000600UMQDDBLNVA	4"600UM SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF	6
RPV-VCK1000600UMTYBLNVA	4" 600 UM SW CHECK VALVE,	BC, NDT	A351 CF8C / NIT 50 / F347, HF	2
RPV-VCK1000600UMWBBL KI	4"600UM SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	9
RPV-VCK1000600UMWBBLNPK	4"600UM SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	4
RPV-VCK1000600UMWDDBLNKI	4"600UM SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	7
RPV-VCK1000600UMXDDBLNKI	4"600UM SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	6
RPV-VCK1000600UMXDDBLNVA	4"600UM SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF	6
RPV-VCK1000900UMCDDBLNKI	4"900UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF	3
RPV-VCK1000900UMNDDBLNPK	4"900UM SW CHECK VALVE.	BC. NDT.	A217 WC9 / F316, HF.	3
RPV-VCK1000900UMPDDBLNKI	4"900UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	9
RPV-VCK1000900UMPDDBLNPK	4"900UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	5
RPV-VCK1000900UMRDBLNPK	4"900UM SW CHECK VALVE.	BC. NDT.	A217 C12 / F316, HF.	2
RPV-VCK1000900UMTYBLNVA	4"900UM SW CHECK VALVE.	BC. BS 1868. NDT	A351 CF8C / F347, HF	3

STOCK CODE	ITEM DESCRIPTION			CURRENT STOCK
RPV-VCK1001500BWADDPLNBO	4" 1500 SW. CHECK VALVE	PSB, BW 160.	A105N / F316, HF	9
RPV-VCK1001500BWNDLPLNBO	4" 1500 SW. CHECK VALVE	PSB, BW 160.	A182 F22 / F316, HF	5
RPV-VCK1001500UMCDDBLNPKI	4"1500UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF	3
RPV-VCK1001500UMNDBLNP	4" 1500UM SW CHECK VALVE.	BC. NDT.	A217 WC9 / F316, HF.	3
RPV-VCK1001500UMPDDBLNKI	4" 1500UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	8
RPV-VCK1001500UMPDDBLNPK	4" 1500UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	3
RPV-VCK1001500UMRDDBLNPK	4" 1500UM SW CHECK VALVE.	BC. NDT.	A217 C12 / F316, HF.	3
RPV-VCK1001500UMTYBBLNVA	4"1500UM SW CHECK VALVE.	BC. BS 1868. NDT	A351 CF8C / F347, HF	3
RPV-VCK1002500BWNBBPL VE	4" CL2500 SW CHECK VALVE.	PSB. BW XXS.	A182 F22 / F6, HF.	2
RPV-VCK1002500UMPDDBLNVA	4" 2500 UM PSB SW CHECK VALVE	BS 1868	A352 LCC / F316, HF	4
RPV-VCK1500150FFBDBBK SH	6" 150 FF SW. CHECK VALVE	BC,	ASTM B148 C95800.	3
RPV-VCK1500150RFCDBLNPK	6"150RF SW CHECK VALVE	BC. ANSI B16.34.	A351 CF8M / F316.	8
RPV-VCK1500150RFCDBLNKI	6"150RF SW CHECK VALVE	BC. BS 1868.	A351 CF8M / F316, HF.	20
RPV-VCK1500150RFDEFBLNPK	6"150RF SW CHECK VALVE.	BC. ANSI B16.34.	A351 CF8 / F304, HFS.	1
RPV-VCK1500150RFDFFB NKI	6"150RF SW CHECK VALVE	BC. B16.34	A351 CF8 / F304, HF	4
RPV-VCK1500150RFPDDBLNMA	6"150RF SW CHECK VALVE.	BC. FULL BORE.	A352 LCC / F316, HFS.	7
RPV-VCK1500150RFPDDBL KI	6"150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	12
RPV-VCK1500150RFPDDBLNKI	6"150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	3
RPV-VCK1500150RFPDDBLNMA	6"150RF SW CHECK VALVE.	BC. FULL BORE.	A352 LCC / F316, HF.	7
RPV-VCK1500150RFQDDBLNKI	6"150RF SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	6
RPV-VCK1500150RFWABBL TR	6"150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HFS.	1
RPV-VCK1500150RFWBBBL KI	6"150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	23
RPV-VCK1500150RFWDBL KI	6"150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	62
RPV-VCK1500300BWWDBLNKI	6"CL 300 SW CHECK VALVE.	BC. BS 1868. BW 80 ENDS	A216 WCB / F316, HF	10
RPV-VCK1500300RFCDBLNKI	6"300RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	10
RPV-VCK1500300RFDEFBLNPK	6"300RF SW CHECK VALVE.	BC. ANSI B16.34.	A351 CF8 / F304, HFS.	2
RPV-VCK1500300RFPDDBL KI	6"300RF SW CHECK VALVE	BC. BS 1868.	A352 LCC / F316, HF	14
RPV-VCK1500300RFPDDBLNKI	6"300RF SW CHECK VALVE	BC. BS 1868.	A352 LCC / F316, HF.	1
RPV-VCK1500300RFQDDBLNKI	6"300RF SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	10
RPV-VCK1500300RFRHHBLNKI	6"300RF SW CHECK VALVE.	BC. BS 1868.	A217 C12 / F321, HF	5
RPV-VCK1500300RFTHHBLNKI	6"300RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8C / F321, HF.	6
RPV-VCK1500300RFWBBBL KI	6"300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	16
RPV-VCK1500300RFWDBL KI	6"300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	29
RPV-VCK1500300RFXDBLNKI	6"300RF SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	7
RPV-VCK1500300RFXDDBLNMA	6"300RF SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	2
RPV-VCK1500300RFZZBLNKI	6"300RF SW CHECK VALVE.	BC. BS 1868.	A351 CF3M / F316L, HF.	3
RPV-VCK1500300UMQDDBLNVA	6" 300 UM SW CHECK VALVE,	BC, NDT	A217 C5 / F316, HF	3
RPV-VCK1500600BWWDBLNKI	6" CL 600 SW CHECK VALVE.	BC. BW 80.	A216 WCB / F316, HF.	4
RPV-VCK1500600BWDBLNKI	6" CL 600 SW CHECK VALVE.	BC. BW 80.	A217 WC6 / F316, HF	5
RPV-VCK1500600RFWBBBL KI	6"600RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	15
RPV-VCK1500600RFWDBL KI	6"600RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	8
RPV-VCK1500600UMCDBLNKI	6"600UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	7
RPV-VCK1500600UMCDBLNPK	6"600UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	1
RPV-VCK1500600UMPDDBL KI	6"600UM SW CHECK VALVE	BC. BS 1868.	A352 LCC / F316, HF	16
RPV-VCK1500600UMQDDBLNKI	6"600UM SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	6
RPV-VCK1500600UMQDDBLNVA	6"600UM SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF	10
RPV-VCK1500600UMTYBBLNVA	6" 600 UM SW CHECK VALVE,	BC, NDT	A351 CF8C / F347, HF	2
RPV-VCK1500600UMWBBBL KI	6"600UM SW CHECK VALVE.	BC. BS 1868	A216 WCB / F6, HF.	11
RPV-VCK1500600UMWDBL KI	6"600UM SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	20
RPV-VCK1500600UMXDBLNKI	6"600UM SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	2
RPV-VCK1500900UMNDBLNPK	6"900UM SW CHECK VALVE.	BC. NDT.	A217 WC9 / F316, HF.	3
RPV-VCK1500900UMPDDBLNKI	6"900UM SW CHECK VALVE.	BC. BS 1868	A352 LCC / F316, HF	14
RPV-VCK1500900UMRDDBLNVA	6"900UM SW CHECK VALVE.	BC. API 600. NDT	A217 C12 / F316, HF	3
RPV-VCK1501500BWADDPLNBO	6" CL1500 SW CHECK VALVE.	PSB. BW 160	A105N / F316, HF.	2
RPV-VCK1501500BWNDLPLNBO	6" CL1500 SW CHECK VALVE.	PSB. BW 160	F22 / F316, HF.	10
RPV-VCK1501500UMNDBLNP	6" 1500UM SW CHECK VALVE.	BC. NDT.	A217 WC9 / F316, HF.	3
RPV-VCK1501500UMPDDBLNKI	6" 1500UM SW CHECK VALVE.	BC. BS 1868	A352 LCC / F316, HF	4
RPV-VCK1501500UMRDDBLNPK	6" 1500UM SW CHECK VALVE.	BC. NDT.	A217 C12 / F316, HF.	1
RPV-VCK1502500BWF91PLNBO	6" CL 2500 PSB SW. CHECK VALVE	FB, BW XXS	A182 F91 / F316, HF	2
RPV-VCK1502500UMPDDBLPC*VA	6" 2500 UM SW CHECK VALVE,	PSB, NDT	A352 LCC / F316, HF	2
RPV-VCK2000150BWWDBLNKI	8"CL 150 SW CHECK VALVE.	BC. BS 1868. BW SCH 80	A216 WCB / F316, HF	4
RPV-VCK2000150RFCDBD NKI	8"150RF SW CHECK VALVE.	BC. ANSI B16.34	A351 CF8M / F316, HF	13
RPV-VCK2000150RFCDBLNKI	8"150RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	14
RPV-VCK2000150RFDFFB NKI	8"150RF SW CHECK VALVE.	BC. ANSI B16.34	A351 CF8 / F304, HF	8
RPV-VCK2000150RFPDDBLNKI	8"150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	8
RPV-VCK2000150RFQDDBLNKI	8"150RF SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	3
RPV-VCK2000150RFQDDBLNMA	8"150RF SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	1
RPV-VCK2000150RFWBBBL KI	8"150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF	35
RPV-VCK2000150RFWDBL KI	8"150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	20
RPV-VCK2000150RFWDBLNKI	8"150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	1
RPV-VCK2000300BWWDBLNKI	8" CL 300 SW CHECK VALVE.	BC. BW 80.	A216 WCB / F316, HF.	3
RPV-VCK2000300RFCDBLNPK	8"300RF SW CHECK VALVE.	BC. ANSI B16.34.	A351 CF8M / F316, HFS.	1
RPV-VCK2000300RFCDBD NKI	8"300 RF SW CHECK VALVE.	BC. ANSI B16.34	A351 CF8M / F316, HF	5
RPV-VCK2000300RFCDBLNKI	8"300RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	10
RPV-VCK2000300RFDEFBLNPK	8"300RF SW CHECK VALVE.	BC. ANSI B16.34.	A351 CF8 / F304, HFS.	1
RPV-VCK2000300RFPDDBL KI	8"300RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	10
RPV-VCK2000300RFPDDBLNKI	8"300RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	2
RPV-VCK2000300RFQDDBLNKI	8"300RF SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	13
RPV-VCK2000300RFWABBL TR	8"300RF SW CHECK VALVE	BC. BS 1868	A216 WCB / F6, HFS.	1
RPV-VCK2000300RFWBBBL KI	8"300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF	12
RPV-VCK2000300RFWDBL KI	8"300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	25
RPV-VCK2000300RFXDBLNKI	8"300RF SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF	7
RPV-VCK2000300RFXDDBLNMA	8"300RF SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF	1
RPV-VCK2000600BWWDBLNKI	8" CL 600 SW CHECK VALVE.	BC. BW 80.	A216 WCB / F316, HF.	4
RPV-VCK2000600RFWBBBLNKI	8"600RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	1
RPV-VCK2000600RFWDBLNKI	8"600RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	2
RPV-VCK2000600UMPDDBL KI	8"600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	10
RPV-VCK2000600UMPDDBLNKI	8"600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	3
RPV-VCK2000600UMPDDBLNNE	8"600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	4
RPV-VCK2000600UMQDDBLNKI	8"600UM SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	4
RPV-VCK2000600UMQDDBLNVA	8"600UM SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF	2
RPV-VCK2000600UMTHHBLNKI	8"600UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8C / F321, HF	4

STOCK CODE	ITEM DESCRIPTION			CURRENT STOCK
RPV-VCK2000600UMWBBLNKI	8"600UM SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	5
RPV-VCK2000600UMWDBLTKI	8"600UM SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	9
RPV-VCK2000600UMWDBLNNE	8"600UM SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	5
RPV-VCK2000600UMXDBLTKI	8"600UM SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	6
RPV-VCK2000900UMNDBLNPK	8"900UM SW CHECK VALVE.	BC. NDT.	A217 WC9 / F316, HF.	1
RPV-VCK2000900UMPDDBLNKI	8"900UM SW CHECK VALVE.	BC.	A352 LCC / F316, HF.	2
RPV-VCK2000900UMPDDBLNVA	8"900UM SW CHECK VALVE.	BC.	A352 LCC / F316, HF.	4
RPV-VCK2000900UMRDBLNPK	8"900UM SW CHECK VALVE.	BC. NDT.	A217 C12 / F316, HF.	2
RPV-VCK2001500BWADDPLNVE	8" CL 1500 PSB SW. CHECK	VALVE. FB. BW SCH 160	A105N / F316, HF.	2
RPV-VCK2001500BWNDPCNBO	8" CL 1500 PSB SW. CHECK	VALVE. FB. BW SCH 160	A182 F22 / F316, HF.	3
RPV-VCK2001500UMNDBLNNE	8" 1500UM SW CHECK VALVE.	BC.	A217 WC9 / F316, HF.	1
RPV-VCK2001500UMPDDBLNVA	8" 1500UM SW CHECK VALVE.	BC.	A352 LCC / F316, HF.	2
RPV-VCK2001500UMRDBLNNE	8" 1500UM SW CHECK VALVE.	BC.	A217 C12 / F316, HF.	1
RPV-VCK2001500UMRDBLNPK	8" 1500UM SW CHECK VALVE.	BC. NDT.	A217 C12 / F316, HF.	1
RPV-VCK2002500BWF91PLNBO	8" CL 2500 PSB SW. CHECK VALVE	FB, BW XXS	A182 F91 / F316, HF.	4
RPV-VCK25001500RFCDBLNPK	10"150RF SW CHECK VALVE.	BC.	A351 CF8M / F316, HFS	1
RPV-VCK25001500RFCDBD NKI	10"150RF SW CHECK VALVE.	BC. ANSI B16.34	A351 CF8M / F316, HF.	7
RPV-VCK25001500RFPDDBL KI	10"150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	1
RPV-VCK25001500RFPDDBLNKI	10"150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	5
RPV-VCK25001500RFQDDBLNKI	10"150RF SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	3
RPV-VCK25001500RFWBBL KI	10"150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	8
RPV-VCK25001500RFWDBL KI	10"150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	12
RPV-VCK2500300RFCDBLNKI	10"300RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	4
RPV-VCK2500300RFPDDBLNKI	10"300RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	5
RPV-VCK2500300RFPDDBLNPK	10"300RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	1
RPV-VCK2500300RFQDDBLNKI	10"300RF SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	5
RPV-VCK2500300RFTHHBLNKI	10"300RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8C / F321, HF.	4
RPV-VCK2500300RFWABBL HA	10"300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HFS.	3
RPV-VCK2500300RFWABBL VE	10"300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HFS.	3
RPV-VCK2500300RFWBBL KI	10"300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	14
RPV-VCK2500300RFWDBL KI	10"300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	13
RPV-VCK2500300RFXDBLNKI	10"300RF SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	3
RPV-VCK2500600UMPDDBLNKI	10"600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	8
RPV-VCK2500600UMQDDBLNKI	10"600UM SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	5
RPV-VCK2500900UMNDBLNNE	10"900UM SW CHECK VALVE.	BC.	A217 WC9 / F316, HF.	1
RPV-VCK2500900UMPDDBLNVA	10"900UM SW CHECK VALVE.	BC.	A352 LCC / F316, HF.	2
RPV-VCK2500900UMRDBLNNE	10"900UM SW CHECK VALVE.	BC.	A217 C12 / F316, HF.	1
RPV-VCK2500900UMRDBLNPK	10"900UM SW CHECK VALVE.	BC.	A217 C12 / F316, HF.	1
RPV-VCK2501500BWADDPLNBO	10" CL1500 SW CHECK VALVE.	PSB. BW 160	A105N / F316, HF.	5
RPV-VCK2501500BWNDPCNBO	10" CL 1500 PSB SW. CHECK	VALVE. FB. BW SCH 160	A182 F22 / F316, HF.	3
RPV-VCK2501500UMNDBLNNE	10" 1500UM SW CHECK VALVE.	BC.	A217 WC9 / F316, HF.	1
RPV-VCK2501500UMPDDBLNNE	10" 1500UM SW CHECK VALVE.	BC.	A352 LCC / F316, HF.	2
RPV-VCK2501500UMPDDBLNPK	10" 1500UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	3
RPV-VCK2501500UMRDBLNPK	10" 1500UM SW CHECK VALVE.	BC.	A217 C12 / F316, HF.	2
RPV-VCK30001500RFCDBD NKI	12"150RF SW CHECK VALVE.	BC. ANSI B16.34	A351 CF8M / F316, HF.	5
RPV-VCK30001500RFPDDBLNKI	12"150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	9
RPV-VCK30001500RFPDDBLNNE	12"150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	3
RPV-VCK30001500RFPDDBLNPK	12"150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	3
RPV-VCK30001500RFWDBLTKI	12"150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	9
RPV-VCK30001500RFWDBLNPK	12"150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	5
RPV-VCK30001500RFWDBLNVE	12"150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	3
RPV-VCK3000300RFPCCBLNKI	12"300RF SW CHECK VALVE.	BC.	A352 LCC / F316.	1
RPV-VCK3000300RFPDDBLNKI	12"300RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	3
RPV-VCK3000300RFQDDBLNKI	12"300RF SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	4
RPV-VCK3000300RFWABBL HA	12"300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HFS.	3
RPV-VCK3000300RFWABBL VE	12"300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HFS.	2
RPV-VCK3000300RFWBBLNKI	12"300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	2
RPV-VCK3000300RFWCCBL PK	12"300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316.	2
RPV-VCK3000300RFWDBLTKI	12"300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	14
RPV-VCK3000300RFXDBLNKI	12"300RF SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	2
RPV-VCK3000600UMPDDBLNKI	12"600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	7
RPV-VCK3000900UMPDDBLNVA	12"900UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	1
RPV-VCK3001500BWADDPLNVE	12" CL 1500 PSB SW. CHECK	VALVE. FB. BW SCH 160	A105N / F316, HF.	2
RPV-VCK3001500UMPDDBLNPK	12" 1500UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	1
RPV-VCK35001500RFPDDBLNKI	14"150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	3
RPV-VCK35001500RFWBBLNKI	14"150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	1
RPV-VCK35001500RFWDBLTKI	14"150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	9
RPV-VCK3500300RFPDDBLNVE	14"300RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	3
RPV-VCK3500300RFQDDBLNKI	14"300RF SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	2
RPV-VCK3500600UMPDDBLNKI	14"600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	1
RPV-VCK40001500RFPDDBLNKI	16"150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	5
RPV-VCK40001500RFWABBL VA	16"150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HFS.	1
RPV-VCK40001500RFWDBLTKI	16"150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	8
RPV-VCK40001500RFWDBLNPK	16"150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	2
RPV-VCK4000300RFPDDBLNKI	16"300RF SW CHECK VALVE.	BC. BS 1868. ES 311.	A352 LCC / F316, HF.	3
RPV-VCK4000300RFWDBLTKI	16"300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	5
RPV-VCK4000600UMPDDBLNKI	16"600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	2
RPV-VCK4000600UMPDDBLNPK	16"600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	1
RPV-VCK4000600UMPDDBLNVE	16"600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	2
RPV-VCK45001500RFPDDBLNKI	18"150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	2
RPV-VCK45001500RFWDBDNNE	18"150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	2
RPV-VCK45001500RFWDBLTKI	18"150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	3
RPV-VCK4500300RFPDDBLNKI	18"300 RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	4
RPV-VCK4500300RFPDDBLNVE	18"300RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	2
RPV-VCK4500300RFWDBLTKI	18"300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	4
RPV-VCK4500300RFWDBLNVE	18"300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	2
RPV-VCK4500600UMPDDBLNNE	18"600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	2
RPV-VCK50001500RFPDDBLNKI	20"150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	3
RPV-VCK5000300RFPDDBLNKI	20"300RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	3
RPV-VCK5000300RFWDBLTKI	20"300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	2
RPV-VCK5000600UMPDDBLNNE	20"600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	2
RPV-VCK60001500RFPDDBLNVE	24"150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	4

STOCK CODE	ITEM DESCRIPTION			CURRENT STOCK
RPV-VCK6000150RFWDDBLNKI	24"150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	2
RPV-VCK6000150RFWDDBLNVE	24"150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	5
RPV-VCK6000300RFPDDBLNKI	24"300RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	2

CHECK VALVES