

CHECK VALVES



Code	Item Description			Current Stock
RPV-VCK0080800NPADDBJNBO	1/4" CL 800 FB P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F316, HF.	31
RPV-VCK0080800NPHDDBJ*BO	1/4" CL 800 FB P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F316(L) / F316, HF.	19
RPV-VCK0150150FFBDBBI SH	1/2" 150 FF PISTON CHECK VALVE.	BOLTED COVER	ASTM B148 C95800	16
RPV-VCK0150150FFBDBBK SH	1/2" 150 FF SW. CHECK VALVE.	BOLTED COVER	ASTM B148 C95800	10
RPV-VCK0150150RFAABBINBO	1/2" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F6, HFS.	28
RPV-VCK0150150RFABBBINBO	1/2" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F6, HF.	27
RPV-VCK0150150RFADDBINBO	1/2" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF.	68
RPV-VCK0150150RFADDBKNBO	1/2" 150RF SW CHECK VALVE.	BC.	A105N / F316, HF	21
RPV-VCK0150150RFADDWINBO	1/2" 150RF P CHECK VALVE. WC	SPRING ASSIST. HIGH LIFTING	A105N / F316, HF.	20
RPV-VCK0150150RFCDDBLNKI	1/2" 150RF SW CHECK VALVE.	BC.	A351 CF8M / F316, HF.	16
RPV-VCK0150150RFEDDBINBO	1/2" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F5 / F316, HF.	25
RPV-VCK0150150RFFDDBINBO	1/2" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F9 / F316, HF.	15
RPV-VCK0150150RFGDDBINBO	1/2" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F11 / F316, HF.	8
RPV-VCK0150150RFHDDBINBO	1/2" 150RF P CHECK VALVE.	BC. SPRING ASSISTED	A182 F316(L) / F316, HF	112
RPV-VCK0150150RFHDDBKNO	1/2" 150RF SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	54
RPV-VCK0150150RFLCDBINBO	1/2" 150RF P CHECK VALVE	BC.	A350 LF2N / F316, HFS.	9
RPV-VCK0150150RFLDDBINBO	1/2" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A350 LF2N / F316, HF.	72
RPV-VCK0150150RFLDDBKNO	1/2" 150RF SW. CHECK VALVE.	BC.	A350 LF2N / F316, HF	17
RPV-VCK0150150RFSHHBINBO	1/2" 150RF P CHECK VALVE	BC. SPRING ASSISTED.	A182 F321(H) / F321, HF	27
RPV-VCK0150150RFTTBKNBO	1/2" 150RF SW CHECK VALVE.	BC.	TITANIUM B381 F2 / B348 GR2/5	2
RPV-VCK0150150RFVVBINBO	1/2" 150 RF P. CHECK VALVE,	BB, SPRING ASSIST.	A182 F55 / UNS S32760, HF	15
RPV-VCK0150300RFAABBINBO	1/2" 300RF P CHECK VALVE.	BC.	A105N / F6, HFS.	4
RPV-VCK0150300RFAABKNBO	1/2" 300RF SW CHECK VALVE.	BC.	A105N / F6, HFS.	3
RPV-VCK0150300RFABBBINBO	1/2" 300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F6, HF.	18
RPV-VCK0150300RFABBBKNBO	1/2" 300RF SW CHECK VALVE.	BC.	A105N / F6, HF.	7
RPV-VCK0150300RFADDBINBO	1/2" 300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF.	52
RPV-VCK0150300RFADDBKNBO	1/2" 300RF SW CHECK VALVE.	BC.	A105N / F316, HF	15
RPV-VCK0150300RFCDDBLNKI	1/2" 300RF SW CHECK VALVE.	BC. ANSI B16.34,	A351 CF8M / F316, HF.	4
RPV-VCK0150300RFEDDBINBO	1/2" 300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F5 / F316, HF.	5
RPV-VCK0150300RFFDDBINBO	1/2" 300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F9 / F316, HF.	5
RPV-VCK0150300RFGDDBINBO	1/2" 300RF P CHECK VALVE.	BC. SPRING ASSISTED	A182 F11 / F316, HF.	25
RPV-VCK0150300RFHDDBI*BO	1/2" 300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F316(L) / F316, HF	50
RPV-VCK0150300RFHDDBINBO	1/2" 300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F316(L) / F316, HF	71
RPV-VCK0150300RFHDDBK*BO	1/2" 300RF SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	40
RPV-VCK0150300RFHDDBKNO	1/2" 300RF SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	20
RPV-VCK0150300RFLCDBINBO	1/2" 300RF P CHECK VALVE	BC	A350 LF2N / F316, HFS.	4
RPV-VCK0150300RFLDDBINBO	1/2" 300RF P CHECK VALVE.	BC.	A350 LF2N / F316, HF.	39
RPV-VCK0150300RFLDDBKNO	1/2" 300RF SW. CHECK VALVE.	BC.	A350 LF2N / F316, HF	9
RPV-VCK0150300RFSHHBINBO	1/2" 300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F321(H) / F321, HF	12
RPV-VCK0150300UMADDWINBO	1/2" 300 UM P CHECK VALVE. WC.	SPRING ASSIST. HIGH LIFTING	A105N / F316, HF.	18
RPV-VCK0150300UMCDDBLNKI	1/2" 300UM SW CHECK VALVE.	BC. ANSI B16.34,	A351 CF8M / F316, HF.	5
RPV-VCK0150300UMSHHBINBO	1/2" 300 UM P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F321(H) / F321, HF	25
RPV-VCK0150300UMVVVBINBO	1/2" 300 UM P. CHECK VALVE,	BB, SPRING ASSIST.	A182 F55 / UNS S32760, HF	15
RPV-VCK0150600BWADDWYNBO	1/2" CL 600 Y-PATT. P. CHECK VALVE.	WC. BW80. SPRING ASSIST	A105N / F316, HF	9
RPV-VCK0150600RFADDBINBO	1/2" 600RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF.	21
RPV-VCK0150600RFLDDBINBO	1/2" 600 RF P CHECK VALVE	BC. SPRING ASSISTED	A350 LF2N / F316, HF	8
RPV-VCK0150600UMADDBINBO	1/2" 600UM P. CHECK VALVE.	BC. SPRING ASSISTED	A105N / F316, HF	35
RPV-VCK0150600UMADDBKNBO	1/2" 600UM SW CHECK VALVE.	BC.	A105N / F316, HF.	73
RPV-VCK0150600UMCDDBLNKI	1/2" 600UM SW CHECK VALVE.	BC. ANSI B16.34,	A351 CF8M / F316, HF.	10

GATE VALVES

GLOBE VALVES

CHECK VALVES

WAFER CHECK VALVES

BALL VALVES

BUTTERFLY VALVES

Code	Item Description			Current Stock
RPV-VCK0150600UMEDDBINBO	1/2" 600UM P CHECK VALVE.	BC. SPRING ASSISTED	A182 F5 / F316, HF.	15
RPV-VCK0150600UMFDDBINBO	1/2" 600UM P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F9 / F316, HF.	3
RPV-VCK0150600UMGDDBINBO	1/2" 600UM P CHECK VALVE.	BC. SPRING ASSISTED	A182 F11 / F316, HF.	7
RPV-VCK0150600UMHDDBI*BO	1/2" 600UM SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	149
RPV-VCK0150600UMHDDBKINBO	1/2" 600UM SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	45
RPV-VCK0150600UMIDDBINBO	1/2" 600UM P CHECK VALVE.	BC.	A182 F316(L) / F316, HF.	111
RPV-VCK0150600UMJFFBKINBO	1/2" 600UM SW CHECK VALVE.	BC.	A182 F304(L) / F304, HF	12
RPV-VCK0150600UMLDDBINBO	1/2" 600UM P CHECK VALVE	BC. SPRING ASSISTED	A350 LF2N / F316, HF.	31
RPV-VCK0150600UMLDDBKINBO	1/2" 600UM SW CHECK VALVE	BC.	A350 LF2N / F316, HF.	35
RPV-VCK0150600UMSHHINBO	1/2" 600UM P CHECK VALVE	BC. SPRING ASSISTED	A182 F321(H) / F321, HF	18
RPV-VCK0150600UMVVBINBO	1/2" 600 UM P. CHECK VALVE,	BB, SPRING ASSIST.	A182 F55 / UNS S32760, HF	15
RPV-VCK0150800BWABBBKINBO	1/2" CL 800 SW CHECK VALVE.	BC. BW80.	A105N / F6, HF.	50
RPV-VCK0150800BWADDBINBO	1/2" CL 800 P. CHECK VALVE.	BC. BW80. SPRING ASSIST	A105N / F316, HF	46
RPV-VCK0150800BWADDBKINBO	1/2" CL 800 SW CHECK VALVE.	BC. BW80. SPRING ASSIST	A105N / F316, HF	48
RPV-VCK0150800BWEDDBINBO	1/2" CL 800 P. CHECK VALVE.	BC. BW80. SPRING ASSIST	A182 F5 / F316, HF	20
RPV-VCK0150800BWHDDBI*BO	1/2" CL 800 P. CHECK VALVE.	BC. BW80. SPRING ASSIST	A182 F316(L) / F316, HF	44
RPV-VCK0150800BWHDDBINBO	1/2" CL 800 P. CHECK VALVE.	BC. BW80. SPRING ASSIST	A182 F316(L) / F316, HF	23
RPV-VCK0150800NPAAABI BO	1/2" CL 800 P CHECK VALVE.	BC. NPTF.	A105N / F6.	7
RPV-VCK0150800NPAABBINBO	1/2" CL 800 P CHECK VALVE.	BC. NPTF.	A105N / F6, HFS.	101
RPV-VCK0150800NPABBBINBO	1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F6, HF.	343
RPV-VCK0150800NPABBBKINBO	1/2" CL 800 SW CHECK VALVE.	BC. NPTF.	A105N / F6, HF.	43
RPV-VCK0150800NPABBBWINBO	1/2" CL 800 P CHECK VALVE.	WC. NPTF. SPRING ASSIST	A105N / F6, HF.	36
RPV-VCK0150800NPACDBMINBO	1/2" CL 800 BALL CHECK VALVE	BC. NPTF.	A105N / F316 / F316 HFS	108
RPV-VCK0150800NPADDBINBO	1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F316, HF.	134
RPV-VCK0150800NPADDBKINBO	1/2" CL 800 SW CHECK VALVE.	BC. NPTF.	A105N / F316, HF.	10
RPV-VCK0150800NPEDDBINBO	1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F5 / F316, HF	18
RPV-VCK0150800NPFBBBINBO	1/2" CL 800 P CHECK VALVE.	BC. NPTF.	A182 F9 / F6, HF.	4
RPV-VCK0150800NPFDDBINBO	1/2" CL 800 P CHECK VALVE.	BC. NPTF.	A182 F9 / F316, HF	19
RPV-VCK0150800NPGBBBINBO	1/2" CL 800 P CHECK VALVE.	BC. NPTF.	A182 F11 / F6, HF.	9
RPV-VCK0150800NPGDDBINBO	1/2" CL 800 P CHECK VALVE.	BC. NPTF	A182 F11 / F316, HF	10
RPV-VCK0150800NPHDDBI*BO	1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F316L / F316, HF.	394
RPV-VCK0150800NPHDDBINBO	1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F316L / F316, HF.	9
RPV-VCK0150800NPHDDBK*BO	1/2" CL 800 SW CHECK VALVE.	BC. NPTF.	A182 F316L / F316, HF.	163
RPV-VCK0150800NPJFFBINBO	1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F304(L) / F304, HF	130
RPV-VCK0150800NPLDDBINBO	1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A350 LF2N / F316, HF.	107
RPV-VCK0150800NPSHHINBO	1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F321-H / F321, HF.	29
RPV-VCK0150800PLA20BLNBO	1/2" CL 800 FB SW. CHECK VALVE.	BC. PLAIN END,	ALLOY 20 / ALLOY 20, HF	5
RPV-VCK0150800PLLDDBKINBO	1/2" CL 800 SW. CHECK VALVE.	BC. PLAIN END (SCH 160 FB)	A350 LF2N / F316, HF.	18
RPV-VCK0150800PLMLLBINBO	1/2" CL 800 P.CHECK VALVE.	BC. SPRING ASSIST. PLAIN END	MONEL 400 / MONEL 400	2
RPV-VCK0150800PLVVVINBO	1/2" CL 800 P. CHECK VALVE.	BC. PLAIN END (SCH 160 FB)	A182 F55 / UNS S32760, HF	5
RPV-VCK0150800PLVVVKINBO	1/2" CL 800 SW. CHECK VALVE.	BC. PLAIN END (SCH 160 FB)	A182 F55 / UNS S32760, HF	5
RPV-VCK0150800SWAABBINBO	1/2" CL 800 P CHECK VALVE.	BC. S/WELD.	A105N / F6, HFS.	94
RPV-VCK0150800SWABBBINBO	1/2" CL 800 P CHECK VALVE.	BC. S/WELD. SPRING ASS.	A105N / F6, HF.	217
RPV-VCK0150800SWACDBMINBO	1/2" CL 800 BALL CHECK VALVE	BC. S/WELD	A105N / F316 / F316 HFS	25
RPV-VCK0150800SWADDBINBO	1/2" CL 800 P CHECK VALVE.	BC. S/WELD. SPRING ASSIST	A105N / F316, HF.	16
RPV-VCK0150800SWHDDBI*BO	1/2" CL 800 P CHECK VALVE.	BC. S/WELD. SPRING ASSIST	A182 F316L / F316, HF.	49
RPV-VCK0151500BWADDBINBO	1/2" CL1500 P CHECK VALVE.	BC. BW160. SPRING ASSIST	A105N / F316, HF	14
RPV-VCK0151500NPADDBINBO	1/2" CL1500 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F316, HF.	173
RPV-VCK0151500NPHDDBI*BO	1/2" CL1500 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F316L / F316, HF.	60
RPV-VCK0151500NPHDDBINBO	1/2" CL1500 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F316L / F316, HF.	60
RPV-VCK0151500NPLDDBINBO	1/2" CL1500 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A350 LF2N / F316, HF.	49
RPV-VCK0151500PLADDBKINBO	1/2" CL1500 SW. CHECK VALVE.	BC. PLAIN END	A105N / F316, HF.	5

GATE VALVES

GLOBE VALVES

CHECK VALVES

WAFER CHECK VALVES

BALL VALVES

BUTTERFLY VALVES

Code	Item Description			Current Stock
RPV-VCK0151500PLHDDBI*BO	1/2" CL1500 P CHECK VALVE.	BC. PLAIN. SPRING ASSIST	A182 F316L / F316, HF.	25
RPV-VCK0151500PLHDDBINBO	1/2" CL1500 P CHECK VALVE.	BC. PLAIN END. SPRING ASSIST.	A182 F316L / F316, HF.	10
RPV-VCK0151500PLHDDBLNBO	1/2" CL1500 FB SW. CHECK VALVE.	BC, FULL BORE, PLAIN END	A182 F316(L) / F316, HF.	19
RPV-VCK0151500PLDDBINBO	1/2" CL1500 P CHECK VALVE. BC	SPRING ASSIST. PLAIN END	A350 LF2N / F316, HF.	10
RPV-VCK0151500PLDDBLNBO	1/2" CL1500 FB SW. CHECK VALVE.	BC, FULL BORE, PLAIN END	A350 LF2N / F316, HF.	10
RPV-VCK0151500PLVVBINBO	1/2" CL1500 P.CHECK VALVE,	BC, PLAIN END SPRING ASS.	A182 F55 / F55, HF	7
RPV-VCK0151500UMADDBJNBO	1/2" 1500UM P CHECK VALVE.	BC. FB. SPRING ASSISTED	A105N / F316, HF.	63
RPV-VCK0151500UMIDDBJ*BO	1/2" 1500UM P CHECK VALVE.	BC. FULL BORE. SPRING.	A182 F316L / F316, HF.	60
RPV-VCK0151500UMIDDBJNBO	1/2" 1500UM P CHECK VALVE.	BC. FULL BORE. SPRING.	A182 F316L / F316, HF.	3
RPV-VCK0151500UMIDDBL*BO	1/2" 1500UM SW. CHECK VALVE.	BC. FULL BORE.	A182 F316L / F316, HF.	13
RPV-VCK0151500UMLDDBJNBO	1/2" 1500UM P CHECK VALVE.	BC. FULL BORE. SPRING	A350 LF2N / F316, HF.	36
RPV-VCK0151500UMLDDBLNBO	1/2" 1500 UM SW. CHECK VALVE.	BC. FULL BORE.	A350 LF2N / F316, HF.	18
RPV-VCK0152500NPIDDBINBO	1/2" CL 2500 P. CHECK VALVE	BC, NPTF. SPRING ASSIST	A182 F316(L) / F316, HF	31
RPV-VCK0152500NPLDDBINBO	1/2" CL 2500 P. CHECK VALVE,	BC, NPTF. SPRING ASSIST	A350 LF2N / F316, HF	24
RPV-VCK0152500PLHDDBI*BO	1/2" CL 2500 FB P CHECK VALVE	BC. SPRING ASSIST. PLAIN END	A182 F316-L / F316, HF	19
RPV-VCK0152500PLHDDBJNBO	1/2" CL 2500 FB P CHECK VALVE	BC. SPRING ASSIST. PLAIN END	A182 F316-L / F316, HF	20
RPV-VCK0152500PLHDDBLNBO	1/2" CL 2500 FB SW. CHECK VALVE,	BC, PLAIN END	A182 F316(L) / F316, HF	10
RPV-VCK0152500PLDDBINBO	1/2" CL 2500 P. CHECK VALVE,	BC, PLAIN END. SPRING ASS.	A350 LF2N / F316, HF	17
RPV-VCK0152500PLDDBLNBO	1/2" CL 2500 FB SW. CHECK VALVE,	BC, PLAIN END. SPRING ASS.	A350 LF2N / F316, HF	4
RPV-VCK0152500UMIDDBJ*BO	1/2" 2500UM FB P CHECK VALVE	BC. SPRING ASSISTED.	A182 F316-L / F316, HF	50
RPV-VCK0152500UMIDDBJNBO	1/2" 2500UM FB P CHECK VALVE	BC. SPRING ASSISTED.	A182 F316-L / F316, HF	9
RPV-VCK0152500UMIDDBLNBO	1/2" 2500UM FB SW. CHECK VALVE	BC.	A182 F316-L / F316, HF	10
RPV-VCK0152500UMLDDBJNBO	1/2" 2500UM FB P CHECK VALVE	BC. SPRING ASSISTED.	A350 LF2N / F316(L), HF	9
RPV-VCK0152500UMVVBJNBO	1/2" 2500 UM FB P CHECK VALVE	BC. SPRING ASSISTED.	A182 F55 / UNS S32760, HF	4
RPV-VCK015PN32NPBBBK SH	1/2" PN32 SW. CHECK VALVE.	NPTF. UB	ASTM B148 C95800	10
RPV-VCK015PN32NPBBBUI SH	1/2" PN32 P CHECK VALVE, UB.	NPTF.	ALI BRONZE B148 C95800	20
RPV-VCK0200150FFBBBBI SH	3/4" 150 FF PISTON CHECK VALVE.	BOLTED COVER	ASTM B148 C95800	9
RPV-VCK0200150FFBBBBK SH	3/4" 150 FF SW. CHECK VALVE.	BOLTED COVER	ASTM B148 C95800	10
RPV-VCK0200150RF276BINBO	3/4" 150 RF P. CHECK VALVE.	BC. REDUCED BORE	HAS C276 / HAS C276, HF	4
RPV-VCK0200150RF276BLNBO	3/4" 150RF FB SW CHECK VALVE.	BC. FULL BORE.	A494 CW12MW / HAS C276, HF	5
RPV-VCK0200150RFA20BINBO	3/4" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	ALLOY 20 / ALLOY 20, HF	2
RPV-VCK0200150RFABBKNBO	3/4" 150RF SW CHECK VALVE.	BC.	A105N / F6, HF.	3
RPV-VCK0200150RFACDBMNBO	3/4" 150RF BALL CHECK VALVE.	BC.	A105N / F316, HFS	8
RPV-VCK0200150RFADDBINBO	3/4" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF.	249
RPV-VCK0200150RFADDBKNBO	3/4" 150RF SW CHECK VALVE.	BC.	A105N / F316, HF	21
RPV-VCK0200150RFADDBWINBO	3/4" 150RF P CHECK VALVE. WC	SPRING ASSIST. HIGH LIFTING	A105N / F316, HF.	29
RPV-VCK0200150RFCCBL PK	3/4" 150RF SW CHECK VALVE	BC. ANSI B16.34.	A351 CF8M / F316.	5
RPV-VCK0200150RFCDDBLNKI	3/4" 150RF SW CHECK VALVE.	BC.	A351 CF8M / F316, HF.	9
RPV-VCK0200150RFEDDBINBO	3/4" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F5 / F316, HF.	5
RPV-VCK0200150RFEDDBINBO	3/4" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F9 / F316, HF.	5
RPV-VCK0200150RFGDDBINBO	3/4" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F11 / F316, HF.	5
RPV-VCK0200150RFHDDBINBO	3/4" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F316L / F316, HF.	86
RPV-VCK0200150RFHDDBKNBO	3/4" 150RF SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	25
RPV-VCK0200150RFLCDBINBO	3/4" 150RF P CHECK VALVE.	BC.	A350 LF2N / F316, HFS.	6
RPV-VCK0200150RFLDDBINBO	3/4" 150RF P CHECK VALVE.	BC. SPRING ASSISTED	A350 LF2N / F316, HF.	61
RPV-VCK0200150RFLDDBKNBO	3/4" 150RF SW. CHECK VALVE.	BC.	A350 LF2N / F316, HF	44
RPV-VCK0200150RFSHHBINBO	3/4" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F321(H) / F321, HF	10
RPV-VCK0200150RFVVBINBO	3/4" 150 RF P. CHECK VALVE,	BB, SPRING ASSIST.	A182 F55 / UNS S32760, HF	15
RPV-VCK0200300RFABBINBO	3/4" 300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F6, HF.	198
RPV-VCK0200300RFADDBINBO	3/4" 300RF P CHECK VALVE	BC. SPRING ASSISTED.	A105N / F316, HF.	399
RPV-VCK0200300RFADDBKNBO	3/4" 300RF SW CHECK VALVE.	BC.	A105N / F316, HF	24
RPV-VCK0200300RFCCBL PK	3/4" 300RF SW CHECK VALVE.	BC. ANSI B16.34.	A351 CF8M / F316.	10

GATE VALVES

GLOBE VALVES

CHECK VALVES

WAFER CHECK VALVES

BALL VALVES

BUTTERFLY VALVES

Code	Item Description			Current Stock
RPV-VCK0200300RFCDDBLNKI	3/4" 300RF SW CHECK VALVE.	BC.	A351 CF8M / F316, HF.	17
RPV-VCK0200300RFEDDBINBO	3/4" 300RF P CHECK VALVE.	BC. SPRING ASSISTED	A182 F5 / F316, HF.	5
RPV-VCK0200300RFFDDBINBO	3/4" 300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F9 / F316, HF.	10
RPV-VCK0200300RFGDDBINBO	3/4" 300RF P CHECK VALVE.	BC. SPRING ASSISTED	A182 F11 / F316, HF.	27
RPV-VCK0200300RFHDDBI*BO	3/4" 300RF P CHECK VALVE.	BC.	A182 F316(L) / F316, HF	74
RPV-VCK0200300RFHDDBINBO	3/4" 300RF P CHECK VALVE.	BC.	A182 F316(L) / F316, HF	62
RPV-VCK0200300RFHDDBK*BO	3/4" 300RF SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	96
RPV-VCK0200300RFLDDBINBO	3/4" 300RF P CHECK VALVE.	BC. SPRING ASSISTED	A350 LF2N / F316, HF.	105
RPV-VCK0200300RFLDDBKNBO	3/4" 300RF SW. CHECK VALVE.	BC.	A350 LF2N / F316, HF	10
RPV-VCK0200300RFSHHBINBO	3/4" 300RF P CHECK VALVE.	BC. SPRING ASSISTED	A182 F321(H) / F321, HF	8
RPV-VCK0200300UMADDWINBO	3/4" 300 UM P CHECK VALVE. WC.	SPRING ASSIST. HIGH LIFTING	A105N / F316, HF.	26
RPV-VCK0200300UMCDDBLNKI	3/4" 300UM SW CHECK VALVE.	BC. ANSI B16.34,	A351 CF8M / F316, HF.	8
RPV-VCK0200300UMEDDBINBO	3/4" 300 UM P CHECK VALVE.	BC. SPRING ASSISTED	A182 F5 / F316, HF.	10
RPV-VCK0200300UMEDDBKNBO	3/4" 300 UM SW. CHECK VALVE.	BC.	A182 F5 / F316, HF	10
RPV-VCK0200300UMFDDDBKNBO	3/4" 300 UM SW. CHECK VALVE.	BC.	A182 F9 / F316, HF	5
RPV-VCK0200300UMHDDBI*BO	3/4" 300 UM P CHECK VALVE.	BC.	A182 F316(L) / F316, HF	10
RPV-VCK0200300UMHDDBK*BO	3/4" 300 UM SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	20
RPV-VCK0200300UMMLLBNBO	3/4" 300 UM FB SW.CHECK VALVE.	BC. PTFE GASKET	MONEL 400 / MONEL 400	3
RPV-VCK0200300UMVVBINBO	3/4" 300 UM P. CHECK VALVE,	BB, SPRING ASSIST.	A182 F55 / UNS S32760, HF	15
RPV-VCK0200600BWADDWYNBO	3/4" CL 600 Y-PATT. P. CHECK VALVE.	WC. BW80. SPRING ASSIST	A105N / F316, HF	19
RPV-VCK0200600RFABBINBO	3/4" 600RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F6, HF.	30
RPV-VCK0200600RFADDBINBO	3/4" 600RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF.	20
RPV-VCK0200600RTIDDBINBO	3/4" 600 RTJ P .CHECK VALVE.	BC. SPRING ASSISTED.	A182 F316(L)/ F316, HF.	2
RPV-VCK0200600UMABBINBO	3/4" 600UM P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F6, HF.	65
RPV-VCK0200600UMABBKNBO	3/4" 600UM SW CHECK VALVE.	BC.	A105N / F6, HF.	14
RPV-VCK0200600UMADDBINBO	3/4" 600 UM P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF.	20
RPV-VCK0200600UMADDBKNBO	3/4" 600UM SW CHECK VALVE.	BC.	A105N / F316, HF.	24
RPV-VCK0200600UMCDDBLNKI	3/4" 600UM SW CHECK VALVE.	BC. ANSI B16.34,	A351 CF8M / F316, HF.	9
RPV-VCK0200600UMEDDBINBO	3/4" 600UM P CHECK VALVE.	BC. SPRING ASSISTED	A182 F5 / F316, HF.	10
RPV-VCK0200600UMFDDBINBO	3/4" 600UM P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F9 / F316, HF.	30
RPV-VCK0200600UMGDDBINBO	3/4" 600UM P CHECK VALVE.	BC. SPRING ASSISTED	A182 F11 / F316, HF.	15
RPV-VCK0200600UMHDDBK*BO	3/4" 600UM SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	70
RPV-VCK0200600UMHDDBKNBO	3/4" 600UM SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	46
RPV-VCK0200600UMIDDBI*BO	3/4" 600UM P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F316(L)/ F316, HF.	115
RPV-VCK0200600UMIDDBINBO	3/4" 600UM P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F316(L)/ F316, HF.	24
RPV-VCK0200600UMJFFBKNBO	3/4" 600UM SW CHECK VALVE.	BC.	A182 F304(L) / F304, HF	6
RPV-VCK0200600UMLDDBINBO	3/4" 600UM P CHECK VALVE	BC.	A350 LF2N / F316, HF.	98
RPV-VCK0200600UMLDDBKNBO	3/4" 600UM SW CHECK VALVE	BC.	A350 LF2N / F316, HF.	52
RPV-VCK0200600UMSHHBINBO	3/4" 600UM P CHECK VALVE	BC. SPRING ASSISTED.	A182 F321(H) / F321, HF	50
RPV-VCK0200600UMVVBINBO	3/4" 600 UM P. CHECK VALVE,	BB, SPRING ASSIST.	A182 F55 / UNS S32760, HF	15
RPV-VCK0200800BWABBKNBO	3/4" CL 800 SW CHECK VALVE.	BC. BW80.	A105N / F6, HF.	14
RPV-VCK0200800BWADDBINBO	3/4" CL 800 P. CHECK VALVE.	BC. BW80. SPRING ASSIST	A105N / F316, HF	69
RPV-VCK0200800BWADDBKNBO	3/4" CL 800 SW. CHECK VALVE.	BC. BW80. SPRING ASSIST	A105N / F316, HF	20
RPV-VCK0200800BWEDDBINBO	3/4" CL 800 P. CHECK VALVE.	BC. BW80. SPRING ASSIST	A182 F5 / F316, HF	20
RPV-VCK0200800BWHDDBI*BO	3/4" CL 800 P. CHECK VALVE.	BC. BW80. SPRING ASSIST	A182 F316(L) / F316, HF	20
RPV-VCK0200800BWHDDBINBO	3/4" CL 800 P. CHECK VALVE.	BC. BW80. SPRING ASSIST	A182 F316(L) / F316, HF	17
RPV-VCK0200800NPAABBINBO	3/4" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F6, HFS.	300
RPV-VCK0200800NPABBINBO	3/4" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F6, HF.	628
RPV-VCK0200800NPABBKNBO	3/4" CL 800 SW CHECK VALVE.	BC. NPTF.	A105N / F6, HF.	423
RPV-VCK0200800NPABBWINBO	3/4" CL 800 P CHECK VALVE.	WELDED COVER. NPTF.	A105N / F6, HF.	60
RPV-VCK0200800NPACBBMNBO	3/4" CL 800 BALL CHECK VALVE	BC. NPTF. SPRING ASSIST	A105N / 316 / F6, HFS.	88
RPV-VCK0200800NPADDBINBO	3/4" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F316, HF.	147

GATE VALVES

GLOBE VALVES

CHECK VALVES

WAFER CHECK VALVES

BALL VALVES

BUTTERFLY VALVES

Code	Item Description			Current Stock
RPV-VCK0200800NPEDDBINBO	3/4" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F5 / F316, HF.	30
RPV-VCK0200800NPFBBBINBO	3/4" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F9 / F6, HF.	4
RPV-VCK0200800NPFDDBINBO	3/4" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F9 / F316(L), HF.	4
RPV-VCK0200800NPGDDBINBO	3/4" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F11 / F316, HF.	136
RPV-VCK0200800NPHDDBI*BO	3/4" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F316(L) / F316, HF	148
RPV-VCK0200800NPHDDBINBO	3/4" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F316(L) / F316, HF	48
RPV-VCK0200800NPHDDBK*BO	3/4" CL 800 SW CHECK VALVE.	BC. NPTF.	A182 F316L / F316, HF.	75
RPV-VCK0200800NPHDDBKNBO	3/4" CL 800 SW CHECK VALVE.	BC. NPTF.	A182 F316L / F316, HF.	7
RPV-VCK0200800NPJFFBINBO	3/4" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F304L / F304, HF.	181
RPV-VCK0200800NPLDDBINBO	3/4" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A350 LF2N / F316, HF.	700
RPV-VCK0200800NPSHHBINBO	3/4" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F321-H / F321, HF.	107
RPV-VCK0200800PLA20BINBO	3/4" CL 800 P CHECK VALVE.	BC. PLAIN END, SPRING ASS.	ALLOY 20 / ALLOY 20, HF	5
RPV-VCK0200800PLA20BKNBO	3/4" CL 800 SW. CHECK VALVE.	BC. PLAIN END,	ALLOY 20 / ALLOY 20, HF	10
RPV-VCK0200800PLFDDBINBO	3/4" CL 800 P CHECK VALVE.	BC. SPRING ASS. PLAIN END	A182 F9 / F316(L), HF.	10
RPV-VCK0200800PLGDDBINBO	3/4" CL 800 P CHECK VALVE.	BC. SPRING ASS. PLAIN END	A182 F11 / F316(L), HF.	10
RPV-VCK0200800PLDDBKNBO	3/4" CL 800 SW. CHECK VALVE.	BC. PLAIN END (SCH 160 FB)	A350 LF2N / F316, HF.	37
RPV-VCK0200800PLSHHBINBO	3/4" CL 800 P CHECK VALVE.	BC. PLAIN END, SPRING ASS.	A182 F321-H / F321, HF.	9
RPV-VCK0200800PLVVVBINBO	3/4" CL 800 P. CHECK VALVE.	BC. PLAIN END (SCH 160 FB)	A182 F55 / UNS S32760, HF	5
RPV-VCK0200800PLVVVBKNBO	3/4" CL 800 SW. CHECK VALVE.	BC. PLAIN END (SCH 160 FB)	A182 F55 / UNS S32760, HF	5
RPV-VCK0200800PLYYYBINBO	3/4" CL 800 P.CHECK VALVE, BC.	SPRING ASSIST. PLAIN END	A182 F347-H / F347, HF	5
RPV-VCK0200800SWAABBINBO	3/4" CL 800 P CHECK VALVE.	BC. S/WELD. SPRING ASS.	A105N / F6, HFS.	419
RPV-VCK0200800SWABBINBO	3/4" CL 800 P CHECK VALVE.	BC. S/WELD. SPRING ASSIST	A105N / F6, HF.	190
RPV-VCK0200800SWABBKNBO	3/4" CL 800 SW CHECK VALVE.	BC. S/WELD.	A105N / F6, HF	63
RPV-VCK0200800SWACDBMNBO	3/4" CL 800 BALL CHECK VALVE	BC. S/WELD. SPRING ASSIST	A105N / 316 / F316, HFS.	142
RPV-VCK0200800SWHDDBI*BO	3/4" CL 800 P CHECK VALVE.	BC. S/WELD, SPRING ASSIST	A182 F316(L) / F316, HF	65
RPV-VCK0200800SWLDDBINBO	3/4" CL 800 P CHECK VALVE.	BC. S/WELD. SPRING ASS.	A350 LF2N / F316, HF	492
RPV-VCK0201500BWADDBINBO	3/4" CL1500 P CHECK VALVE.	BC. BW160. SPRING ASSIST	A105N / F316, HF	25
RPV-VCK0201500NPADDBINBO	3/4" CL1500 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F316, HF.	51
RPV-VCK0201500NPHDDBI*BO	3/4" CL1500 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F316L / F316, HF.	88
RPV-VCK0201500NPLDDBINBO	3/4" CL1500 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A350 LF2N / F316, HF.	35
RPV-VCK0201500PLADDBKNBO	3/4" CL1500 SW. CHECK VALVE.	BC. PLAIN END	A105N / F316, HF.	10
RPV-VCK0201500PLHDDBI*BO	3/4" CL1500 P CHECK VALVE.	BC. PLAIN END. SPRING ASSIST.	A182 F316L / F316, HF.	10
RPV-VCK0201500PLHDDBINBO	3/4" CL1500 P CHECK VALVE.	BC. PLAIN END. SPRING ASSIST.	A182 F316L / F316, HF.	2
RPV-VCK0201500PLHDDBLNBO	3/4" CL1500 FB SW. CHECK VALVE.	BC, FULL BORE, PLAIN END	A182 F316(L) / F316, HF.	20
RPV-VCK0201500PLDDBINBO	3/4" CL1500 P CHECK VALVE.	BC. SPRING ASSIST. PLAIN END.	A350 LF2N / F316, HF.	33
RPV-VCK0201500PLDDBLNBO	3/4" CL1500 FB SW. CHECK VALVE.	BC, FULL BORE, PLAIN END	A350 LF2N / F316, HF.	20
RPV-VCK0201500PLVVVBINBO	3/4" CL1500 P.CHECK VALVE,	BC, PLAIN END SPRING ASS.	A182 F55 / F55, HF	10
RPV-VCK0201500RFLDDBJNBO	3/4" 1500 RF P CHECK VALVE.	BC. FULL BORE. SPRING	A350 LF2N / F316, HF.	1
RPV-VCK0201500SWHCCBI BO	3/4" CL1500 P CHECK VALVE.	BC. S/WELD.	A182 F316L / F316.	1
RPV-VCK0201500UMADDBJNBO	3/4" 1500UM P CHECK VALVE.	BC. FB. SPRING ASSISTED	A105N / F316, HF.	85
RPV-VCK0201500UMIDDBJ*BO	3/4" 1500UM FB P CHECK VALVE	BC. SPRING ASSISTED.	A182 F316(L) / F316, HF	96
RPV-VCK0201500UMIDDBJNBO	3/4" 1500UM FB P CHECK VALVE	BC. SPRING ASSISTED.	A182 F316(L) / F316, HF	4
RPV-VCK0201500UMIDDBL*BO	3/4" 1500UM SW. CHECK VALVE.	BC. FULL BORE.	A182 F316L / F316, HF.	14
RPV-VCK0201500UMLDDBJNBO	3/4" 1500UM P CHECK VALVE.	BC. FULL BORE. SPRING	A350 LF2N / F316, HF.	46
RPV-VCK0201500UMLDDBLNBO	3/4" 1500 UM SW. CHECK VALVE.	BC. FULL BORE.	A350 LF2N / F316, HF.	16
RPV-VCK0202500NPIDDBI*BO	3/4" CL 2500 FB P. CHECK VALVE	BC, NPTF. SPRING ASSIST	A182 F316(L) / F316, HF	18
RPV-VCK0202500NPLDDBINBO	3/4" CL 2500 FB P. CHECK VALVE,	BC, NPTF. SPRING ASSIST	A350 LF2N / F316, HF	60
RPV-VCK0202500PLHDDBJNBO	3/4" CL 2500 FB P. CHECK VALVE,	BC, SPRING ASSIST. PLAIN END	A182 F316(L) / F316, HF	18
RPV-VCK0202500PLHDDBLNBO	3/4" CL 2500 FB SW. CHECK VALVE,	BC, PLAIN END	A182 F316(L) / F316, HF	10
RPV-VCK0202500PLDDBJNBO	3/4" CL 2500 FB P. CHECK VALVE,	BC, SPRING ASSIST. PLAIN END	A350 LF2N / F316, HF	20
RPV-VCK0202500PLDDBLNBO	3/4" CL 2500 FB SW. CHECK VALVE,	BC, PLAIN END. SPRING ASS.	A350 LF2N / F316, HF	3
RPV-VCK0202500SWLDDBJNBO	3/4" CL 2500 FB P. CHECK VALVE,	BC, S/WELD. SPRING ASSIST	A350 LF2N / F316, HF	9

GATE VALVES

GLOBE VALVES

CHECK VALVES

WAFER CHECK VALVES

BALL VALVES

BUTTERFLY VALVES

Code	Item Description			Current Stock
RPV-VCK0202500UMIDDBJ*BO	3/4" 2500UM FB P CHECK VALVE	BC. SPRING ASSISTED.	A182 F316-L / F316, HF	20
RPV-VCK0202500UMIDDBJNBO	3/4" 2500UM FB P CHECK VALVE	BC. SPRING ASSISTED.	A182 F316-L / F316, HF	4
RPV-VCK0202500UMIDDBLNBO	3/4" 2500UM FB SW. CHECK VALVE	BC.	A182 F316-L / F316, HF	10
RPV-VCK0202500UMLDDBJNBO	3/4" 2500UM FB P CHECK VALVE	BC. SPRING ASSISTED.	A350 LF2N / F316(L), HF	12
RPV-VCK020PN32NPBBBK SH	3/4" PN32 SW. CHECK VALVE.	NPTF. UB	ASTM B148 C95800	9
RPV-VCK020PN32NPBBBUI SH	3/4" PN32 P CHECK VALVE, UB.	NPTF.	ALI BRONZE. B148 C95800	21
RPV-VCK0250150FFBDBBI SH	1" 150 FF PISTON CHECK VALVE.	BOLTED COVER	ASTM B148 C95800	8
RPV-VCK0250150FFBDBBK SH	1" 150 FF SW. CHECK VALVE.	BOLTED COVER	ASTM B148 C95800	9
RPV-VCK0250150RF276BLNBO	1" 150RF FB SW CHECK VALVE.	BC. FULL BORE.	A494 CW12MW / HAS C276, HF	5
RPV-VCK0250150RFA20BINBO	1" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	ALLOY 20 / ALLOY 20, HF	2
RPV-VCK0250150RFABBINBO	1" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F6, HF.	659
RPV-VCK0250150RFADDBINBO	1" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF.	507
RPV-VCK0250150RFADDBKNBO	1" 150RF SW. CHECK VALVE.	BC.	A105N / F316, HF	426
RPV-VCK0250150RFADDBWINBO	1" 150RF P CHECK VALVE. WC	SPRING ASSIST. HIGH LIFTING	A105N / F316, HF.	22
RPV-VCK0250150RFCDDBLNKI	1" 150RF SW CHECK VALVE.	BC. API 600	A351 CF8M / F316, HF.	33
RPV-VCK0250150RFHDBI*BO	1" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F316(L) / F316, HF	162
RPV-VCK0250150RFHDBK*BO	1" 150RF SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	50
RPV-VCK0250150RFHDBKNBO	1" 150RF SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	34
RPV-VCK0250150RFLDDBINBO	1" 150RF P CHECK VALVE.	BC. SPRING ASSISTED	A350 LF2N / F316, HF.	256
RPV-VCK0250150RFLDDBKNBO	1" 150RF SW. CHECK VALVE.	BC.	A350 LF2N / F316, HF	77
RPV-VCK0250150RFMLLBNBO	1" 150 RF P. CHECK VALVE.	BC.	MONEL 400 / MONEL 400, HF	2
RPV-VCK0250150RFMLLBKNBO	1" 150RF SW. CHECK VALVE.	BC.	MONEL 400 / MONEL 400, HF	2
RPV-VCK0250150RFSHHBNBO	1" 150RF P CHECK VALVE	BC. SPRING ASSISTED.	A182 F321(H) / F321, HF	22
RPV-VCK0250150RFSHHBKNBO	1" 150RF SW. CHECK VALVE	BC.	A182 F321(H) / F321, HF	5
RPV-VCK0250150RFTITBINBO	1" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	B381 F2 TITANIUM BODY	3
RPV-VCK0250150RFVVBINBO	1" 150 RF P. CHECK VALVE,	BB, SPRING ASSIST.	A182 F55 / UNS S32760, HF	15
RPV-VCK0250300RFABBINBO	1" 300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F6, HF.	47
RPV-VCK0250300RFADDBINBO	1" 300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF.	64
RPV-VCK0250300RFADDBKNBO	1" 300RF SW CHECK VALVE.	BC.	A105N / F316, HF.	77
RPV-VCK0250300RFCDDBLNKI	1" 300RF SW CHECK VALVE.	BC. API 600	A351 CF8M / F316, HF.	5
RPV-VCK0250300RFEDDBINBO	1" 300RF P CHECK VALVE.	BC. SPRING ASSISTED	A182 F5 / F316, HF.	36
RPV-VCK0250300RFFDDBINBO	1" 300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F9 / F316, HF.	24
RPV-VCK0250300RFGDDBINBO	1" 300RF P CHECK VALVE.	BC. SPRING ASSISTED	A182 F11 / F316, HF.	34
RPV-VCK0250300RFHDBI*BO	1" 300RF P CHECK VALVE.	BC. SPRING ASSISTED	A182 F316(L) / F316, HF	125
RPV-VCK0250300RFHDBINBO	1" 300RF P CHECK VALVE.	BC. SPRING ASSISTED	A182 F316(L) / F316, HF	7
RPV-VCK0250300RFHDBK*BO	1" 300RF SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	50
RPV-VCK0250300RFHDBKNBO	1" 300RF SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	54
RPV-VCK0250300RFLDDBINBO	1" 300RF P CHECK VALVE.	BC. SPRING ASSISTED	A350 LF2N / F316, HF.	86
RPV-VCK0250300RFLDDBKNBO	1" 300RF SW. CHECK VALVE.	BC.	A350 LF2N / F316, HF	38
RPV-VCK0250300RFSHHBNBO	1" 300RF P CHECK VALVE	BC. SPRING ASSISTED	A182 F321 / F321, HF.	24
RPV-VCK0250300RFZEEBI BO	1" 300RF P CHECK VALVE.	BC.	A350 LF3 / F304.	1
RPV-VCK0250300UMA20BINBO	1" 300 UM P CHECK VALVE	BC. SPRING ASSISTED	ALLOY 20 / ALLOY 20, HF	2
RPV-VCK0250300UMADDBWINBO	1" 300 UM P CHECK VALVE. WC.	SPRING ASSIST. HIGH LIFTING	A105N / F316, HF.	75
RPV-VCK0250300UMCDDBLNKI	1" 300UM SW CHECK VALVE.	BC. ANSI B16.34,	A351 CF8M / F316, HF.	3
RPV-VCK0250300UMEDDBINBO	1" 300 UM P CHECK VALVE.	BC. SPRING ASSISTED	A182 F5 / F316, HF	10
RPV-VCK0250300UMEDDBKNBO	1" 300 UM SW. CHECK VALVE.	BC.	A182 F5 / F316, HF	10
RPV-VCK0250300UMFDDDBKNBO	1" 300 UM SW. CHECK VALVE.	BC.	A182 F9 / F316, HF	5
RPV-VCK0250300UMLDDBKNBO	1" 300 UM SW. CHECK VALVE.	BC.	A350 LF2N / F316, HF	20
RPV-VCK0250300UMMLLBNBO	1" 300 UM FB SW.CHECK VALVE.	BC. PTFE GASKET	MONEL 400 / MONEL 400	3
RPV-VCK0250300UMSHHBNBO	1" 300 UM P CHECK VALVE	BC. SPRING ASSISTED	A182 F321 / F321, HF.	20
RPV-VCK0250300UMVVVBINBO	1" 300 UM P. CHECK VALVE,	BB, SPRING ASSIST.	A182 F55 / UNS S32760, HF	11
RPV-VCK0250600BWADDWYNBO	1" CL 600 Y-PATT. P. CHECK VALVE.	WC. BW80. SPRING ASSIST	A105N / F316, HF	20

GATE VALVES

GLOBE VALVES

CHECK VALVES

WAFER CHECK VALVES

BALL VALVES

BUTTERFLY VALVES

Code	Item Description			Current Stock
RPV-VCK0250600RFADDBINBO	1" 600RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF.	62
RPV-VCK0250600RFADDWINBO	1" 600RF P CHECK VALVE.	WC. SPRING ASSISTED.	A105N / F316, HF.	1
RPV-VCK0250600RFLDDBINBO	1" 600RF P CHECK VALVE.	BC. SPRING ASSISTED	A350 LF2N / F316, HF	43
RPV-VCK0250600UM276BKNBO	1" 600 UM SW. CHECK VALVE,	BC, PTFE GASKET	A494 CW12MW / HAST C276, HF	4
RPV-VCK0250600UMABBINBO	1" 600UM P CHECK VALVE.	BC. SPRING ASSISTED	A105N / F6, HF.	42
RPV-VCK0250600UMADDBINBO	1" 600UM P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF.	67
RPV-VCK0250600UMADDBKNBO	1" 600UM SW CHECK VALVE.	BC.	A105N / F316, HF	131
RPV-VCK0250600UMCDDBL*KI	1" 600UM SW CHECK VALVE.	BC.	A351 CF8M / F316, HF.	5
RPV-VCK0250600UMCDDBLNKI	1" 600UM SW CHECK VALVE.	BC. ANSI B16.34,	A351 CF8M / F316, HF.	1
RPV-VCK0250600UMEDDBINBO	1" 600UM P CHECK VALVE.	BC. SPRING ASSISTED	A182 F5 / F316, HF.	27
RPV-VCK0250600UMFDDBINBO	1" 600UM P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F9 / F316, HF.	39
RPV-VCK0250600UMGDDBINBO	1" 600UM P CHECK VALVE.	BC. SPRING ASSISTED	A182 F11 / F316, HF.	42
RPV-VCK0250600UMHDDBK*BO	1" 600UM SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	35
RPV-VCK0250600UMHDDBKNBO	1" 600UM SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	1
RPV-VCK0250600UMIDDBI*BO	1" 600UM P CHECK VALVE.	BC. SPRING ASSISTED	A182 F316(L)/ F316, HF.	100
RPV-VCK0250600UMIDDBINBO	1" 600UM P CHECK VALVE.	BC. SPRING ASSISTED	A182 F316(L)/ F316, HF.	12
RPV-VCK0250600UMJFFBKNBO	1" 600UM SW CHECK VALVE	BC.	A182 F304(L) / F304, HF	13
RPV-VCK0250600UMLDDBINBO	1" 600UM P CHECK VALVE.	BC. SPRING ASSISTED	A350 LF2N / F316, HF.	46
RPV-VCK0250600UMLDDBKNBO	1" 600UM SW CHECK VALVE.	BC.	A350 LF2N / F316, HF.	56
RPV-VCK0250600UMSHHBINBO	1" 600UM P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F321(H) / F321, HF	24
RPV-VCK0250600UMVVVBINBO	1" 600 UM P. CHECK VALVE,	BB, SPRING ASSIST.	A182 F55 / UNS S32760, HF	15
RPV-VCK0250800BWABBKNBO	1" CL 800 SW CHECK VALVE.	BC. BW80.	A105N / F6, HF.	85
RPV-VCK0250800BWADDBINBO	1" CL 800 P. CHECK VALVE.	BC. BW80. SPRING ASSIST	A105N / F316, HF	110
RPV-VCK0250800BWADDBKNBO	1" CL 800 SW CHECK VALVE.	BC. BW80.	A105N / F316, HF	93
RPV-VCK0250800BWEDDBINBO	1" CL 800 P. CHECK VALVE.	BC. BW80. SPRING ASSIST	A182 F5 / F316, HF	17
RPV-VCK0250800BWHDDBINBO	1" CL 800 P. CHECK VALVE.	BC. BW80. SPRING ASSIST	A182 F316(L) / F316, HF	111
RPV-VCK0250800NPAABBINBO	1" CL 800 P CHECK VALVE.	BC. NPTF.	A105N / F6, HFS.	468
RPV-VCK0250800NPABBINBO	1" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F6, HF.	649
RPV-VCK0250800NPABBKNBO	1" CL 800 SW CHECK VALVE.	BC. NPTF.	A105N / F6, HF.	300
RPV-VCK0250800NPABBWINBO	1" CL 800 P CHECK VALVE.	WC. NPTF. SPRING ASSIST	A105N / F6, HF.	64
RPV-VCK0250800NPACBBMNBO	1" CL 800 BALL CHECK VALVE	BC. NPTF.	A105N / 316 / F6, HFS.	1
RPV-VCK0250800NPACDBMNBO	1" CL 800 BALL CHECK VALVE	BC. NPTF. SPRING ASS.	A105N / 316 / F316, HFS	378
RPV-VCK0250800NPADDBINBO	1" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F316, HF.	196
RPV-VCK0250800NPADDBKNBO	1" CL 800 SW CHECK VALVE.	BC. NPTF.	A105N / F316, HF	105
RPV-VCK0250800NPALLBMNBO	1" CL 800 BALL CHECK VALVE	BC. NPTF.	A105N / MONEL	67
RPV-VCK0250800NPEDDBINBO	1" CL 800 P CHECK VALVE.	BC. NPTF.	A182 F5 / F316, HF	80
RPV-VCK0250800NPFDDBINBO	1" CL 800 P.CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F9 / F316, HF.	14
RPV-VCK0250800NPGDDBINBO	1" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F11 / F316, HF.	42
RPV-VCK0250800NPHDDBI*BO	1" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F316(L) / F316, HF	320
RPV-VCK0250800NPHDDBKNBO	1" CL 800 SW CHECK VALVE.	BC. NPTF.	A182 F316L / F316, HF.	72
RPV-VCK0250800NPJFFBINBO	1" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F304(L) / F304, HF	63
RPV-VCK0250800NPLDDBINBO	1" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A350 LF2N / F316, HF.	278
RPV-VCK0250800NPSHHBINBO	1" CL 800 P CHECK VALVE.	BC. NPTF.	A182 F321-H / F321, HF.	31
RPV-VCK0250800PL276BINBO	1" CL 800 P CHECK VALVE.	BC. PLAIN END, SPRING ASS.	A494 CW12MW / HAS 276, HF	15
RPV-VCK0250800PL825BKNBO	1" CL 800 SW. CHECK VALVE.	BC. PLAIN END,	INC 825 / INC 825, HF	5
RPV-VCK0250800PLA20BINBO	1" CL 800 P CHECK VALVE.	BC. PLAIN END, SPRING ASS.	ALLOY 20 / ALLOY 20, HF	5
RPV-VCK0250800PLA20BKNBO	1" CL 800 FB SW. CHECK VALVE.	BC. PLAIN END,	ALLOY 20 / ALLOY 20, HF	10
RPV-VCK0250800PLFDDBINBO	1" CL 800 P CHECK VALVE.	BC. SPRING ASS. PLAIN END	A182 F9 / F316(L), HF.	10
RPV-VCK0250800PLGDDBINBO	1" CL 800 P CHECK VALVE.	BC. SPRING ASS. PLAIN END	A182 F11 / F316(L), HF.	10
RPV-VCK0250800PLDDBKNBO	1" CL 800 SW. CHECK VALVE.	BC. PLAIN END (SCH 160 FB)	A350 LF2N / F316, HF.	33
RPV-VCK0250800PLMLLBINBO	1" CL 800 P.CHECK VALVE.	BC. SPRING ASSIST. PLAIN END	MONEL 400 / MONEL 400	2
RPV-VCK0250800PLVVVBINBO	1" CL 800 P. CHECK VALVE.	BC. PLAIN END (SCH 160 FB)	A182 F55 / UNS S32760, HF	5

GATE VALVES

GLOBE VALVES

CHECK VALVES

WAFER CHECK VALVES

BALL VALVES

BUTTERFLY VALVES

Code	Item Description			Current Stock
RPV-VCK0250800PLVVVBKNBO	1" CL 800 SW. CHECK VALVE.	BC. PLAIN END (SCH 160 FB)	A182 F55 / UNS S32760, HF	5
RPV-VCK0250800PLYYBINBO	1" CL 800 P.CHECK VALVE.	BC. SPRING ASSIST. PLAIN END	A182 F347(H) / F347, HF	5
RPV-VCK0250800PPHDDBI*BO	1" CL 800 P CHECK VALVE.	BC. S/WELD, SPRING ASS.	A182 F316(L) / F316, HF	1
RPV-VCK0250800SWAABBINBO	1" CL 800 P CHECK VALVE.	BC. S/WELD. SPRING ASS.	A105N / F6, HFS.	686
RPV-VCK0250800SWABBINBO	1" CL 800 P CHECK VALVE.	BC. S/WELD. SPRING ASSIST	A105N / F6, HF.	124
RPV-VCK0250800SWACDBMNBO	1" CL 800 BALL CHECK VALVE	BC. S/WELD. SPRING ASS.	A105N / 316 / F316, HFS	352
RPV-VCK0250800SWHDDBI*BO	1" CL 800 P CHECK VALVE.	BC. S/WELD, SPRING ASS.	A182 F316(L) / F316, HF	137
RPV-VCK0250800SWLDDBINBO	1" CL 800 P CHECK VALVE.	BC. S/WELD. SPRING ASSIST	A350 LF2N / F316, HF.	219
RPV-VCK0251500BWADDBINBO	1" CL1500 P CHECK VALVE.	BC. BW160. SPRING ASSIST	A105N / F316, HF	28
RPV-VCK0251500NPABBINBO	1" CL1500 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F6, HF.	55
RPV-VCK0251500NPADDBINBO	1" CL1500 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F316, HF.	101
RPV-VCK0251500NPHDDBI*BO	1" CL1500 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F316L / F316, HF.	74
RPV-VCK0251500NPLDDBINBO	1" CL1500 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A350 LF2N / F316, HF.	29
RPV-VCK0251500PLADDBKNBO	1" CL1500 SW. CHECK VALVE.	BC. PLAIN END	A105N / F316, HF.	8
RPV-VCK0251500PLHDDBI*BO	1" CL1500 P CHECK VALVE.	BC. PLAIN END, SPRING ASS	A182 F316L / F316, HF.	35
RPV-VCK0251500PLHDDBINBO	1" CL1500 P CHECK VALVE.	BC. SPRING ASSIST. PLAIN END	A182 F316L / F316, HF.	11
RPV-VCK0251500PLHDDBLNBO	1" CL1500 FB SW. CHECK VALVE.	BC, FULL BORE, PLAIN END	A182 F316(L) / F316, HF.	15
RPV-VCK0251500PLDDBINBO	1" CL1500 P CHECK VALVE.	BC. SPRING ASSIST. PLAIN END.	A350 LF2N / F316, HF.	10
RPV-VCK0251500PLDDBLNBO	1" CL1500 FB SW. CHECK VALVE.	BC, FULL BORE, PLAIN END	A350 LF2N / F316, HF.	10
RPV-VCK0251500PLVVBINBO	1" CL1500 P.CHECK VALVE,	BC, PLAIN END SPRING ASS.	A182 F55 / F55, HF	8
RPV-VCK0251500SWLDDBMNBO	1" CL1500 BALL CHECK VALVE.	BC. S/WELD. SPRING ASS.	A350 LF2 / F316, HFS	2
RPV-VCK0251500UMADDBJNBO	1" 1500UM P CHECK VALVE.	BC. FB. SPRING ASSISTED	A105N / F316, HF.	204
RPV-VCK0251500UMIDDBJ*BO	1" 1500UM P CHECK VALVE	BC. FULL BORE, SPRING	A182 F316 / F316, HF.	86
RPV-VCK0251500UMIDDBL*BO	1" 1500UM SW. CHECK VALVE.	BC. FULL BORE.	A182 F316L / F316, HF.	25
RPV-VCK0251500UMLDDBINBO	1" 1500UM P CHECK VALVE.	BC. FULL BORE. SPRING	A350 LF2N / F316, HF.	118
RPV-VCK0251500UMLDDBLNBO	1" 1500 UM SW. CHECK VALVE.	BC. FULL BORE.	A350 LF2N / F316, HF.	20
RPV-VCK0252500NPIDDBINBO	1" CL 2500 FB P. CHECK VALVE	BC, NPTF. SPRING ASSIST	A182 F316(L) / F316, HF	63
RPV-VCK0252500NPLDDBINBO	1" CL 2500 P. CHECK VALVE,	BC, NPTF. SPRING ASSIST	A350 LF2N / F316, HF	146
RPV-VCK0252500PLHDDBLNBO	1" CL 2500 FB SW. CHECK VALVE,	BC, PLAIN END	A182 F316(L) / F316, HF	10
RPV-VCK0252500PLIDDBINBO	1" CL 2500 P. CHECK VALVE	BC, PLAIN END. SPRING ASSIST	A182 F316(L) / F316, HF	8
RPV-VCK0252500PLDDBINBO	1" CL 2500 P. CHECK VALVE,	BC, PLAIN END. SPRING ASSIST	A350 LF2N / F316, HF	19
RPV-VCK0252500PLDDBLNBO	1" CL 2500 FB SW. CHECK VALVE,	BC, PLAIN END. SPRING ASS.	A350 LF2N / F316, HF	3
RPV-VCK0252500PLVVBJNBO	1" CL 2500 FB P CHECK VALVE	BC. SPRING ASSIST, PLAIN	A182 F55 / UNS S32760, HF	3
RPV-VCK0252500UMIDDBJ*BO	1" 2500UM FB P CHECK VALVE	BC. SPRING ASSISTED.	A182 F316-L / F316, HF	31
RPV-VCK0252500UMIDDBLNBO	1" 2500UM FB SW. CHECK VALVE	BC.	A182 F316-L / F316, HF	8
RPV-VCK0252500UMLDDBINBO	1" 2500UM FB P CHECK VALVE	BC. SPRING ASSISTED.	A350 LF2N / F316(L), HF	53
RPV-VCK0252500UMVVBJNBO	1" 2500UM FB P CHECK VALVE	BC. SPRING ASSISTED.	A182 F55 / UNS S32760, HF	5
RPV-VCK025PN32NPBBBK SH	1" PN32 SW. CHECK VALVE.	NPTF. UB	ASTM B148 C95800	19
RPV-VCK025PN32NPBBBUI SH	1" PN32 P CHECK VALVE, UB.	NPTF.	ASTM B148 C95800.	34
RPV-VCK0400150FFBDBBI SH	1 1/2" 150 FF PISTON CHECK VALVE.	BOLTED COVER	ASTM B148 C95800	8
RPV-VCK0400150FFBDBBK SH	1 1/2" 150 FF SW. CHECK VALVE.	BOLTED COVER	ASTM B148 C95800	10
RPV-VCK0400150RF276BLNBO	1 1/2" 150RF FB SW CHECK VALVE.	BC. FULL BORE.	A494 CW12MW / HAS C276, HF	5
RPV-VCK0400150RFA20BKNBO	1 1/2" 150 RF SW. CHECK VALVE.	BC. SPRING ASSISTED.	ALLOY 20 / ALLOY 20, HF	2
RPV-VCK0400150RFADDBINBO	1.1/2" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF.	117
RPV-VCK0400150RFADDBKNBO	1.1/2" 150RF SW CHECK VALVE.	BC.	A105N / F316, HF	111
RPV-VCK0400150RFADDBWINBO	1 1/2" 150RF P CHECK VALVE. WC	SPRING ASSIST. HIGH LIFTING	A105N / F316, HF.	21
RPV-VCK0400150RFCDDBL*KI	1.1/2" 150RF SW CHECK VALVE.	BC. BS 1868	A351 CF8M / F316, HF.	10
RPV-VCK0400150RFHDDBI*BO	1.1/2" 150RF P CHECK VALVE.	BC. SPRING ASSISTED	A182 F316(L) / F316, HF	50
RPV-VCK0400150RFHDDBINBO	1.1/2" 150RF P CHECK VALVE.	BC. SPRING ASSISTED	A182 F316(L) / F316, HF	39
RPV-VCK0400150RFHDDBK*BO	1.1/2" 150RF SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	22
RPV-VCK0400150RFHDDBKNBO	1.1/2" 150RF SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	18
RPV-VCK0400150RFLDDBINBO	1.1/2" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A350 LF2N / F316, HF.	37

GATE VALVES

GLOBE VALVES

CHECK VALVES

WAFER CHECK VALVES

BALL VALVES

BUTTERFLY VALVES

Code	Item Description			Current Stock
RPV-VCK0400150RFLDDBKNBO	1.1/2" 150RF SW. CHECK VALVE	BC.	A350 LF2N / F316, HF	37
RPV-VCK0400150RFSHHBINBO	1.1/2" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F321(H) / F321, HF	6
RPV-VCK0400150RFVVBINBO	1.1/2" 150 RF FB P. CHECK VALVE.	BC. SPRING ASSISTED.	A182 F55 / UNS S32760, HF	7
RPV-VCK0400150RFVVBINBO	1.1/2" 150 RF FB SW. CHECK VALVE.	BC.	A182 F55 / UNS S32760, HF	2
RPV-VCK0400300RFABBINBO	1.1/2" 300RF P CHECK VALVE	BC. SPRING ASSISTED	A105N / F6, HF.	37
RPV-VCK0400300RFADDBINBO	1.1/2" 300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF.	34
RPV-VCK0400300RFADDBKNBO	1.1/2" 300RF SW CHECK VALVE.	BC.	A105N / F316, HF.	36
RPV-VCK0400300RFCDDBL*KI	1.1/2" 300RF SW CHECK VALVE.	BC. BS 1868	A351 CF8M / F316, HF.	10
RPV-VCK0400300RFEDDBINBO	1.1/2" 300RF P CHECK VALVE.	BC. SPRING ASSISTED	A182 F5 / F316, HF.	16
RPV-VCK0400300RFGDDBINBO	1.1/2" 300RF P CHECK VALVE.	BC. SPRING ASSISTED	A182 F11 / F316, HF	11
RPV-VCK0400300RFHDDBINBO	1.1/2" 300RF P CHECK VALVE.	BC. SPRING ASSISTED	A182 F316(L) / F316, HF	11
RPV-VCK0400300RFHDDBK*BO	1.1/2" 300RF SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	15
RPV-VCK0400300RFHDDBKNBO	1.1/2" 300RF SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	6
RPV-VCK0400300RFLDDBINBO	1.1/2" 300RF P CHECK VALVE	BC.	A350 LF2N / F316, HF.	37
RPV-VCK0400300RFLDDBKNBO	1.1/2" 300RF SW CHECK VALVE.	BC.	A350 LF2N / F316, HF.	26
RPV-VCK0400300RFSHHBINBO	1.1/2" 300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F321(H) / F321, HF	27
RPV-VCK0400300UMADDWINBO	1 1/2" 300 UM P CHECK VALVE. WC.	SPRING ASSIST. HIGH LIFTING	A105N / F316, HF.	10
RPV-VCK0400300UMCDDBLNKI	1.1/2" 300UM SW CHECK VALVE.	BC. ANSI B16.34,	A351 CF8M / F316, HF.	5
RPV-VCK0400300UMMEDDBINBO	1.1/2" 300 UM P CHECK VALVE.	BC. SPRING ASSISTED	A182 F5 / F316, HF.	10
RPV-VCK0400300UMFDDBINBO	1.1/2" 300 UM P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F9 / F316, HF	8
RPV-VCK0400300UMHDDBKNBO	1.1/2" 300 UM SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	5
RPV-VCK0400300UMLDDBINBO	1.1/2" 300 UM P CHECK VALVE	BC.	A350 LF2N / F316, HF.	11
RPV-VCK0400300UMVVBINBO	1 1/2" 300 UM P. CHECK VALVE,	BB, SPRING ASSIST.	A182 F55 / UNS S32760, HF	10
RPV-VCK0400600BWADDWYNBO	1 1/2" CL 600 Y-PATT. P. CHECK VALVE.	WC. BW80. SPRING ASSIST	A105N / F316, HF	9
RPV-VCK0400600RFADDBINBO	1.1/2" 600RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF.	23
RPV-VCK0400600RFADDBKNBO	1.1/2" 600RF SW CHECK VALVE	BC	A105N / F316, HF	19
RPV-VCK0400600RFUIJBINSA	1.1/2" 600RF P.CHECK VALVE.	BC.	A182 F51 / S31803, HFS.	1
RPV-VCK0400600UMABBINBO	1.1/2" 600UM P CHECK VALVE.	BC.	A105N / F6, HF.	52
RPV-VCK0400600UMADDBINBO	1.1/2" 600UM P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF.	53
RPV-VCK0400600UMADDBKNBO	1.1/2" 600 UM SW. CHECK VALVE	BC	A105N / F316, HF	43
RPV-VCK0400600UMCDDBLNKI	1.1/2" 600UM SW CHECK VALVE.	BC. ANSI B16.34,	A351 CF8M / F316, HF.	9
RPV-VCK0400600UMMEDDBINBO	1.1/2" 600UM P CHECK VALVE.	BC. SPRING ASSISTED	A182 F5 / F316, HF.	18
RPV-VCK0400600UMFDDBINBO	1.1/2" 600UM P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F9 / F316, HF.	8
RPV-VCK0400600UMGDDBINBO	1.1/2" 600UM P CHECK VALVE.	BC. SPRING ASSISTED	A182 F11 / F316, HF.	9
RPV-VCK0400600UMHDDBK*BO	1.1/2" 600UM SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	30
RPV-VCK0400600UMHDDBKNBO	1.1/2" 600UM SW CHECK VALVE.	BC.	A182 F316L / F316, HF.	12
RPV-VCK0400600UMIDDBINBO	1.1/2" 600UM P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F316(L)/ F316, HF.	15
RPV-VCK0400600UMJFFBKNBO	1.1/2" 600UM SW CHECK VALVE	BC.	A182 F304(L) / F304, HF	3
RPV-VCK0400600UMLDDBINBO	1.1/2" 600UM P CHECK VALVE.	BC. SPRING ASSISTED.	A350 LF2N / F316, HF.	22
RPV-VCK0400600UMLDDBKNBO	1.1/2" 600UM SW CHECK VALVE.	BC.	A350 LF2N / F316, HF.	40
RPV-VCK0400600UMSHHBINBO	1.1/2" 600UM P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F321(H)/ F321, HF.	14
RPV-VCK0400600UMVVBINBO	1 1/2" 600 UM P. CHECK VALVE,	BB, SPRING ASSIST.	A182 F55 / UNS S32760, HF	10
RPV-VCK0400800BWABBBKNBO	1.1/2" CL 800 SW CHECK VALVE.	BC. BW80.	A105N / F6, HF.	27
RPV-VCK0400800BWADDBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. BW80. SPRING ASSIST	A105N / F316, HF	65
RPV-VCK0400800BWADDBKNBO	1.1/2" CL 800 SW CHECK VALVE.	BC. BW80.	A105N / F316, HF	40
RPV-VCK0400800BWEDDBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. BW80. SPRING ASSIST	A182 F5 / F316, HF	26
RPV-VCK0400800BWLCDMNSA	1.1/2" CL800 BALL CHECK VALVE	BC, BUTT WELD SCH 160	A350 LF2N / F316, HFS	5
RPV-VCK0400800NPABBIBO	1.1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F6, HF.	2
RPV-VCK0400800NPABBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F6, HF.	326
RPV-VCK0400800NPABBWINBO	1.1/2" CL 800 P CHECK VALVE.	WC. NPTF. SPRING ASSIST	A105N / F6, HF.	20
RPV-VCK0400800NPADDBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F316, HF.	130
RPV-VCK0400800NPADDBKNBO	1.1/2" CL 800 SW CHECK VALVE.	BC. NPTF.	A105N / F316, HF.	40

GATE VALVES

GLOBE VALVES

CHECK VALVES

WAFER CHECK VALVES

BALL VALVES

BUTTERFLY VALVES

Code	Item Description			Current Stock
RPV-VCK0400800NPADDBMNBO	1.1/2" CL 800 BALL CHECK VALVE	BC. NPTF. SPRING ASSIST	A105N / 316 / 316, HFS.	74
RPV-VCK0400800NPEDDBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F5 / F316, HF.	33
RPV-VCK0400800NPFDDBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F9 / F316, HF.	28
RPV-VCK0400800NPGDDBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F11 / F316, HF.	30
RPV-VCK0400800NPHDDBI*BO	1.1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F316L / F316, HF.	69
RPV-VCK0400800NPHDDBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F316L / F316, HF.	1
RPV-VCK0400800NPHDDBK*BO	1.1/2" CL 800 SW CHECK VALVE.	BC. NPTF.	A182 F316L / F316, HF.	20
RPV-VCK0400800NPHDDBKNB	1.1/2" CL 800 SW CHECK VALVE.	BC. NPTF.	A182 F316L / F316, HF.	6
RPV-VCK0400800NPJFFBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F304L / F304, HF.	8
RPV-VCK0400800NPLDDBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A350 LF2N / F316, HF.	37
RPV-VCK0400800NPSHHBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. NPTF.	A182 F321-H / F321, HF.	9
RPV-VCK0400800PL317BINBO	1 1/2" CL 800 P. CHECK VALVE, BC.	SPRING ASSIST. PLAIN END	A182 F317(L) / F317, HF	3
RPV-VCK0400800PL825BKNBO	1 1/2" CL 800 SW. CHECK VALVE.	BC. PLAIN END,	INC 825 / INC 825, HF	5
RPV-VCK0400800PLA20BINBO	1 1/2" CL 800 P. CHECK VALVE,	BC. SPRING ASSIST. PLAIN END	ALLOY 20 / ALLOY 20, HF	2
RPV-VCK0400800PLA20BKNBO	1 1/2" CL 800 SW. CHECK VALVE.	BC. PLAIN END,	ALLOY 20 / ALLOY 20, HF	5
RPV-VCK0400800PLEDDBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. PLAIN END. SPRING ASS	A182 F5 / F316, HF.	9
RPV-VCK0400800PLFDDBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. PLAIN END	A182 F9 / F316, HF	16
RPV-VCK0400800PLGDDBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. PLAIN END**	A182 F11 / F316, HF	10
RPV-VCK0400800PLHDDBI*BO	1.1/2" CL 800 P CHECK VALVE.	BC. PLAIN. SPRING ASSIST	A182 F316L / F316, HF.	15
RPV-VCK0400800PLHDDBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. PLAIN. SPRING ASSIST	A182 F316L / F316, HF.	6
RPV-VCK0400800PLHDDBKNB	1.1/2" CL 800 SW CHECK VALVE.	BC. PLAIN END	A182 F316L / F316, HF.	9
RPV-VCK0400800PLLDDBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. PLAIN END. SPRING ASSIST	A350 LF2N / F316, HF.	25
RPV-VCK0400800PLLDDBKNB	1 1/2" CL 800 SW. CHECK VALVE.	BC. PLAIN END (SCH 160 FB)	A350 LF2N / F316, HF.	14
RPV-VCK0400800PLSHHBINBO	1.1/2" CL 800 P CHECK VALVE.	BC. PLAIN END	A182 F321-H / F321, HF.	17
RPV-VCK0401500BWADDBINBO	1 1/2" CL1500 P CHECK VALVE.	BC. BW160. SPRING ASSIST	A105N / F316, HF	23
RPV-VCK0401500NPADDBINBO	1.1/2" CL1500 P.CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F316, HF.	49
RPV-VCK0401500NPHDDBI*BO	1.1/2" CL1500 P.CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F316L / F316, HF.	20
RPV-VCK0401500NPHDDBINBO	1.1/2" CL1500 P.CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F316L / F316, HF.	21
RPV-VCK0401500NPLDDBINBO	1.1/2" CL1500 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A350 LF2N / F316, HF.	10
RPV-VCK0401500PLADDBKNBO	1 1/2" CL1500 SW. CHECK VALVE.	BC. PLAIN END	A105N / F316, HF.	3
RPV-VCK0401500PLHDDBI*BO	1 1/2" CL1500 P CHECK VALVE.	BC. SPRING ASSIST. PLAIN END	A182 F316L / F316, HF.	10
RPV-VCK0401500PLHDDBINBO	1 1/2" CL1500 P CHECK VALVE.	BC. SPRING ASSIST. PLAIN END	A182 F316L / F316, HF.	1
RPV-VCK0401500PLHDDBLNB	1 1/2" CL1500 FB SW. CHECK VALVE.	BC, FULL BORE, PLAIN END	A182 F316(L) / F316, HF.	4
RPV-VCK0401500PLLDDBINBO	1.1/2" CL1500 P CHECK VALVE.	BC. SPRING ASSIST. PLAIN END	A350 LF2N / F316, HF.	5
RPV-VCK0401500PLLDDBLNB	1 1/2" CL1500 FB SW. CHECK VALVE.	BC, FULL BORE, PLAIN END	A350 LF2N / F316, HF.	5
RPV-VCK0401500PLNDDBKNB	1 1/2" CL1500 SW. CHECK VALVE.	BC. PLAIN END	A182 F22 / F316, HF.	2
RPV-VCK0401500PLVVVBINBO	1 1/2" CL1500 P.CHECK VALVE,	BC, PLAIN END SPRING ASS.	A182 F55 / F55, HF	5
RPV-VCK0401500UMADDBJNB	1.1/2" 1500UM P CHECK VALVE.	BC. FB. SPRING ASSISTED	A105N / F316, HF.	51
RPV-VCK0401500UMIDDBI*BO	1.1/2" 1500UM P CHECK VALVE.	BC. FULL BORE. SPRING	A182 F316 / F316, HF.	30
RPV-VCK0401500UMIDDBJNB	1.1/2" 1500UM P CHECK VALVE.	BC. FULL BORE. SPRING	A182 F316 / F316, HF.	2
RPV-VCK0401500UMIDDBL*BO	1 1/2" 1500UM SW. CHECK VALVE.	BC. FULL BORE.	A182 F316L / F316, HF.	6
RPV-VCK0401500UMLDDBINBO	1.1/2" 1500UM P CHECK VALVE.	BC. FULL BORE. SPRING	A350 LF2N / F316, HF.	62
RPV-VCK0401500UMLDDBLNB	1 1/2" 1500 UM SW. CHECK VALVE.	BC. FULL BORE.	A350 LF2N / F316, HF.	10
RPV-VCK0401500UMVVVBINBO	1 1/2" 1500 UM P. CHECK VALVE	BC, FULL BORE	A182 F55 / UNS S32760, HF	2
RPV-VCK0402500PLHDDBLNB	1 1/2" CL 2500 FB SW. CHECK VALVE,	BC, PLAIN END	A182 F316(L) / F316, HF	5
RPV-VCK0402500PLIDDBINBO	1 1/2" CL 2500 FB P.CHECK VALVE	BC, SPRING ASSISTED	A182 F316(L) / F316, HF	18
RPV-VCK0402500PLLDDBJNB	1.1/2" 2500 FB P CHECK VALVE	BC. PLAIN END. SPRING ASS	A350 LF2N / F316, HF	18
RPV-VCK0402500UMIDDBI*BO	1 1/2" 2500UM FB P CHECK VALVE	BC. SPRING ASSISTED.	A182 F316-L / F316, HF	1
RPV-VCK0402500UMIDDBLNB	1 1/2" 2500UM FB SW. CHECK VALVE	BC.	A182 F316-L / F316, HF	5
RPV-VCK0402500UMLDDBJNB	1.1/2" 2500UM FB P CHECK VALVE	BC. SPRING ASSISTED.	A350 LF2N / F316(L), HF	19
RPV-VCK040PN32NPBBK SH	1 1/2" PN32 SW. CHECK VALVE.	NPTF. UB	ASTM B148 C95800	8
RPV-VCK040PN32NPBBUI SH	1 1/2" PN32 P CHECK VALVE, UB	NPTF.	ASTM B148 C95800	38

GATE VALVES

GLOBE VALVES

CHECK VALVES

WAFER CHECK VALVES

BALL VALVES

BUTTERFLY VALVES

Code	Item Description			Current Stock
RPV-VCK0500150FFB8BBI SH	2" 150 FF PISTON CHECK VALVE.	BOLTED COVER	ASTM B148 C95800	12
RPV-VCK0500150FFB8BBI SH	2" 150 FF SW. CHECK VALVE	BC,	ASTM B148 C95800.	18
RPV-VCK0500150RF276BINBO	2" 150 RF P. CHECK VALVE.	BC. REDUCED BORE	HAS C276 / HAS C276, HF	1
RPV-VCK0500150RF276BLNBO	2" 150 RF FB SW CHECK VALVE.	BC. FULL BORE.	A494 CW12MW / HAS C276, HF	2
RPV-VCK0500150RFA20B NKI	2" 150 RF SW CHECK VALVE.	BC. ANSI B16.34. A-SERIES	ALLOY 20 / ALLOY 20	2
RPV-VCK0500150RFA20BKNNNE	2" 150 RF SW. CHECK VALVE	BC, REDUCED PORT	A351 CN7M / F20 STEM	2
RPV-VCK0500150RFA20BLNKI	2" 150 RF SW. CHECK VALVE	BC, BS 1868	A351 CN7M / CN7M, HF	2
RPV-VCK0500150RFADDBINBO	2" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF	69
RPV-VCK0500150RFCDDBL*KI	2" 150RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	50
RPV-VCK0500150RFCDDBLNKI	2" 150RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	4
RPV-VCK0500150RFDEEBLNPK	2" 150RF SW CHECK VALVE	BC. ANSI B16.34.	A351 CF8 / F304.	2
RPV-VCK0500150RFDFFB NKI	2" 150RF SW CHECK VALVE.	BC. ANSI B16.34.	A351 CF8 / F304, HF	18
RPV-VCK0500150RFHDDBI*BO	2" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F316(L) / F316, HF	40
RPV-VCK0500150RFHDDBINBO	2" 150RF P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F316(L) / F316, HF	15
RPV-VCK0500150RFHDDBL*BO	2" 150 RF SW. CHECK VALVE	BC, FULL BORE	A182 F316(L) / F316, HF	57
RPV-VCK0500150RFLDDBINBO	2" 150RF P CHECK VALVE.	BC. SPRING ASSIST. BS5352	A350 LF2N / F316, HF	35
RPV-VCK0500150RFLDDBLNBO	2" 150 RF SW. CHECK VALVE	BC, FULL BORE	A350 LF2N / F316, HF	37
RPV-VCK0500150RFPDDBL KI	2" 150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	46
RPV-VCK0500150RFQDDBLNKI	2" 150RF SW CHECK VALVE.	BC. FULL BORE. BS1868.	A217 C5 / F316, HF.	30
RPV-VCK0500150RFQDDBLNMA	2" 150RF SW CHECK VALVE.	BC. FULL BORE. BS1868.	A217 C5 / F316, HF.	3
RPV-VCK0500150RFSSHBLNBO	2" 150 RF SW. CHECK VALVE	BC, FULL BORE	A182 F321(H) / F321, HF	8
RPV-VCK0500150RFVVBINBO	2" 150 RF SW. CHECK VALVE	BC, FULL BORE	A182 F55 / UNS S32760, HF	17
RPV-VCK0500150RFWABBLNPK	2" 150UD SW CHECK VALVE.	BC. API600.	A216 WCB / F6, HFS.	1
RPV-VCK0500150RFWBBL KI	2" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF	76
RPV-VCK0500150RFWBBL~VA	2" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF	12
RPV-VCK0500150RFWDDBL KI	2" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	100
RPV-VCK0500150RFWDDBLNVA	2" 150RF SW CHECK VALVE.	BC.	A216 WCB / F316, HF	1
RPV-VCK0500150RFXDDBLNKI	2" 150RF SW CHECK VALVE.	BC. FULL BORE. BS1868.	A217 WC6 / F316, HF.	11
RPV-VCK0500300RFADDBINBO	2" 300RF P CHECK VALVE.	BC. SPRING ASSISTED.	A105N / F316, HF.	19
RPV-VCK0500300RFADDBLNBO	2" 300RF SW. CHECK VALVE	BC, FULL BORE	A105N / F316, HF	50
RPV-VCK0500300RFCCBLNMA	2" 300RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316.	3
RPV-VCK0500300RFCDDBL*KI	2" 300RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	25
RPV-VCK0500300RFCDDBLNKI	2" 300RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	31
RPV-VCK0500300RFDFFB NKI	2" 300 RF SW CHECK VALVE.	BC. ANSI B16.34	A351 CF8 / F304, HF	11
RPV-VCK0500300RFEDDBLNBO	2" 300RF SW. CHECK VALVE,	BC, FULL BORE	A182 F5 / F316(L), HF	10
RPV-VCK0500300RFHDDBI*BO	2" 300 RF P. CHECK VALVE,	BC,	A182 F316(L) / F316, HF	10
RPV-VCK0500300RFHDDBINBO	2" 300 RF P. CHECK VALVE,	BC,	A182 F316(L) / F316, HF	32
RPV-VCK0500300RFHDDBL*BO	2" 300 RF SW. CHECK VALVE	BC, FULL BORE	A182 F316(L) / F316, HF	43
RPV-VCK0500300RFLDDBINBO	2" 300RF P CHECK VALVE	BC.	A350 LF2N / F316, HF.	28
RPV-VCK0500300RFPDDBL KI	2" 300RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	73
RPV-VCK0500300RFPDDBLNMA	2" 300RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	10
RPV-VCK0500300RFQDDBLNKI	2" 300RF SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	23
RPV-VCK0500300RFQDDBLNMA	2" 300RF SW CHECK VALVE.	BC. FULL BORE. BS1868.	A217 C5 / F316, HF.	1
RPV-VCK0500300RFRDDBLNKI	2" 300 RF SW CHECK VALVE.	BC. BS 1868.	A217 C12 / F316, HF.	4
RPV-VCK0500300RFSHBLNBO	2" 300RF SW. CHECK VALVE	BC, FULL BORE	A182 F321(H) / F321, HF	22
RPV-VCK0500300RFWABBLNPK	2" 300UD SW CHECK VALVE.	BC. API600.	A216 WCB / F6, HFS.	3
RPV-VCK0500300RFWBBL KI	2" 300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	89
RPV-VCK0500300RFWBBL~VA	2" 300 RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF	10
RPV-VCK0500300RFWDDBL KI	2" 300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	49
RPV-VCK0500300RFWDDBLNMA	2" 300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	1
RPV-VCK0500300RFXDDBLNKI	2" 300RF SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	38
RPV-VCK0500300RFXDDBLNMA	2" 300RF SW CHECK VALVE.	BC. BS 1868. NON CE	A217 WC6 / F316, HF.	9

GATE VALVES

GLOBE VALVES

CHECK VALVES

WAFER CHECK VALVES

BALL VALVES

BUTTERFLY VALVES

Code	Item Description			Current Stock
RPV-VCK0500300UM625BLNBO	2" 300 UM SW. CHECK VALVE	BC, FULL BORE	A494 CW6MC / INC 625, HF	3
RPV-VCK0500300UMA20BLNBO	2" 300 UM SW. CHECK VALVE	BC, FULL BORE	ALLOY 20 / ALLOY 20, HF	5
RPV-VCK0500300UMEDDBLNBO	2" 300 UM SW. CHECK VALVE,	BC, FULL BORE	A182 F5 / F316(L), HF	28
RPV-VCK0500300UMFBBBLNBO	2" 300 UM SW. CHECK VALVE,	BC. FULL BORE	A182 F9 / F6, HF	4
RPV-VCK0500300UMFDDBLNBO	2" 300 UM SW. CHECK VALVE,	BC, FULL BORE	A182 F9 / F316, HF	8
RPV-VCK0500300UMHDDBINBO	2" 300 UM P. CHECK VALVE,	BC,	A182 F316(L) / F316, HF	5
RPV-VCK0500300UMHDDBLNBO	2" 300 UM SW. CHECK VALVE	BC, FULL BORE	A182 F316(L) / F316, HF	10
RPV-VCK0500300UMLDDBLNBO	2" 300 UM FB SW. CHECK VALVE,	BC, FULL BORE	A350 LF2N / F316, HF	5
RPV-VCK0500300UMMLLBNBO	2" 300 UM SW.CHECK VALVE.	BC. PTFE GASKET	MONEL 400 / MONEL 400	2
RPV-VCK0500300UMSHHBLNBO	2" 300 UM SW. CHECK VALVE	BC, FULL BORE	A182 F321(H) / F321, HF	5
RPV-VCK0500300UMVVVBLNBO	2" 300 UM SW. CHECK VALVE	BC, FULL BORE	A182 F55 / UNS S32760, HF	14
RPV-VCK0500300UMWLLBL*VA	2" 300 UM SW CHECK VALVE.	BC. BS 1868.	A216 WCB / MONEL	2
RPV-VCK0500600BWWDDBLNKI	2" CL 600 SW CHECK VALVE.	BC. BW 80.	A216 WCB / F316, HF.	10
RPV-VCK0500600BWWDDBLNNE	2" CL 600 SW CHECK VALVE.	BC. BW 80.	A216 WCB / F316, HF.	10
RPV-VCK0500600BWXDDBLNKI	2" CL 600 SW CHECK VALVE.	BC. BW 80.	A217 WC6 / F316, HF.	3
RPV-VCK0500600RFPDDBLNMA	2" 600RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	4
RPV-VCK0500600RFWBBBL KI	2" 600RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF	51
RPV-VCK0500600RFWDDBL KI	2" 600RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	39
RPV-VCK0500600UMADDBKNBO	2" 600UM SW CHECK VALVE.	BC.	A105N / F316, HF.	22
RPV-VCK0500600UMCDDBL*KI	2" 600UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	19
RPV-VCK0500600UMEDDBLNBO	2" 600 UM SW. CHECK VALVE,	BC, FULL BORE	A182 F5 / F316, HF	8
RPV-VCK0500600UMFBBBLNBO	2" 600 UM SW. CHECK VALVE,	BC. FULL BORE	A182 F9 / F6, HF	4
RPV-VCK0500600UMFDDBLNBO	2" 600 UM SW. CHECK VALVE,	BC, FULL BORE	A182 F9 / F316, HF	10
RPV-VCK0500600UMGDDBLNBO	2" 600 UM SW. CHECK VALVE,	BC, FULL BORE	A182 F11 / F316, HF	14
RPV-VCK0500600UMHDDBI*BO	2" 600UM P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F316(L) / F316, HF.	10
RPV-VCK0500600UMHDDBINBO	2" 600UM P CHECK VALVE.	BC. SPRING ASSISTED.	A182 F316(L) / F316, HF.	4
RPV-VCK0500600UMHDDBL*BO	2" 600 UM SW. CHECK VALVE,	BC, FULL BORE	A182 F316(L) / F316, HF	10
RPV-VCK0500600UMHDDBLNBO	2" 600 UM SW. CHECK VALVE,	BC, FULL BORE	A182 F316(L) / F316, HF	14
RPV-VCK0500600UMLDDBINBO	2" 600UM P CHECK VALVE.	BC. SPRING ASSISTED.	A350 LF2N / F316, HF.	26
RPV-VCK0500600UMLDDBLNBO	2" 600 UM SW. CHECK VALVE,	BC, FULL BORE	A350 LF2N / F316, HF	35
RPV-VCK0500600UMPDDBL KI	2" 600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	22
RPV-VCK0500600UMPDDBLNMA	2" 600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	5
RPV-VCK0500600UMSHHBLNBO	2" 600 UM SW. CHECK VALVE,	BC, FULL BORE	A182 F321-H / F321, HF	25
RPV-VCK0500600UMTHHBLNKI	2" 600UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8C / F321, HF.	6
RPV-VCK0500600UMVVVBLNBO	2" 600 UM SW. CHECK VALVE	BC, FULL BORE	A182 F55 / UNS S32760, HF	16
RPV-VCK0500600UMWBBBL KI	2" 600UM SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	78
RPV-VCK0500600UMWBBBL~VA	2" 600UM SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	8
RPV-VCK0500600UMWDDBL KI	2" 600UM SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	54
RPV-VCK0500600UMXDDBLNKI	2" 600UM SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	9
RPV-VCK0500800BWADDBINBO	2" CL 800 P. CHECK VALVE.	BC. BW80. SPRING ASSIST	A105N / F316, HF	20
RPV-VCK0500800BWADDBLNBO	2" CL 800 SW CHECK VALVE.	BC. FULL BORE, BW 80.	A105N / F316, HF	11
RPV-VCK0500800NPABBWINBO	2" CL 800 P.CHECK VALVE.	WC. NPTF. SPRING ASSIST	A105N / F6, HF.	21
RPV-VCK0500800NPADDBINBO	2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A105N / F316, HF	141
RPV-VCK0500800NPADDBKNBO	2" CL 800 SW CHECK VALVE.	BC. NPTF.	A105N / F316, HF	37
RPV-VCK0500800NPADDBLNBO	2" CL 800 SW CHECK VALVE.	BC. FULL BORE, NPTF.	A105N / F316, HF	22
RPV-VCK0500800NPHDDBINBO	2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A182 F316L / F316, HF.	50
RPV-VCK0500800NPLDDBINBO	2" CL 800 P CHECK VALVE.	BC. NPTF. SPRING ASSIST	A350 LF2N / F316, HF.	24
RPV-VCK0500800NPLDDBKNBO	2" CL 800 SW. CHECK VALVE.	BC. NPTF.	A350 LF2N / F316, HF	15
RPV-VCK0500800PLA20BLNBO	2" CL 800 FB SW. CHECK VALVE.	BC. PLAIN END,	ALLOY 20 / ALLOY 20, HF	5
RPV-VCK0500800PLADDBLNBO	2" CL 800 SW CHECK VALVE.	BC. FULL BORE, PLAIN END	A105N / F316, HF	5
RPV-VCK0500800PLFDDBLNBO	2" CL 800 SW CHECK VALVE.	BC. FULL BORE, PLAIN END	A182 F9 / F316, HF	4
RPV-VCK0500800PLGDDBLNBO	2" CL 800 SW CHECK VALVE.	BC. FULL BORE, PLAIN	A182 F11 / F316, HF	7

GATE VALVES

GLOBE VALVES

CHECK VALVES

WAFER CHECK VALVES

BALL VALVES

BUTTERFLY VALVES

Code	Item Description			Current Stock
RPV-VCK0500800PLHDDBLNBO	2" CL 800 SW CHECK VALVE.	BC. FULL BORE, PLAIN END	A182 F316(L) / F316, HF	36
RPV-VCK0500800PLDDBLNBO	2" CL 800 SW CHECK VALVE.	BC. FULL BORE, PLAIN END	A350 LF2N / F316, HF	4
RPV-VCK0500800PLMLLBJNBO	2" CL 800 FB P.CHECK VALVE.	BC. SPRING ASSIST.	MONEL 400 / MONEL 400, HF	2
RPV-VCK0500800SWACDBMNBO	2" CL 800 BALL CHECK VALVE.	BC. S/WELD. SPRING ASSIST	A105N / F316 / F316, HFS	1
RPV-VCK0500800SWHDDBINBO	2" CL 800 P CHECK VALVE.	BC. S/WELD SPRING ASSIST	A182 F316L / F316, HF.	1
RPV-VCK0501500BWADDBL BO	2" CL 1500 SW CHECK VALVE.	BC. FULL BORE. BW XS	A105N / F316, HF.	1
RPV-VCK0501500BWADDBLNBO	2" CL 1500 SW CHECK VALVE.	BC. FULL BORE. BW 160	A105N / F316, HF.	22
RPV-VCK0501500BWADDBLNBO	2" CL 1500 PSB SW CHECK	VALVE, BW SCH 160	A105N / F316, HF	22
RPV-VCK0501500BWNDDBLNBO	2" CL 1500 PSB SW CHECK	VALVE, FB, BW SCH XXS	A182 F22 / F316, HF	4
RPV-VCK0501500NPADDBINBO	2" CL 1500 P. CHECK VALVE	BC. NPTF. SPRING ASSIST	A105N / F316, HF	26
RPV-VCK0501500NPLDDBINBO	2" CL 1500 P. CHECK VALVE	BC. NPTF	A350 LF2N / F316, HF	29
RPV-VCK0501500PLHDDBINBO	2" CL1500 P CHECK VALVE.	BC. SPRING ASSIST. PLAIN END	A182 F316L / F316, HF.	10
RPV-VCK0501500PLHDDBLNBO	2" CL1500 FB SW. CHECK VALVE.	BC, FULL BORE, PLAIN END	A182 F316(L) / F316, HF.	3
RPV-VCK0501500PLDDBINBO	2" CL 1500 P. CHECK VALVE	BC. PLAIN END	A350 LF2N / F316, HF	20
RPV-VCK0501500PLDDBLNBO	2" CL1500 FB SW. CHECK VALVE.	BC, FULL BORE, PLAIN END	A350 LF2N / F316, HF.	13
RPV-VCK0501500UMADDBINBO	2" 1500UM P CHECK VALVE.	BC. FB. SPRING ASSISTED	A105N / F316, HF.	45
RPV-VCK0501500UMGDDBLNBO	2" 1500UM SW CHECK VALVE.	BC. FULL BORE.	A182 F11 / F316, HF.	5
RPV-VCK0501500UMHDDBINBO	2" 1500UM SW CHECK VALVE.	BC. FULL BORE.	A182 F316(L) / F316, HF	23
RPV-VCK0501500UMHDDBK*BO	2" 1500UM SW CHECK VALVE.	BC. FULL BORE.	A182 F316(L) / F316, HF	50
RPV-VCK0501500UMIDDBJ*BO	2" 1500UM P CHECK VALVE.	BC. FB. SPRING ASSISTED	A182 F316(L) / F316, HF.	20
RPV-VCK0501500UMIDDBINBO	2" 1500UM P CHECK VALVE.	BC. FB. SPRING ASSISTED	A182 F316(L) / F316, HF.	9
RPV-VCK0501500UMLDDBLNBO	2" 1500UM SW CHECK VALVE.	BC. FULL BORE.	A350 LF2N / F316, HF.	65
RPV-VCK0501500UMSHHBLNBO	2" 1500UM SW CHECK VALVE.	BC. FULL BORE.	A182 F321(H) / F321, HF	14
RPV-VCK0501500UMVVVBLNBO	2" 1500 UM SW. CHECK VALVE	BC, FULL BORE	A182 F55 / UNS S32760, HF	33
RPV-VCK0502500BWADDBLNBO	2" CL 2500 PSB SW CHECK	VALVE, BW SCH XXS	A105N / F316, HF	19
RPV-VCK0502500BWF91PLNBO	2" CL 2500 PSB SW CHECK	VALVE, BW SCH XXS	A182 F91 / F316, HF	4
RPV-VCK0502500BWNBBPL VE	2" CL2500 SW CHECK VALVE.	PSB. BW XXS.	A182 F22 / F6, HF.	1
RPV-VCK0502500BWNDDBLNBO	2" CL 2500 PSB SW CHECK	VALVE, BW SCH XXS	A182 F22 / F316, HF	4
RPV-VCK0502500PLHDDBLNBO	2" CL 2500 FB SW. CHECK VALVE,	BC, PLAIN END	A182 F316(L) / F316, HF	5
RPV-VCK0502500UMLDDBLNBO	2" 2500UM SW CHECK VALVE.	BC. FULL BORE.	A350 LF2N / F316, HF.	22
RPV-VCK0502500UMSHHBLNBO	2" 2500 UM P. CHECK VALVE.	BC. FULL BORE.	A182 F321(H) / F321, HF	2
RPV-VCK0502500UMSHHBLNBO	2" 2500UM SW CHECK VALVE.	BC. FULL BORE.	A182 F321(H) / F321, HF	5
RPV-VCK0502500UMVVVBLNBO	2" 2500UM SW CHECK VALVE	BC. FULL BORE	A182 F55 / UNS S32760, HF	5
RPV-VCK050PN16FFBBSBI SH	2" PN16 150 PISTON CHECK VALVE	BC,	BS1400 LG2 GUNMETAL BODY	1
RPV-VCK050PN32NPBBBUI SH	2" PN50 P. CHECK VALVE,	UB, RS, NPT.	B148 C95800 ALI BRONZE	15
RPV-VCK050PN32NPBBBUK SH	2" PN 32 SW. CHECK VALVE,	UB, NPT.	B148 C95800 ALI BRONZE	10
RPV-VCK0650150UDCDDB *KI	2.1/2" 150UD SW CHECK VALVE.	BC. ANSI B16.34	A351 CF8M / F316, HF	15
RPV-VCK0650150UDCDDB NKI	2.1/2" 150UD SW CHECK VALVE.	BC. ANSI B16.34	A351 CF8M / F316, HF	2
RPV-VCK0650150UDWBBBLNBO	2.1/2" 150 UD SW. CHECK VALVE,	BC. BS 1868	A216 WCB / F6, HF	10
RPV-VCK0652500BWADDBLNBO	2 1/2" CL 2500 PSB SW CHECK	VALVE, BW SCH XXS	A105N / F316, HF	1
RPV-VCK0800150FFBBSBK SH	3" 150 FF SW. CHECK VALVE	BC,	ASTM B148 C95800.	11
RPV-VCK0800150RF276BK SH	3" 150 RF SW. CHECK VALVE	BC, BS 1868	HAST A494 CW12MW	1
RPV-VCK0800150RFCCDBLNPK	3" 150RF SW CHECK VALVE.	BC. ANSI B16.34.	A351 CF8M / F316, HFS.	1
RPV-VCK0800150RFCCDB NKI	3" 150RF SW CHECK VALVE.	BC. B16.34	A351 CF8M / F316, HF	23
RPV-VCK0800150RFCCDBL*KI	3" 150RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	39
RPV-VCK0800150RFPCCDBLNMA	3" 150RF SW CHECK VALVE.	BC. FULL BORE.	A352 LCC / F316, HFS.	2
RPV-VCK0800150RFPDDBL KI	3" 150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	48
RPV-VCK0800150RFPDDBLNMA	3" 150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	8
RPV-VCK0800150RFQDDBLNKI	3" 150RF SW CHECK VALVE.	BC. FULL BORE. BS1868	A217 C5 / F316, HF.	25
RPV-VCK0800150RFQDDBLNMA	3" 150RF SW CHECK VALVE.	BC. FULL BORE. BS1868	A217 C5 / F316, HF.	1
RPV-VCK0800150RFRBBSL*VA	3" 150 RF SW. CHECK VALVE,	BC, NDT	A217 C12 / F6 HF.	2
RPV-VCK0800150RFTHHBL*VA	3" 150RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8C / F321, HF.	4

GATE VALVES

GLOBE VALVES

CHECK VALVES

WAFER CHECK VALVES

BALL VALVES

BUTTERFLY VALVES

Code	Item Description			Current Stock
RPV-VCK0800150RFTHHBLNKI	3" 150RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8C / F321, HF.	8
RPV-VCK0800150RFVVVBLNVA	3" 150 RF SW.CHECK VALVE,	BC, API 600	ASTM A995 6A / F55, HF	2
RPV-VCK0800150RFWBBBL KI	3" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	29
RPV-VCK0800150RFWBBBL~VA	3" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF	10
RPV-VCK0800150RFWDDBL KI	3" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	34
RPV-VCK0800150RFWLLBL*VA	3" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / MONEL	4
RPV-VCK0800150RFXDDBLNKI	3" 150RF SW CHECK VALVE.	BC. BS1868	A217 WC6 / F316, HF	19
RPV-VCK0800150RFXDDBLNMA	3" 150RF SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	2
RPV-VCK0800300BWWDDBLNKI	3" CL 300 SW CHECK VALVE.	BC. BW 80.	A216 WCB / F316, HF	9
RPV-VCK0800300RFCCLBLNPK	3" 300RF SW CHECK VALVE	BC. ANSI B16.34.	A351 CF8M / F316.	1
RPV-VCK0800300RFCDDBL NKI	3" 300 RF SW CHECK VALVE.	BC. ANSI B16.34	A351 CF8M / F316, HF	5
RPV-VCK0800300RFCDDBL*KI	3" 300RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	5
RPV-VCK0800300RFCDDBLNKI	3" 300RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	6
RPV-VCK0800300RFDFFB NKI	3" 300 RF SW CHECK VALVE.	BC. ANSI B16.34	A351 CF8 / F304, HF	6
RPV-VCK0800300RFPDDBL KI	3" 300RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	49
RPV-VCK0800300RFQDDBLNKI	3" 300RF SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	11
RPV-VCK0800300RFTHHBLNKI	3" 300RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8C / F321, HF.	11
RPV-VCK0800300RFWABBLNPK	3" 300 UD SW CHECK VALVE.	BC. API 600	A216 WCB / F6, HFS	1
RPV-VCK0800300RFWBBBL KI	3" 300 RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF	34
RPV-VCK0800300RFWBBBL~VA	3" 300 RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF	6
RPV-VCK0800300RFWDDBL KI	3" 300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	28
RPV-VCK0800300RFWLLBD*VA	3" 300 RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / MONEL	3
RPV-VCK0800300RFXDDBLNKI	3" 300RF SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	14
RPV-VCK0800300UMCDDBL*KI	3" 300RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	10
RPV-VCK0800300UMPDDBL KI	3" 300 UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	10
RPV-VCK0800300UMQDDBLNVA	3" 300 UM SW CHECK VALVE,	BC, NDT	A217 C5 / F316, HF	14
RPV-VCK0800300UMRBBBL*VA	3" 300 UM SW. CHECK VALVE,	BC, NDT	A217 C12 / F6 HF.	4
RPV-VCK0800300UMVVVBL*VA	3" 300 UM SW. CHECK VALVE,	BC,	ASTM A995 6A / F55, HF	3
RPV-VCK0800600BWWDDBLNKI	3" CL 600 SW CHECK VALVE.	BC. BW 80.	A216 WCB / F316, HF	21
RPV-VCK0800600BWWDDBLNNE	3" CL 600 SW CHECK VALVE.	BC. BW 80.	A216 WCB / F316, HF	10
RPV-VCK0800600BWXDDBLNKI	3" CL 600 SW CHECK VALVE.	BC. BW 80.	A217 WC6 / F316, HF.	10
RPV-VCK0800600RFCDDBLNPK	3" 600 RF SW CHECK VALVE.	BC. ANSI B16.34.	A351 CF8M / F316, HF	1
RPV-VCK0800600RFPDDBL KI	3" 600 RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	2
RPV-VCK0800600RFPDDBLNMA	3" 600RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	3
RPV-VCK0800600RFWBBBL KI	3" 600 RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF	8
RPV-VCK0800600RFWDDBL KI	3" 600RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	8
RPV-VCK0800600UMCDDBLNKI	3" 600UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	11
RPV-VCK0800600UMDFBLNPK	3" 600UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8 / F304, HF.	3
RPV-VCK0800600UMPDDBL KI	3" 600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	15
RPV-VCK0800600UMPDDBLNMA	3" 600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	1
RPV-VCK0800600UMQDDBLNKI	3" 600UM SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	13
RPV-VCK0800600UMQDDBLNVA	3" 600UM SW CHECK VALVE.	BC. ASME B16.10	A217 C5 / F316, HF	2
RPV-VCK0800600UMRBBBL*VA	3" 600 UM SW. CHECK VALVE,	BC. NDT	A217 C12 / F6 HF.	2
RPV-VCK0800600UMTHHBLNKI	3" 600UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8C / F321, HF.	7
RPV-VCK0800600UMVVVBL*VA	3" 600 UM SW. CHECK VALVE,	BC,	ASTM A995 6A / F55, HF	3
RPV-VCK0800600UMWBBBL KI	3" 600UM SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF	23
RPV-VCK0800600UMWBBBL~VA	3" 600UM SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	4
RPV-VCK0800600UMWDDBL KI	3" 600UM SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	18
RPV-VCK0800600UMXDDBLNKI	3" 600UM SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	12
RPV-VCK0800600UMXDDBLNMA	3" 600UM SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	2
RPV-VCK0800600UMXDDBLNVA	3" 600UM SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF	6
RPV-VCK0800900UMCDDBLNKI	3" 900UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF	3

GATE VALVES

GLOBE VALVES

CHECK VALVES

WAFER CHECK VALVES

BALL VALVES

BUTTERFLY VALVES

Code	Item Description			Current Stock
RPV-VCK0800900UMNDDBLNPK	3" 900UM SW CHECK VALVE.	BC. NDT.	A217 WC9 / F316, HF.	3
RPV-VCK0800900UMPDDBLNKI	3" 900UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	17
RPV-VCK0800900UMRDBDLNPK	3" 900UM SW CHECK VALVE.	BC. NDT.	A217 C12 / F316, HF.	3
RPV-VCK0800900UMTYBYLNVA	3" 900UM SW CHECK VALVE.	BC. BS 1868. NDT	A351 CF8C / F347, HF	3
RPV-VCK0801500BWADDPLNBO	3" 1500 SW. CHECK VALVE	PSB, BW 160.	A105N / F316, HF	17
RPV-VCK0801500BWF91PLNBO	3" 1500 SW. CHECK VALVE	PSB, BW XXS	A182 F91 / F316, HF	3
RPV-VCK0801500BWNDDPLNBO	3" 1500 SW. CHECK VALVE	PSB, BW XXS	A182 F22 / F316, HF	8
RPV-VCK0801500UMCDDBLNKI	3" 1500UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF	1
RPV-VCK0801500UMNDDBLNPK	3" 1500UM SW CHECK VALVE.	BC. NDT.	A217 WC9 / F316, HF.	1
RPV-VCK0801500UMPDDBLNKI	3" 1500UM SW CHECK VALVE.	BC. BS1868	A352 LCC / F316, HF.	14
RPV-VCK0801500UMRBBBL*VA	3" 1500 UM SW. CHECK VALVE,	BC, NDT	A217 C12 / F6 HF.	3
RPV-VCK0801500UMTYBYLNVA	3" 1500UM SW CHECK VALVE.	BC. BS 1868. NDT	A351 CF8C / F347, HF	3
RPV-VCK0802500BWADDPCNBO	3" CL2500 SW CHECK VALVE.	PSB. BW XXS.	A105N / F316, HF	5
RPV-VCK0802500BWF91PLNBO	3" 2500 SW. CHECK VALVE	PSB, BW XXS	A182 F91 / F316, HF	7
RPV-VCK0802500BWNDDPLNBO	3" CL2500 SW CHECK VALVE.	PSB. BW XXS.	A182 F22 / F316, HF	1
RPV-VCK0802500UMPCDPLNVA	3" 2500 UM PSB SW CHECK VALVE.	BS 1868		4
RPV-VCK0802500UMPDPLNVA	3" 2500 UM PSB SW CHECK VALVE.	BS 1868		1
RPV-VCK1000150FFBDBBK SH	4" 150 FF SW. CHECK VALVE	BC,	ASTM B148 C95800.	9
RPV-VCK1000150RFCCDBLNPK	4" 150RF SW CHECK VALVE.	BC. ANSI B16.34.	A351 CF8M / F316, HFS.	4
RPV-VCK1000150RFCDDBL*KI	4" 150RF SW CHECK VALVE.	BC. BS1868.	A351 CF8M / F316, HF.	10
RPV-VCK1000150RFCDDBLNKI	4" 150RF SW CHECK VALVE.	BC. BS1868.	A351 CF8M / F316, HF.	8
RPV-VCK1000150RFCDDBLNMA	4" 150RF SW CHECK VALVE.	BC. BS1868. NOT CE	A351 CF8M / F316, HF.	1
RPV-VCK1000150RFDFFB NKI	4" 150 RF SW CHECK VALVE.	BC. ANSI B16.34	A351 CF8 / F304, HF	1
RPV-VCK1000150RFPDDBLNMA	4" 150RF SW CHECK VALVE.	BC. FULL BORE.	A352 LCC / F316, HFS.	9
RPV-VCK1000150RFPDDBL KI	4" 150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	35
RPV-VCK1000150RFQDDBLNKI	4" 150RF SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	25
RPV-VCK1000150RFQDDBLNMA	4" 150RF SW CHECK VALVE.	BC. FULL BORE. BS1868.	A217 C5 / F316, HF.	1
RPV-VCK1000150RFRDDBLNKI	4" 150RF SW CHECK VALVE.	BC. BS 1868.	A217 C12 / F316, HF.	7
RPV-VCK1000150RFTHHBL*VA	4" 150 RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8C / F321, HF.	7
RPV-VCK1000150RFTHHBLNKI	4" 150 RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8C / F321, HF.	5
RPV-VCK1000150RFVVBVNVA	4" 150 RF SW.CHECK VALVE,	BC, API 600	ASTM A995 6A / F55, HF	2
RPV-VCK1000150RFWBDBL KI	4" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	35
RPV-VCK1000150RFWBDBL~VA	4" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF	8
RPV-VCK1000150RFWDDBL KI	4" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	36
RPV-VCK1000150RFXDDBLNKI	4" 150RF SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	20
RPV-VCK1000300BWWBDBLNPK	4" CL 300 SW CHECK VALVE.	BC. BW 80.	A216 WCB / F6, HF.	2
RPV-VCK1000300BWWDDBLNKI	4" CL 300 SW CHECK VALVE.	BC. BW 80	A216 WCB / F316, HF	2
RPV-VCK1000300BWWDDBLNVE	4" CL 300 SW CHECK VALVE.	BC. BW 80	A216 WCB / F316, HF.	3
RPV-VCK1000300RFCCDBLNPK	4" 300RF SW CHECK VALVE	BC. ANSI B16.34.	A351 CF8M / F316.	9
RPV-VCK1000300RFCDDBL*KI	4" 300RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	5
RPV-VCK1000300RDEFDBLNPK	4" 300RF SW CHECK VALVE.	BC. ANSI B16.34.	A351 CF8 / F304, HFS.	2
RPV-VCK1000300RFDFFB NKI	4" 300RF SW CHECK VALVE	BC. ANSI B16.34.	A351 CF8 / F304, HF	10
RPV-VCK1000300RFPDDBL KI	4" 300RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	24
RPV-VCK1000300RFQDDBLNKI	4" 300RF SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	23
RPV-VCK1000300RFTHHBLNKI	4" 300RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8C / F321, HF.	10
RPV-VCK1000300RFWABDBLNPK	4" 300UD SW CHECK VALVE.	BC. API600.	A216 WCB / F6, HFS.	1
RPV-VCK1000300RFWBDBL KI	4" 300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF	13
RPV-VCK1000300RFWBDBL~VA	4" 300 RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF	4
RPV-VCK1000300RFWBDBLNMA	4" 300RF SW CHECK VALVE.	BC. BS1868.	A216 WCB / F6, HF.	5
RPV-VCK1000300RFWDDBL KI	4" 300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	15
RPV-VCK1000300RFXDDBLNKI	4" 300RF SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	19
RPV-VCK1000300UMCDDBL*KI	4" 300 UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	5

GATE VALVES

GLOBE VALVES

CHECK VALVES

WAFER CHECK VALVES

BALL VALVES

BUTTERFLY VALVES

Code	Item Description			Current Stock
RPV-VCK1000300UMCDDBL*VA	4" 300 UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	5
RPV-VCK1000300UMQDDBLNVA	4" 300 UM SW CHECK VALVE,	BC, NDT	A217 C5 / F316, HF	3
RPV-VCK1000300UMRBBBL*VA	4" 300 UM SW. CHECK VALVE,	BC, NDT	A217 C12 / F6 HF.	6
RPV-VCK1000300UMVVVBL*VA	4" 300 UM SW. CHECK VALVE,	BC,	ASTM A995 6A / F55, HF	3
RPV-VCK1000600BWWBBLNPK	4" CL 600 SW CHECK VALVE.	BC. BW 80.	A216 WCB / F6, HF.	2
RPV-VCK1000600BWWDBLNKI	4" CL 600 SW CHECK VALVE.	BC. BW 80.	A216 WCB / F316, HF.	15
RPV-VCK1000600BWXDDBLNKI	4" CL 600 SW CHECK VALVE.	BC. BW 80.	A217 WC6 / F316, HF	2
RPV-VCK1000600RFWBBBL KI	4" 600RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF	12
RPV-VCK1000600RFWDDBL KI	4" 600 RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	2
RPV-VCK1000600RFWDDBLNKI	4" 600RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	2
RPV-VCK1000600UMCDDBLNKI	4" 600UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	6
RPV-VCK1000600UMDFFB NKI	4" 600UM SW CHECK VALVE.	BC. B16.34	A351 CF8 / F304, HF	5
RPV-VCK1000600UMDFFBLNPK	4" 600UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8 / F304, HF.	2
RPV-VCK1000600UMPDDBL KI	4" 600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	13
RPV-VCK1000600UMQDDBLNKI	4" 600UM SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF	4
RPV-VCK1000600UMQDDBLNVA	4" 600UM SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF	6
RPV-VCK1000600UMRBBBL*VA	4" 600 UM SW. CHECK VALVE,	BC, NDT	A217 C12 / F6 HF.	2
RPV-VCK1000600UMTYBYLNVA	4" 600 UM SW CHECK VALVE,	BC, NDT.	A351 CF8C / NIT 50 / F347, HF	2
RPV-VCK1000600UMVVVBL*VA	4" 600 UM SW. CHECK VALVE,	BC,	ASTM A995 6A / F55, HF	3
RPV-VCK1000600UMWBBBL KI	4" 600UM SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	5
RPV-VCK1000600UMWBBBL~VA	4" 600UM SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	2
RPV-VCK1000600UMWDBLNKI	4" 600UM SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	6
RPV-VCK1000600UMXDDBLNKI	4" 600UM SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	5
RPV-VCK1000600UMXDDBLNVA	4" 600UM SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF	6
RPV-VCK1000900UMCDDBLNKI	4" 900UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF	3
RPV-VCK1000900UMNDDBLNPK	4" 900UM SW CHECK VALVE.	BC. NDT.	A217 WC9 / F316, HF.	2
RPV-VCK1000900UMPDDBL*VA	4" 900UM SW CHECK VALVE.	BC. BS 1868. NDT	A352 LCC / F316, HF.	4
RPV-VCK1000900UMPDDBLNKI	4" 900UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	7
RPV-VCK1000900UMPDDBLNPK	4" 900UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	3
RPV-VCK1000900UMRDDBLNKI	4" 900UM SW CHECK VALVE.	BC.	A217 C12 / F316, HF.	3
RPV-VCK1000900UMRDDBLNPK	4" 900UM SW CHECK VALVE.	BC. NDT.	A217 C12 / F316, HF.	1
RPV-VCK1000900UMTHHBLNKI	4" 900UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8C / F321, HF	3
RPV-VCK1000900UMTYBYLNVA	4" 900UM SW CHECK VALVE.	BC. BS 1868. NDT	A351 CF8C / F347, HF	3
RPV-VCK1001500BWADDPNBO	4" 1500 SW. CHECK VALVE	PSB, BW 160.	A105N / F316, HF	55
RPV-VCK1001500BWNDDPNBO	4" 1500 SW. CHECK VALVE	PSB, BW 160.	A182 F22 / F316, HF	5
RPV-VCK1001500UMCDDBLNKI	4" 1500UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF	3
RPV-VCK1001500UMNDDBLNPK	4" 1500UM SW CHECK VALVE.	BC. NDT.	A217 WC9 / F316, HF.	2
RPV-VCK1001500UMPDDBLNKI	4" 1500UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	7
RPV-VCK1001500UMPDDBLNPK	4" 1500UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	3
RPV-VCK1001500UMRDDBLNPK	4" 1500UM SW CHECK VALVE.	BC. NDT.	A217 C12 / F316, HF.	3
RPV-VCK1001500UMTYBYLNVA	4" 1500UM SW CHECK VALVE.	BC. BS 1868. NDT	A351 CF8C / F347, HF	3
RPV-VCK1002500BWADDPNBO	4" CL2500 SW CHECK VALVE.	PSB. BW XXS.	A105N / F316, HF	6
RPV-VCK1002500BWF91PLNBO	4" 2500 SW. CHECK VALVE	PSB, BW XXS	A182 F91 / F316, HF	4
RPV-VCK1002500BWNBBPL VE	4" CL2500 SW CHECK VALVE.	PSB. BW XXS.	A182 F22 / F6, HF.	2
RPV-VCK1002500UMPDCLNVA	4" 2500 UM PSB SW CHECK VALVE.	BS 1868		2
RPV-VCK1002500UMPDPLNVA	4" 2500 UM PSB SW CHECK VALVE.	BS 1868		3
RPV-VCK1500150FFBBBBK SH	6" 150 FF SW. CHECK VALVE	BC,	ASTM B148 C95800.	5
RPV-VCK1500150RFCCBLNPK	6" 150RF SW CHECK VALVE	BC. ANSI B16.34.	A351 CF8M / F316.	8
RPV-VCK1500150RFCDDBL*KI	6" 150RF SW CHECK VALVE	BC. BS 1868.	A351 CF8M / F316, HF.	10
RPV-VCK1500150RFCDDBLNKI	6" 150RF SW CHECK VALVE	BC. BS 1868.	A351 CF8M / F316, HF.	10
RPV-VCK1500150RFDFFB NKI	6" 150RF SW CHECK VALVE	BC. B16.34	A351 CF8 / F304, HF	5
RPV-VCK1500150RFPDDBLNMA	6" 150RF SW CHECK VALVE.	BC. FULL BORE.	A352 LCC / F316, HFS.	7

GATE VALVES

GLOBE VALVES

CHECK VALVES

WAFER CHECK VALVES

BALL VALVES

BUTTERFLY VALVES

Code	Item Description			Current Stock
RPV-VCK1500150RFPDDBL KI	6" 150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	13
RPV-VCK1500150RFPDDBLNMA	6" 150RF SW CHECK VALVE.	BC. FULL BORE.	A352 LCC / F316, HF.	7
RPV-VCK1500150RFQDDBLNKI	6" 150RF SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	5
RPV-VCK1500150RFTHHBLNKI	6" 150RF SW CHECK VALVE	BC. BS 1868.	A351 CF8C / F321, HF.	2
RPV-VCK1500150RFWBBL KI	6" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	17
RPV-VCK1500150RFWBBL~VA	6" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF	6
RPV-VCK1500150RFWDDBL KI	6" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	17
RPV-VCK1500300BWWDDBLNKI	6" CL 300 SW CHECK VALVE.	BC. BS 1868. BW 80 ENDS	A216 WCB / F316, HF	7
RPV-VCK1500300RFCDDBLNKI	6" 300RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	7
RPV-VCK1500300RFEFBLNPK	6" 300RF SW CHECK VALVE.	BC. ANSI B16.34.	A351 CF8 / F304, HFS.	1
RPV-VCK1500300RFPDDBL KI	6" 300RF SW CHECK VALVE	BC. BS 1868.	A352 LCC / F316, HF	13
RPV-VCK1500300RFQDDBLNKI	6" 300RF SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	11
RPV-VCK1500300RFRHHBLNKI	6" 300RF SW CHECK VALVE.	BC. BS 1868.	A217 C12 / F321, HF	5
RPV-VCK1500300RFTHHBLNKI	6" 300RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8C / F321, HF.	6
RPV-VCK1500300RFWBBL KI	6" 300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	12
RPV-VCK1500300RFWBBL~VA	6" 300 RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF	2
RPV-VCK1500300RFWDDBL KI	6" 300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	26
RPV-VCK1500300RFXDDBLNKI	6" 300RF SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	7
RPV-VCK1500300RFXDDBLNMA	6" 300RF SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	2
RPV-VCK1500300RFZZBLNKI	6" 300RF SW CHECK VALVE.	BC. BS 1868.	A351 CF3M / F316L, HF.	3
RPV-VCK1500300UMPDDBL KI	6" 300 UM SW CHECK VALVE	BC. BS 1868.	A352 LCC / F316, HF	5
RPV-VCK1500300UMQDDBLNVA	6" 300 UM SW CHECK VALVE,	BC, NDT	A217 C5 / F316, HF	3
RPV-VCK1500300UMRBBL*VA	6" 300 UM SW. CHECK VALVE,	BC, NDT	A217 C12 / F6 HF.	2
RPV-VCK1500600BWWDDBLNKI	6" CL 600 SW CHECK VALVE.	BC. BW 80.	A216 WCB / F316, HF.	10
RPV-VCK1500600BWWDDBLNNE	6" CL 600 SW CHECK VALVE.	BC. BW 80.	A216 WCB / F316, HF.	5
RPV-VCK1500600BWXDDBLNKI	6" CL 600 SW CHECK VALVE.	BC. BW 80.	A217 WC6 / F316, HF	4
RPV-VCK1500600RFWBBL KI	6" 600RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	3
RPV-VCK1500600RTPDDBL KI	6" 600RTJ SW CHECK VALVE	BC. BS 1868.	A352 LCC / F316, HF	1
RPV-VCK1500600UMCDDBL*KI	6" 600 UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	3
RPV-VCK1500600UMCDDBL*VA	6" 600 UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	3
RPV-VCK1500600UMCDDBLNKI	6" 600UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	2
RPV-VCK1500600UMCDDBLNPK	6" 600UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	1
RPV-VCK1500600UMPDDBL KI	6" 600UM SW CHECK VALVE	BC. BS 1868.	A352 LCC / F316, HF	9
RPV-VCK1500600UMQDDBLNKI	6" 600UM SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	6
RPV-VCK1500600UMQDDBLNVA	6" 600UM SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF	8
RPV-VCK1500600UMRBBL*VA	6" 600UM SW CHECK VALVE.	BC. BS 1868.	A217 C12 / F6, HF	5
RPV-VCK1500600UMTYBLNVA	6" 600 UM SW CHECK VALVE,	BC, NDT. B8M BOLT	A351 CF8C / F347, HF	2
RPV-VCK1500600UMVVBL*VA	6" 600 UM SW. CHECK VALVE,	BC,	ASTM A995 6A / F55, HF	1
RPV-VCK1500600UMWBBL KI	6" 600UM SW CHECK VALVE.	BC. BS 1868	A216 WCB / F6, HF.	7
RPV-VCK1500600UMWDDBL KI	6" 600UM SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	14
RPV-VCK1500600UMXDDBLNKI	6" 600UM SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	9
RPV-VCK1500900UMCDDBL*VA	6" 900UM SW CHECK VALVE.	BC. API 600. NDT	A351 CF8M / F316, HF	2
RPV-VCK1500900UMNDDBLNPK	6" 900UM SW CHECK VALVE.	BC. NDT.	A217 WC9 / F316, HF.	3
RPV-VCK1500900UMPDDBL*VA	6" 900UM SW CHECK VALVE.	BC. API 600. NDT	A352 LCC / F316, HF	10
RPV-VCK1500900UMPDDBLNKI	6" 900UM SW CHECK VALVE.	BC. BS 1868	A352 LCC / F316, HF	13
RPV-VCK1500900UMRDBLNVA	6" 900UM SW CHECK VALVE.	BC. API 600. NDT	A217 C12 / F316, HF	3
RPV-VCK1500900UMTHBL*VA	6" 900UM SW CHECK VALVE.	BC. API 600. NDT	A351 CF8C / F321, HF	2
RPV-VCK1501500BWADDPNBO	6" CL1500 SW CHECK VALVE.	PSB. BW 160	A105N / F316, HF.	20
RPV-VCK1501500BWNDDPNBO	6" CL1500 SW CHECK VALVE.	PSB. BW 160	F22 / F316, HF.	8
RPV-VCK1501500UMCDDBL*VA	6" 1500 UM SW CHECK VALVE.	BC. API 600. NDT	A351 CF8M / F316, HF	2
RPV-VCK1501500UMNDDBLNPK	6" 1500UM SW CHECK VALVE.	BC. NDT.	A217 WC9 / F316, HF.	1
RPV-VCK1501500UMPDDBLNKI	6" 1500UM SW CHECK VALVE.	BC. BS 1868	A352 LCC / F316, HF	4

GATE VALVES

GLOBE VALVES

CHECK VALVES

WAFER CHECK VALVES

BALL VALVES

BUTTERFLY VALVES

Code	Item Description			Current Stock
RPV-VCK1501500UMPDDLNVVA	6" 1500UM SW CHECK VALVE.	BC. BS1868	A352 LCC / F316, HF	10
RPV-VCK1501500UMRBBBL*VA	6" 1500 UM SW. CHECK VALVE,	BC, NDT	A217 C12 / F6 HF.	2
RPV-VCK1501500UMRDDBLNPK	6" 1500UM SW CHECK VALVE.	BC. NDT.	A217 C12 / F316, HF.	3
RPV-VCK1501500UMTHHBL*VA	6" 1500 UM SW CHECK VALVE.	BC. API 600. NDT	A351 CF8C / F321, HF	2
RPV-VCK1502500BWADDPLNBO	6" CL2500 SW CHECK VALVE.	PSB. BW 160	A105N / F316, HF.	2
RPV-VCK1502500BWF91PLNBO	6" CL 2500 PSB SW. CHECK	VALVE, FB, BW XXS	A182 F91 / F316, HF	2
RPV-VCK1502500UMPDDPC*VA	6" 2500 UM SW CHECK VALVE,	PSB, NDT	A352 LCC / F316, HF	2
RPV-VCK2000150BWWDDLNPKI	8" CL 150 SW CHECK VALVE.	BC. BS 1868. BW SCH 80	A216 WCB / F316, HF	4
RPV-VCK2000150FFBDBBK SH	8" 150 FF SW. CHECK VALVE	BC,	ASTM B148 C95800.	5
RPV-VCK2000150RFCDDDB NKI	8" 150RF SW CHECK VALVE.	BC. ANSI B16.34	A351 CF8M / F316, HF	11
RPV-VCK2000150RFCDDLBNKI	8" 150RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	4
RPV-VCK2000150RFDFFB NKI	8" 150RF SW CHECK VALVE.	BC. ANSI B16.34	A351 CF8 / F304, HF	8
RPV-VCK2000150RFPDDLBNKI	8" 150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	7
RPV-VCK2000150RFQDDLBNKI	8" 150RF SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	5
RPV-VCK2000150RFQDDLBNMA	8" 150RF SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	1
RPV-VCK2000150RFWBBL KI	8" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF	24
RPV-VCK2000150RFWBBL~VA	8" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF	2
RPV-VCK2000150RFWDDL KI	8" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	16
RPV-VCK2000300BWWDDLBNKI	8" CL 300 SW CHECK VALVE.	BC. BW 80.	A216 WCB / F316, HF.	5
RPV-VCK2000300BWWDDLBNNE	8" CL 300 SW CHECK VALVE.	BC. BW 80.	A216 WCB / F316, HF.	2
RPV-VCK2000300RFCDDLBNPK	8" 300RF SW CHECK VALVE.	BC. ANSI B16.34.	A351 CF8M / F316, HFS.	1
RPV-VCK2000300RFCDDDB NKI	8" 300 RF SW CHECK VALVE.	BC. ANSI B16.34	A351 CF8M / F316, HF	4
RPV-VCK2000300RFCDDLBNKI	8" 300RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	8
RPV-VCK2000300RDFEFLBNPK	8" 300RF SW CHECK VALVE.	BC. ANSI B16.34.	A351 CF8 / F304, HFS.	1
RPV-VCK2000300RFPDDL KI	8" 300RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	16
RPV-VCK2000300RFQDDLBNKI	8" 300RF SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	14
RPV-VCK2000300RFWBBL KI	8" 300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF	13
RPV-VCK2000300RFWBBL~VA	8" 300 RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF	2
RPV-VCK2000300RFWDDL KI	8" 300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	14
RPV-VCK2000300RFXDDBLNKI	8" 300RF SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF	6
RPV-VCK2000300RFXDDBLNMA	8" 300RF SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	1
RPV-VCK2000300UMPDDL KI	8" 300 UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	5
RPV-VCK2000300UMQDDLBNKI	8" 300 UM SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	5
RPV-VCK2000300UMRBBBL*VA	8" 300 UM SW. CHECK VALVE,	BC, NDT	A217 C12 / F6 HF.	3
RPV-VCK2000300UMRDDBLNPKI	8" 300 UM SW CHECK VALVE.	BC. BS 1868.	A217 C12 / F316, HF.	2
RPV-VCK2000300UMTHHBL*VA	8" 300 UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8C / F321, HF.	4
RPV-VCK2000300UMTHHBLNPKI	8" 300 UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8C / F321, HF.	3
RPV-VCK2000600BWWDDLBNKI	8" CL 600 SW CHECK VALVE.	BC. BW 80.	A216 WCB / F316, HF.	5
RPV-VCK2000600BWWDDLBNNE	8" CL 600 SW CHECK VALVE.	BC. BW 80.	A216 WCB / F316, HF.	2
RPV-VCK2000600BWXDDLBNKI	8" CL 600 SW CHECK VALVE.	BC. BW 160	A217 WC6 / F316, HF.	2
RPV-VCK2000600BWXDDLBNNE	8" CL 600 SW CHECK VALVE.	BC. BW 160	A217 WC6 / F316, HF.	2
RPV-VCK2000600UMPDDL KI	8" 600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	9
RPV-VCK2000600UMPDDLBNKI	8" 600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	3
RPV-VCK2000600UMPDDLBNNE	8" 600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	4
RPV-VCK2000600UMQDDLBNKI	8" 600UM SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	4
RPV-VCK2000600UMQDDLBNVA	8" 600UM SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF	2
RPV-VCK2000600UMRBBBL*VA	8" 600UM SW CHECK VALVE.	BC. BS 1868.	A217 C12 / F6, HF	2
RPV-VCK2000600UMRDDBLNPKI	8" 600 UM SW CHECK VALVE.	BC. BS 1868.	A217 C12 / F316, HF.	2
RPV-VCK2000600UMTHHBLNPKI	8" 600UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8C / F321, HF	4
RPV-VCK2000600UMWBBL KI	8" 600UM SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	3
RPV-VCK2000600UMWDDLBNKI	8" 600UM SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	6
RPV-VCK2000600UMWDDLBNNE	8" 600UM SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	5

GATE VALVES

GLOBE VALVES

CHECK VALVES

WAFER CHECK VALVES

BALL VALVES

BUTTERFLY VALVES

Code	Item Description			Current Stock
RPV-VCK2000600UMXDDBLNKI	8" 600UM SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	6
RPV-VCK2000900UMCDDBL*VA	8" 900UM SW CHECK VALVE.	BC. API 600. NDT	A351 CF8M / F316, HF	2
RPV-VCK2000900UMNDDBLNPK	8" 900UM SW CHECK VALVE.	BC. NDT.	A217 WC9 / F316, HF.	1
RPV-VCK2000900UMPDDBLNKI	8" 900UM SW CHECK VALVE.	BC.	A352 LCC / F316, HF	5
RPV-VCK2000900UMPDDBLNVA	8" 900UM SW CHECK VALVE.	BC.	A352 LCC / F316, HF	4
RPV-VCK2000900UMRDDBLNKI	8" 900UM SW CHECK VALVE.	BC.	A217 C12 / F316, HF.	2
RPV-VCK2000900UMRDDBLNPK	8" 900UM SW CHECK VALVE.	BC. NDT.	A217 C12 / F316, HF.	2
RPV-VCK2000900UMTHHBLNKI	8" 900UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8C / F321, HF	2
RPV-VCK2001500BWADDBLNBO	8" CL1500 SW CHECK VALVE.	PSB. BW 160	A105N / F316, HF.	2
RPV-VCK2001500BWADDBLNVE	8" CL 1500 PSB SW. CHECK	VALVE. FB. BW SCH 160	A105N / F316, HF	2
RPV-VCK2001500BWNDDBPCNBO	8" CL 1500 PSB SW. CHECK	VALVE. FB. BW SCH 160	A182 F22 / F316, HF	2
RPV-VCK2001500UMNDDBLNNE	8" 1500UM SW CHECK VALVE.	BC.	A217 WC9 / F316, HF	1
RPV-VCK2001500UMPDDBLNVA	8" 1500UM SW CHECK VALVE.	BC.	A352 LCC / F316, HF	4
RPV-VCK2001500UMRDDBLNKI	8" 1500UM SW CHECK VALVE.	BC.	A217 C12 / F316, HF	1
RPV-VCK2001500UMRDDBLNNE	8" 1500UM SW CHECK VALVE.	BC.	A217 C12 / F316, HF	1
RPV-VCK2002500BWF91PLNBO	8" CL 2500 PSB SW. CHECK	VALVE, FB, BW XXS	A182 F91 / F316, HF	4
RPV-VCK2002500UMPDDBL*VA	8" 2500 UM SW CHECK VALVE,	PSB, NDT	A352 LCC / F316, HF	2
RPV-VCK2500150FFBDBBK SH	10" 150 FF SW. CHECK VALVE	BC,	ASTM B148 C95800.	5
RPV-VCK2500150RFCDDDB NKI	10" 150RF SW CHECK VALVE.	BC. ANSI B16.34	A351 CF8M / F316, HF	7
RPV-VCK2500150RFCDDDBL*KI	10" 150RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	3
RPV-VCK2500150RFCDDDBL*VA	10" 150RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF.	3
RPV-VCK2500150RFPDDBL KI	10" 150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	6
RPV-VCK2500150RFPDDBLNKI	10" 150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	3
RPV-VCK2500150RFQDDBLNKI	10" 150RF SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	3
RPV-VCK2500150RFWBDBL KI	10" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF	4
RPV-VCK2500150RFWBDBL~VA	10" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF	2
RPV-VCK2500150RFWDDBL KI	10" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	6
RPV-VCK2500300RFCDDDBL*KI	10" 300RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF	5
RPV-VCK2500300RFPDDBL KI	10" 300RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	5
RPV-VCK2500300RFPDDBL*VA	10" 300RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	5
RPV-VCK2500300RFQDDBLNKI	10" 300RF SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	1
RPV-VCK2500300RFTHHBLNKI	10" 300RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8C / F321, HF	4
RPV-VCK2500300RFWABBL VE	10" 300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HFS.	2
RPV-VCK2500300RFWBDBL KI	10" 300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	9
RPV-VCK2500300RFWDDBL KI	10" 300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	16
RPV-VCK2500300RFXDDBLNKI	10" 300RF SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	3
RPV-VCK2500300UMCDDBL*VA	10" 300 UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF	1
RPV-VCK2500300UMPDDBL*VA	10" 300 UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	3
RPV-VCK2500300UMQDDBL*VA	10" 300 UM SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	1
RPV-VCK2500300UMQDDBLNKI	10" 300 UM SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	2
RPV-VCK2500300UMRDBBL*VA	10" 300 UM SW. CHECK VALVE,	BC, NDT	A217 C12 / F6 HF.	2
RPV-VCK2500300UMXDDBL*VA	10" 300 UM SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	2
RPV-VCK2500600UMPDDBL KI	10" 600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	5
RPV-VCK2500600UMPDDBLNKI	10" 600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	3
RPV-VCK2500600UMQDDBLNKI	10" 600UM SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF	5
RPV-VCK2500600UMTHHBL*VA	10" 600UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8C / F321, HF	2
RPV-VCK2500900UMCDDBL*VA	10" 900UM SW CHECK VALVE.	BC. API 600	A351 CF8M / F316, HF	1
RPV-VCK2500900UMNDDBLNNE	10" 900UM SW CHECK VALVE.	BC.	A217 WC9 / F316, HF	1
RPV-VCK2500900UMPDDBLNKI	10" 900UM SW CHECK VALVE.	BC.	A352 LCC / F316, HF	5
RPV-VCK2500900UMPDDBLNVA	10" 900UM SW CHECK VALVE.	BC.	A352 LCC / F316, HF	5
RPV-VCK2500900UMRDDBLNNE	10" 900UM SW CHECK VALVE.	BC.	A217 C12 / F316, HF	1
RPV-VCK2500900UMRDDBLNPK	10" 900UM SW CHECK VALVE.	BC.	A217 C12 / F316, HF	1

GATE VALVES

GLOBE VALVES

CHECK VALVES

WAFER CHECK VALVES

BALL VALVES

BUTTERFLY VALVES

Code	Item Description			Current Stock
RPV-VCK2500900UMTHHBL*VA	10" 900UM SW CHECK VALVE.	BC. API 600	A351 CF8C / F321, HF	1
RPV-VCK2501500BWADDBLNBO	10" CL1500 SW CHECK VALVE.	PSB. BW 160	A105N / F316, HF.	5
RPV-VCK2501500BWNDPCNBO	10" CL 1500 PSB SW. CHECK	VALVE. FB. BW SCH 160	A182 F22 / F316, HF	3
RPV-VCK2501500UMNDDBLNNE	10" 1500UM SW CHECK VALVE.	BC.	A217 WC9 / F316, HF	1
RPV-VCK2501500UMPDDBLNNE	10" 1500UM SW CHECK VALVE.	BC.	A352 LCC / F316, HF	2
RPV-VCK2501500UMPDDBLNPK	10" 1500UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	3
RPV-VCK2501500UMRDDBLNPK	10" 1500UM SW CHECK VALVE.	BC.	A217 C12 / F316, HF	2
RPV-VCK3000150FFBBSBK SH	12" 150 FF SW. CHECK VALVE	BC,	ASTM B148 C95800.	4
RPV-VCK3000150RFCDDDBL NKI	12" 150RF SW CHECK VALVE.	BC. ANSI B16.34	A351 CF8M / F316, HF	5
RPV-VCK3000150RFPDDBLNKI	12" 150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	7
RPV-VCK3000150RFPDDBLNNE	12" 150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	3
RPV-VCK3000150RFPDDBLNPK	12" 150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	3
RPV-VCK3000150RFWBBSL~VA	12" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF	2
RPV-VCK3000150RFWDDBLNKI	12" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	3
RPV-VCK3000150RFWDDBLNPK	12" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	5
RPV-VCK3000150RFWDDBLNVE	12" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	3
RPV-VCK3000300RFCDDDBL*KI	12" 300RF SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF	2
RPV-VCK3000300RFPCCBLNKI	12" 300RF SW CHECK VALVE.	BC.	A352 LCC / F316.	1
RPV-VCK3000300RFPDDBLNKI	12" 300RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	3
RPV-VCK3000300RFQDDBLNKI	12" 300RF SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF.	3
RPV-VCK3000300RFWCCBL PK	12" 300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316.	2
RPV-VCK3000300RFWDDBLNKI	12" 300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	13
RPV-VCK3000300RFXDDBLNKI	12" 300RF SW CHECK VALVE.	BC. BS 1868.	A217 WC6 / F316, HF.	2
RPV-VCK3000300UMCDDDBL*VA	12" 300 UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8M / F316, HF	2
RPV-VCK3000300UMRBBBL*VA	12" 300 UM SW. CHECK VALVE,	BC, NDT	A217 C12 / F6 HF.	2
RPV-VCK3000600UMPDDBLNKI	12" 600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	8
RPV-VCK3000600UMQDDBDNKI	12" 600UM SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF	2
RPV-VCK3000600UMRBBBL*VA	12" 600UM SW CHECK VALVE.	BC. BS 1868.	A217 C12 / F6, HF	2
RPV-VCK3000600UMRDDBLNKI	12" 600UM SW CHECK VALVE.	BC. BS 1868.	A217 C12 / F316, HF	2
RPV-VCK3000600UMTHHBL*VA	12" 600UM SW CHECK VALVE.	BC. BS 1868.	A351 CF8C / F321, HF	2
RPV-VCK3000900UMPDDBLNVA	12" 900UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	4
RPV-VCK3001500BWADDBLNVE	12" CL 1500 PSB SW. CHECK	VALVE. FB. BW SCH 160	A105N / F316, HF	2
RPV-VCK3001500BWF91PLNBO	12" CL 1500 PSB SW. CHECK	VALVE, FB, BW 160	F91 / CA15 / F304 / F316, HF	2
RPV-VCK3001500UMPDDBLNKI	12" 1500 UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	1
RPV-VCK3001500UMPDDBLNPK	12" 1500UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	1
RPV-VCK3002500BWF91PLNVE	12" CL 2500 PSB SW. CHECK	VALVE, FB, BW XXS	A182 F91 BODY	2
RPV-VCK3500150RFPDDBLNKI	14" 150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	5
RPV-VCK3500150RFWBBSL*VA	14" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	4
RPV-VCK3500150RFWBBSLNVE	14" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F6, HF.	5
RPV-VCK3500150RFWDDBL KI	14" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	4
RPV-VCK3500150RFWDDBL*VA	14" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	5
RPV-VCK3500150RFWDDBLNVE	14" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	5
RPV-VCK3500300RFPDDBLNKI	14" 300RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	3
RPV-VCK3500300RFPDDBLNVE	14" 300RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	5
RPV-VCK3500300RFQDDBLNKI	14" 300RF SW CHECK VALVE.	BC. BS 1868.	A217 C5 / F316, HF	2
RPV-VCK3500300FRBBSLNKI	14" 300RF SW CHECK VALVE.	BC. BS 1868.	A217 C12 / F6, HF	1
RPV-VCK3500300RFWDDBLNKI	14" 300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	8
RPV-VCK3500300RFWDDBLNVE	14" 300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	10
RPV-VCK3500300UMRBBBL*VA	14" 300 UM SW CHECK VALVE.	BC. BS 1868.	A217 C12 / F6, HF	1
RPV-VCK3500600UMPDDBLNKI	14" 600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	3
RPV-VCK4000150RFPDDBLNKI	16" 150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	5
RPV-VCK4000150RFWDDBLNKI	16" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	5

GATE VALVES

GLOBE VALVES

CHECK VALVES

WAFER CHECK VALVES

BALL VALVES

BUTTERFLY VALVES

Code	Item Description			Current Stock
RPV-VCK4000150RFWDDBLNPK	16" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	2
RPV-VCK4000300RFPDDBLNKI	16" 300RF SW CHECK VALVE.	BC. BS 1868. ES 311.	A352 LCC / F316, HF.	3
RPV-VCK4000300RFWDDBLNKI	16" 300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	5
RPV-VCK4000600UMPDDBLNKI	16" 600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	6
RPV-VCK4000600UMPDDBLNPK	16" 600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF.	1
RPV-VCK4000600UMRDDBL*VA	16" 600UM SW CHECK VALVE.	BC. BS 1868. NDT	A217 C12 / F316, HF	1
RPV-VCK4000600UMTHHBL*VA	16" 600 UM SW CHECK VALVE.	BC. BS 1868. NDT	A351 CF8C / F321, HF	1
RPV-VCK4001500BWF91PLNBO	16" CL 1500 PSB SW. CHECK VALVE, FB, BW 160		A182 F91 / CA15 / F304L, HF	2
RPV-VCK4500150RFPDDBLNKI	18" 150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	2
RPV-VCK4500150RFWDDBLNKI	18" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF.	4
RPV-VCK4500300RFPDDBLNKI	18" 300 RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	4
RPV-VCK4500300RFPDDBLNVE	18" 300RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	2
RPV-VCK4500300RFWDDBLNKI	18" 300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	3
RPV-VCK4500300RFWDDBLNVE	18" 300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	2
RPV-VCK4500600UMPDDBLNNE	18" 600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	4
RPV-VCK5000150RFPDDBLNKI	20" 150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	4
RPV-VCK5000150RFPDDBLNVE	20" 150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCB (LCC) / F316, HF	2
RPV-VCK5000300RFPDDBLNKI	20" 300RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	2
RPV-VCK5000300RFWDDBLNKI	20" 300RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	2
RPV-VCK5000600UMPDDBLNNE	20" 600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	4
RPV-VCK6000150RFPDDBLNVE	24" 150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	2
RPV-VCK6000150RFWDDBLNKI	24" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	2
RPV-VCK6000150RFWDDBLNVE	24" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	5
RPV-VCK6000300RFPDDBLNKI	24" 300RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	3
RPV-VCK6000600UMPDDBLNNE	24" 600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	2
RPV-VCK7000600UMPDDBLNNE	28" 600UM SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	2
RPV-VCK7500150RFPDDBLNNE	30" 150RF SW CHECK VALVE.	BC. BS 1868.	A352 LCC / F316, HF	2
RPV-VCK7500150RFWDDBL*VA	30" 150RF SW CHECK VALVE.	BC. BS 1868.	A216 WCB / F316, HF	2

GATE VALVES

GLOBE VALVES

CHECK VALVES

WAFER CHECK VALVES

BALL VALVES

BUTTERFLY VALVES